PowerLogic™ ION9000 series

User manual

7EN02-0390-08 10/2023





Legal information

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this guide are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owners.

This guide and its content are protected under applicable copyright laws and furnished for informational use only. No part of this guide may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the guide or its content, except for a non-exclusive and personal license to consult it on an "as is" basis. Schneider Electric products and equipment should be installed, operated, serviced, and maintained only by qualified personnel.

As standards, specifications, and designs change from time to time, information contained in this guide may be subject to change without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this material or consequences arising out of or resulting from the use of the information contained herein.

Safety information

Important information

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this manual or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of either symbol to a "Danger" or "Warning" safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

A CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

Please note

Electrical equipment should be installed, operated, serviced and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material. A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

Notices

FCC

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The user is cautioned that any changes or modifications not expressly approved by Schneider Electric could void the user's authority to operate the equipment.

This digital apparatus complies with CAN ICES-3 (B) /NMB-3(B).

Metering equipment symbols

The following IEC 60417 and ISO 7000 symbols may be used on the metering equipment:

Symbol	Reference	Title and description
<u></u>	IEC 60417-5017	Earth; ground To identify an earth (ground) terminal in cases where neither the symbol 5018 nor 5019 is explicitly required.
4	IEC 60417-5018	Functional earthing; functional grounding (US) * To identify a functional earthing (grounding) terminal, for example, of a specially designed earthing (grounding) system to avoid causing malfunction of the equipment.
	IEC 60417-5019	Protective class I; Protective earth/ground To identify any terminal which is intended for connection to an external conductor for protection against electric shock in case of a fault, or the terminal of a protective earth (ground) electrode.
	IEC 60417-5172	Protective class II equipment ** To identify equipment meeting the safety requirements specified for Class II equipment (double or reinforced insulation).
<u></u>	ISO 7000-0434B	Caution, refer to accompanying documents To indicate that caution is necessary when operating the device or control close to where the symbol is placed. To indicate that the current situation needs operator awareness or operator action in order to avoid undesirable consequences.
[]i	ISO 7000-1641	Operator's manual; operating instructions To identify the location where the operator's manual is stored or to identify information that relates to the operating instructions. To indicate operating instructions should be considered when operating the device or operating controls close to where the symbol is placed.

^{*} There may be national differences concerning the use of this symbol.

^{**} Protective class equipment requirements are outlined in IEC 61140.

About this manual

This manual discusses features of the PowerLogic™ ION9000 series power meter and provides configuration instructions.

Throughout the manual, the term "meter" refers to all models of the PowerLogic™ ION9000 series meter. All differences between the models, such as a feature specific to one model, are indicated with the appropriate model number or description.

This manual assumes you have an understanding of power metering and are familiar with the equipment and power system in which your meter is installed.

This manual does not provide configuration information for advanced features where an expert user would perform advanced configuration. It also does not include instructions on how to incorporate meter data or perform meter configuration using energy management systems or software, other than ION Setup. ION Setup is a free configuration tool available for download from www.se.com.

Contact your local Schneider Electric representative to learn what additional training opportunities are available regarding the PowerLogic™ ION9000 series meter.

Make sure you are using the most up-to-date version of your meter's firmware in order to access the latest features.

The most up-to-date documentation about your meter is available for download from www.se.com.





Related documents

Document	Number
PowerLogic™ ION9000 online documents	https://www.se.com/ca/en/product-range/64241-new%21-powerlogic-ion9000/#documents
PowerLogic™ ION9000 series installation guide	NVE78642
PowerLogic™ ION9000 series - LVCS installation guide	GDE96023
PowerLogic™ ION9000 series - LVDC installation guide	NNZ67817
PowerLogic™ ION9000 series - LVDC/LVCS installation guide	NNZ67818

Document	Number
PowerLogic™ ION9000 series - Measurement Canada installation guide	NNZ55235
ION Reference	7EN02-0290
PowerLogic™ ION9000 series technical datasheet	PLSED310106EN
PowerLogic™ Fiber Ethernet option module	METSEPMFIBER
PowerLogic™ 4-wire RS-485 option module	METSEPMRS4854W

Table of Contents

Safety information	3
Notices	4
Metering equipment symbols	5
Safety precautions	19
Meter overview	21
ION9000 series overview	21
Measurement accuracy	
Power quality	
Root cause analysis and sequence-of-events support	21
Cybersecurity	21
Account management	22
Your meter in an energy management system	22
Communications	22
Supported protocols	22
Meter configuration	23
ION Setup device configuration tool	23
Switching ION Setup to Advanced mode	
Data display	
Built-in web server and webpages	
Localization	
Display	
Notification	
Active and historical alarms	
Email notifications	
ION9000 meter models and accessories	
Terminal covers	
Cybersecurity	
Recommended actions	
Plan	
Cybersecurity awareness	
System defense-in-depth assumptions	
Device security capabilities	
Security risks and mitigation strategies	
Configure	
Meter security configuration Disabling and enabling protocols and changing port numbers	
Verifying the meter security settings Viewing the Device Configuration Checklist	
Applying security settings to multiple meters	
Updating passwords on multiple meters	
Default meter security settings	
Doladi. Motor occurry octains	

Advanced security mode	51
Operate	53
Monitoring the event log	53
Reporting a security incident or vulnerability	54
Maintain	54
Viewing and downloading an event log	54
Upgrades and security configuration	55
Decommission	55
Wiping the device	55
Overwriting the meter template file	57
Restoring default security configuration	57
Overwriting factory module registers	57
Overwriting communication module registers	58
Disposal, reuse, recycling	58
Installation and commissioning	60
Installation	60
Power system wiring	
Residual current measurement	
Functional ground	
LVCS overview	
LPCT configuration	63
LPCT compensation	66
Removing the display from back-to-back mounting adapter	
Removing the meter from back-to-back mounting adapter	
Option modules	
Maximum number of option modules	
Commissioning	
Factory default settings	
Commissioning using ION Setup	70
Configuring metering parameters	7 ²
Using the Phasor Viewer	
Basic setup using the webpages or display	
Communications	
Communications overview	
Ethernet communications	
Ethernet communications connections	
Protocols, ports, and connections	
Self-discovery over Ethernet	
Ethernet configuration	
DHCP	
Meter domain name	
Network protocol control	
Serial communications	
RS-485	
1.0 100	

RS-485 wiring	90
RS-485 configuration	91
Disabling serial communications ports	95
ION	96
Secure ION	96
ION sessions	99
Modbus	100
Key terms	100
Ethernet Modbus device prerequisites	100
Serial Modbus device prerequisites	101
Your meter as a Modbus client	101
Your meter as a Modbus server	104
Supported Modbus features	106
Modbus implementation	108
Modbus map	109
Configuring custom Modbus data using ION Setup	110
Ethernet gateway	112
EtherGate configuration	113
Modbus Ethernet gateway	115
Creating an Ethernet gateway site using ION Setup	116
HTTPS	117
Changing web protocol settings using ION Setup	117
Secure website indicator	118
Default SSL certificate and webpages security	118
Uploading a custom SSL certificate	118
Generating a new self-signed SSL certificate	118
Deleting a custom SSL certificate	119
Secure File Transfer Protocol (SFTP)	119
Transferring files using SFTP	119
Free up flash memory	119
SFTP folders and file permissions	119
SFTP file name restrictions	120
Simple Network Management Protocol (SNMP)	120
Key terms	120
Your meter in an SNMP system	
SNMP trapping	121
Configuring SNMP using ION Setup	122
Configuring SNMP using webpages	
SNMP implementation	
Default SNMP mapping	
Configuring SNMP MIB files	
IEC 61850	
Mapping additional data to IEC 61850	
Enabling IEC 61850 functionality	

	Configuring digital outputs for IEC 61850 control	129
	Deleting an IEC 61850 configuration file	130
	Distributed Network Protocol (DNP)	130
	DNP supported features and default implementation	130
	DLMS/COSEM	130
ln	puts/Outputs	132
	Inputs/Outputs overview	132
	Input/output ION modules	132
	Input/output ION modules, ports, and labels	133
	Factory configured settings	133
	I/O option modules	134
	Viewing I/O option module data	134
	I/O option module configuration	135
	Analog inputs	135
	Analog input applications	135
	Analog input voltage and current mode	136
	Analog input behavior	136
	Analog input zero scale and full scale values	136
	Configuring option module analog inputs using ION Setup	137
	Analog outputs	137
	Analog output applications	137
	Analog output behavior	138
	Analog output zero scale and full scale values	138
	Configuring option module analog outputs using ION Setup	138
	Digital inputs	139
	Digital input applications	139
	IRIG-B time synchronization	140
	Configuring onboard digital inputs using ION Setup	140
	Configuring option module digital inputs using ION Setup	141
	WAGES monitoring	142
	Input metering	143
	Digital outputs	145
	Digital output applications	145
	Configuring onboard digital outputs using ION Setup	145
	Configuring option module digital outputs using ION Setup	146
	Energy pulsing	147
	Default energy pulsing LED sources	147
	Configuring LED energy pulsing using ION Setup	148
	Configuring digital output energy pulsing using ION Setup	149
	Calculate your maximum kWh/pulse (pulse weight) value	150
W	ebpages	151
	Webpage interface	
	Default meter webpages	
	Accessing webpages for data viewing and meter configuration	

Embedding images and files in meter webpages	154
Creating custom webpages	154
Deleting custom webpages	155
Loading webpages using ION Setup	155
Loading webpages using SFTP	155
Sample data viewing webpage	156
Sample webpage data viewing result	156
Sample HTML code for data viewing webpage content	158
Sample setup webpage	161
Sample HTML code for setup webpage content	163
Display	167
Display overview	167
Mode indicator	167
Home button	168
Revenue lock icon	168
Alarm icon	168
Alarm and status LED indicators	169
Display icons	169
More screens access	170
Overrange indication	170
Interrupted display data	170
Auto-scaling feature	171
Display screens	171
Display modes	171
Norm mode display menu	172
Alt mode display menu	172
Alt mode data display screens	172
Setup menu	173
Meter setup using your display	174
Display setup	176
Language setup	177
Creating custom displays using ION Setup	
Display units scaling	
Configuring display units scaling using ION Setup	
Remote display troubleshooting icons	179
Alarms and alerts	180
Alarms	180
Alarm types	180
Standard and high-speed alarms	181
Relative setpoint	183
Sag/swell alarms	183
Digital alarms	184
Transient alarms	184
Alarm event priorities	184

Alarm indicators	185
Default alarms	186
Alarm information	186
Viewing and acknowledging alarms using the display	187
Alarm configuration	187
Alerts	193
Setpoint learning	194
Learning installation mode and learning duration	194
Implementing standard alarm setpoint learning using ION Setup	195
Implementing sag and swell limit learning using ION Setup	197
Implementing transient learning using ION Setup	198
Power quality	199
Power quality configuration	199
Power quality logging	200
Sags and swells	200
Transients	202
Configuring Advanced Power Quality	204
Configuring IEC 61000-4-30	204
Configuring EN 50160	205
Configuring IEEE 519	206
Configuring RVC	207
Rapid Voltage Change	207
Harmonics	207
Viewing harmonics information using the display	208
Voltage crest factor	208
Current crest factor	208
K-factor	208
Harmonic content calculations	209
THD% calculations	209
thd and TDD	209
Phasors	209
Power quality standards compliance	210
Meter compliance	210
Power quality standards compliance reporting	210
Disturbance direction detection	211
Disturbance direction detection events	212
COMTRADE	213
COMTRADE implementation	213
Waveforms on the meter webpages	
Viewing waveforms on meter webpages	
Burst data logging	216
Data recorder burst data	217
Waveform capture	
Standard waveform capture	218

Delayed waveform capture	219
Extended waveform capture	219
High-Speed Transient Capture (HSTC)	222
High-Speed Transient Capture overview	222
HSTC prerequisites	222
Verify the correct meter framework	223
Verify the correct ION Setup version	223
Commission HSTC	223
System voltage	223
Voltage reference	223
Communications	224
Set up HSTC	224
Enable and configure HSTC alarms	225
Log HSTC	226
HSTC logging	226
HSTC logging default settings	226
HSTC Data set logging	226
HSTC waveform logging	227
Enable and configure HSTC logging	228
View HSTC	228
View and acknowledge alarms	229
View HSTC logs	229
View HSTC waveforms	229
HSTC events	232
HSTC resets	233
Logging	234
Logging overview	234
Default data logging configuration	234
Revenue Log	235
Historic data logs	235
Loss Log	236
Harmonics logs	236
Energy and Demand Log	237
Daily Nominal Log	237
Rapid Voltage Change Log	238
Sag/swell Log	238
Sg/Sw HS Log	238
Transient Log	239
EN 50160 compliance logs	239
IEC 61000-4-30 logs	240
IEEE 519 compliance logs	241
Configuring data logging using ION Setup	242
Waveform recording	242
Waveform data storage format	243

Types of waveform data	243
Key terms	243
Default waveform recording configuration	244
Waveform Recorder modules	244
COMTRADE modules	245
Event log	245
Default event log configuration	246
Syslog	247
Configuring Syslog network settings using ION Setup	247
Syslog severity to event log priority mapping	248
Advanced log setup and memory optimization	248
Viewing log configuration and memory usage information	248
Log depth configuration	249
Log interval configuration	249
Log mode configuration	249
Log buffer configuration	250
Changing log interval and depth settings using ION Setup	253
Time and timekeeping	255
Time and timekeeping overview	255
Internal clock temperature compensation	
Time synchronization	
Supported time synchronization sources	
Clock source	
Clock source time quality flag	
PTP system setting recommendations	
Star network topology	
Configuring time information using ION Setup	
Configuring time information using the display	
Measurements	
Energy	
Demand	
Instantaneous measurements	
Harmonics	
Min/max recording	
Power quality measurements	
Disturbance event recording	
Power quality standards logging	
Advanced power quality features	
Power factor (PE)	
Power factor (PF)	
Apparent, active, and reactive power (PQS)	
Current phase shift from voltage	
Power demand	
Peak demand	268

Peak demand reset lockout	268
Sliding window demand	268
Examples of sliding window demand	268
Incremental energy	269
Example: Incremental energy	270
Configuring incremental energy using ION Setup	270
Conditional energy	271
Configuring conditional energy using ION Setup	271
Trending and forecasting overview	272
Trending and forecasting implementation	272
Viewing trending and forecasting data on your meter's w	ebpages272
Resets	274
Resets overview	274
Option modules reset	274
Available resets	274
Performing resets using ION Setup	275
Performing resets using the meter webpages	276
Performing resets using the display	277
Firmware upgrades	280
Firmware upgrades overview	280
Obtaining meter upgrades	
Upgrade information	280
Meter firmware	280
Restart requirement	280
Legacy security support	280
Meter firmware upgrade prerequisites	281
Back up custom meter webpages	281
Back up custom meter frameworks	281
Back up accumulated energy values	282
Download latest ION Setup	282
Connection requirements	282
Meter firmware upgrades	282
Option 1 (recommended) – Upgrading using ZIP file	283
Option 2 – Upgrading using individual upgrade files	285
Status	285
Upgrading display firmware	285
Upgrading option module firmware	285
Loading option module firmware using ION Setup	286
Loading option module firmware using SFTP	287
Maintenance	288
Maintenance overview	288
Editing accumulated energy values using ION Setup	
Test mode	
Test mode default screens	

Putting your meter in test mode using ION Setup	289
Putting your meter in test mode using the display	290
Cleaning instructions	290
Device-specific information	291
Revenue	293
Revenue metering components	293
Revenue firmware security features	293
Protected features and settings	293
Revenue locking	293
Revenue-locking summary	294
Revenue lock switch	294
Revenue lock LED behavior	294
Revenue locking your meter	295
Anti-tamper sealing	295
PT/CT correction	296
Transformer loss compensation	296
Time of use	297
Energy pulsing LED behavior	
Verifying accuracy	298
Verifying accuracy overview	298
Accuracy test requirements	298
Signal and power source	298
Control equipment	298
Environment	299
Reference device or energy standard	299
Energy pulsing	299
Verifying accuracy test meter settings	300
Verifying accuracy test	
Calculate the number of required pulses	302
Percentage error calculation for accuracy verification testing	302
Typical sources of test errors	303
Accuracy verification test points	
Troubleshooting	305
Setting up Advanced security troubleshooting	305
Option module troubleshooting	306
Technical assistance	307
ION9000 specifications	308
Mechanical characteristics	308
Mechanical compliance	308
Electrical characteristics	308
Environmental characteristics	312
LEDs	312
EMC (electromagnetic compatibility)	312

Safety	313
Ethernet communications	313
RS-485 communications	
Real-time clock	314
Display	314
Option modules	
Other	316

Safety precautions

Installation, wiring, testing and service must be performed in accordance with all local and national electrical codes.

AA DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Apply appropriate Personal Protective Equipment (PPE) and follow safe electrical work practices. See NFPA 70E, CSA Z462 or other local standards.
- Turn off all power supplying this device and the equipment in which it is installed before working on or in the equipment.
- Follow guidelines in the Wiring section of the related Installation Guide.
- Always use a properly rated voltage sensing device to confirm that all power is off.
- Do not use the data from the meter to confirm power is off.
- Do not exceed the maximum ratings of this device.
- Do not short secondary terminals of Voltage Transformer (VT).
- Do not open secondary terminals of Current Transformer (CT).
- Ground secondary circuit of CTs.
- Use only Low Power Current Transformers (LPCTs) that are approved for use with this
 device.
- Do not connect CT secondary signals to meter low voltage LPCT terminals.
- Do not install CTs or LPCTs in equipment where they exceed 75% of the wiring space of any cross-sectional area in the equipment.
- Do not install CTs or LPCTs in areas where ventilation openings may be blocked or in areas
 of breaker arc venting.
- Do not install CTs or LPCTs using Class 2 wiring methods or connect to Class 2 equipment.
 See NFPA 70.
- Secure CT or LPCT secondary conductors to ensure they do not contact live circuits.
- Assume communications and I/O wiring are hazardous live until determined otherwise.
- Replace all devices, doors and covers before turning on power to this equipment.

Failure to follow these instructions will result in death or serious injury.

NOTE: See IEC 60950-1 for more information on communications and I/O wiring connected to multiple devices.

WARNING

UNINTENDED OPERATION

Do not use this device for critical control or protection of persons, animals, property, or equipment.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

WARNING

POTENTIAL COMPROMISE OF SYSTEM AVAILABILITY, INTEGRITY, AND CONFIDENTIALITY

- Change default passwords/passcodes to help prevent unauthorized access to device settings and information.
- Disable unused ports/services and default accounts, where possible, to minimize pathways for malicious attacks.
- Place networked devices behind multiple layers of cyber defenses (such as firewalls, network segmentation, and network intrusion detection and protection).
- Use cybersecurity best practices (for example: least privilege, separation of duties) to help prevent unauthorized exposure, loss, modification of data and logs, interruption of services, or unintended operation.

Failure to follow these instructions can result in death or serious injury or equipment damage.

Meter overview

ION9000 series overview

The ION9000 series advanced energy and power quality meter helps meet the needs of your energy management, power management, and cost management applications within your EcoStruxure™ Power architecture.

ION9000 series revenue-accurate meters comply with international metering standards. The meters feature flexible ION programmability that enhances functionality through customization by loading specialized frameworks. You can add optional modules and incorporate mounting accessories into the physical installation to meet a variety of installation and application needs.

Measurement accuracy

Third-party international standards-certified:

- Class 0,1S for energy
- Power Quality Instrument Class A (PQI-A) for all normative IEC 61000-4-30 power quality metrics
- IEC 62053-22, -23, -24 and ANSI C12.20

Power quality

Third-party international standards-certified:

- IEC 62586-1, IEC 62586-2, and IEC 61000-4-30
- EN 50160, including flicker monitoring
- IEEE 519

Root cause analysis and sequence-of-events support

- Disturbance Direction Detection
- High-speed RMS data capture with pre and post event records
- Extended waveform capture
- Time quality flag for GPS or PTP time sources
- Time synchronization to 1 ms accuracy
- High-speed voltage transient capture with 10 MHz sampling rate (ION9000T only)

Cybersecurity

- · Meter security with multiple users and access levels
- Total control for each communications port and protocol, including protocol lockout
- Secure webpages (HTTPS)
- Support for meter event logging to a remote server (syslog)

Account management

If your meter's user access information is lost, you must return the meter to the factory, where your meter is reset to its factory defaults and all logged data is lost.

NOTICE

DATA LOSS

Record your device's user and password information in a secure location.

Failure to follow these instructions can result in loss of data.

Your meter in an energy management system

As a key piece in your energy management system, the PowerLogic[™] ION9000 series meter provides highly accurate measurements and calculations for a wide variety of power system values, performs analysis on collected data, alerts you of potential issues and integrates with a variety of display and analysis software.

It performs analysis on collected data, alerts you of potential issues and integrates with a variety of edge control software such as EcoStruxure™ Power Operation and EcoStruxure™ Power Monitoring Expert, and cloud-based energy management software such as EcoStruxure™ Energy One Hub.

For further analysis, you can also connect your meter with EcoStruxure™ Power Advisor to enhance the performance and maintenance of power networks.

Communications

Supported protocols

Your meter's fundamental protocol and architecture is ION.

You can integrate the meter into various industry-standard networks. Data that the meter measures can be made available to other devices using:

- Modbus
- DNP 3.0
- DLMS
- SNMP
- MV-90 billing software

You can configure the meter to import data from other devices on these networks. Your meter supports the IEC 61850 protocol and COMTRADE waveform data format.

Your meter also supports IPv6, Devices Profile for Web Services (DPWS), and Rapid Spanning Tree Protocol (RSTP) Ethernet protocols.

Meter configuration

ION Setup device configuration tool

ION Setup is a free configuration tool for your meter that lets you remotely configure your meter's features over Ethernet or serial communications.

- Use the setup screens to guide you through the process of configuring your meter.
- Use the real-time data screens to verify your meter's configuration.
- · Use the data screens to view your meter's recorded data.
- · Use the charting function to view your meter's recorded waveforms.
- Use ION Setup in Advanced mode to work directly with modules.

Download ION Setup from www.se.com.

Switching ION Setup to Advanced mode

- 1. Open ION Setup.
- 2. Ctrl + click on the meter to select it. This switches ION Setup to Advanced mode.

Data display

Built-in web server and webpages

Your meter's onboard internal web server and built-in webpages provide quick and easy access to real-time energy, basic power quality information and meter configuration without having to use specialized software.

Localization

The meter can be customized to use different regional settings.

Localization settings determine:

- The language used for the display and webpages
- Time, date, and digit formats
- Displayed phase labels (123/ABC)
- Institute of Electrical and Electronics Engineers (IEEE) or International Electrotechnical Commission (IEC) conventions for power, power factor, and energy

Configure your meter's localization settings using ION Setup or the display.

Display

Use the meter's display to view real-time and historical power quality data, access monitoring tools, receive and acknowledge alarms, and perform basic device configuration.

The touch-screen color display has multiple mounting options to suit your environment and an eight-language interface with external LED indicators for power, alarms, and energy pulsing applications.

Notification

Active and historical alarms

The meter's display shows an alarm icon and the alarm LED flashes if your meter detects an active alarm condition.

Depending on the priority of the alarm, the display also flashes. You can view and acknowledge active alarms, historic alarms, and events using the display and webpages.

An active alarm becomes a historic alarm when the alarm condition no longer exists.

Email notifications

Configure your meter to automatically email information such as notification of a high-priority event or a regularly scheduled send of logged data.

Specify the type of event that triggers an email alert, such as a power quality disturbance or interval for logged data. Email messages from your meter are received like any other email message.

ION9000 meter models and accessories

Commercial references for the ION9000 series meter and accessories.

Commercial reference	Description	
METSEION92030	ION9000 series meter	
METSEION92830		
METSEION92040	ION9000 series meter with RD192 remote display	
METSEION92043	ION9000 series – Measurement Canada Approved meter	
METSEION92044	ION9000 series – Measurement Canada Sealed meter	
METSEION92130	ION9000 series – LVDC meter	
METSEION92140	ION9000 series – LVDC meter with RD192 remote display	
METSEION93030	ION9000 series – LVCS meter	
METSEION93040	ION9000 series – LVCS meter with RD192 remote display	
METSEION93130	ION9000 series – LVDC/LVCS meter	
METSEION93140	ION9000 series – LVDC/LVCS meter with RD192 remote display	
METSEION95030	ION9000T series meter	
METSEION95040	ION9000T series meter with RD192 remote display	
METSERD192	RD192 192 x 192 mm remote display with ION9000 series back-to-back mounting adapter and 1/4 DIN (92 x 92 mm) panel cutout mounting adapter	

Commercial reference	Description
METSEPM89RD96	PM89RD96 96 x 96 mm remote display with 1/4 DIN (92 x 92 mm) panel cutout mounting adapter
METSEPM89M2600	Digital I/O option module (2 outputs, 6 inputs)
METSEPM89M0024	Analog I/O option module (2 outputs, 4 inputs)
METSEPMRS4854W	4-wire RS-485 option module
METSEPMFIBER	Fiber Ethernet option module
METSE9B2BMA	ION9000 series back-to-back mounting adapter
METSE9HWK	ION9000 series replacement hardware connectors and terminal covers
METSE9HWKLVCS	ION9000 series – LVCS replacement hardware connectors and terminal covers
METSE9USBK	RD192 replacement USB cover
METSERD192HWK	RD192 replacement hardware kit
METSECAB10	Remote display cable, 10 m

For more information on meter types and accessories, refer to your meter's catalog pages, available from www.se.com.

Terminal covers

The terminal covers enclose the terminals, the conductor fixing screws, and a length of the external conductors and their insulation. The terminal covers are secured by tamper-resistant meter seals.

The voltage and current terminal covers help prevent tampering with the meter's voltage and current measurement inputs.

These covers are included for meter models where sealable voltage and current covers are required to comply with revenue or regulatory standards.

The meter terminal covers must be installed by a qualified installer.

Refer to your meter's installation guide or the instructions that came with your terminal covers for instructions on installing the terminal covers.

Cybersecurity

Your device has security capabilities that:

- Allow it to be part of a NERC CIP compliant facility. For information on NERC Reliability Standards, go to the North American Electric Reliability Corporation website.
- Align with cybersecurity standards in the IEC 62443 international standard for business IT systems and Industrial Automation and Control Systems (IACS) products. For information about the IEC 62443 international standard, go to the <u>International Electrotechnical</u> Commission website.

This chapter contains information about your product's cybersecurity. Network administrators, system integrators, and personnel that commission, operate, maintain, or decommission a device should review "Recommended actions" on page 26 to help secure your device in a protected environment.

WARNING

POTENTIAL COMPROMISE OF SYSTEM AVAILABILITY, INTEGRITY, AND CONFIDENTIALITY

- Change default passwords/passcodes to help prevent unauthorized access to device settings and information.
- Disable unused ports/services and default accounts, where possible, to minimize pathways for malicious attacks.
- Place networked devices behind multiple layers of cyber defenses (such as firewalls, network segmentation, and network intrusion detection and protection).
- Use cybersecurity best practices (for example: least privilege, separation of duties) to help prevent unauthorized exposure, loss, modification of data and logs, interruption of services, or unintended operation.

Failure to follow these instructions can result in death or serious injury or equipment damage.

Recommended actions

Your device is designed to be used in a protected environment that uses a defense in depth strategy, in compliance with IEC 62443, the global standard for industrial automation control system security.

To help secure your device, you must take specific actions at every stage of the project life-cycle.

NOTE: The list of recommended actions below is not a complete list of possible cybersecurity measures. It is meant to be a starting point to improve the security of your device in a protected environment. Consult with cybersecurity experts to plan, configure, operate, maintain, and decommission your device based on your needs.

The following table lists the actions we recommend you take to help secure your device in a protected environment, organized by life-cycle stage:

Recommended action	Defense-in-depth role
Plan	
Review cybersecurity awareness	Resources to increase your cybersecurity knowledge and awareness.
Review the system defense in depth assumptions	Understand the security measures expected to be provided by the external environment in which the device is to be used.
Review the device security capabilities	Understand how the device's security capabilities can be used in a protected environment.
Review the "Security risks and mitigation strategies" on page 34	Known security risks and the mitigation strategies to help minimize the risks.
Review the Security risks and mitigation strategies	Known security risks and the mitigation strategies to help minimize the risks.
Configure	
Change the default password *	Help reduce unauthorized access. Default account settings are often the source of unauthorized access by malicious users.
Disable meter configuration methods *	Limiting configuration options and providing read-only access reduces the attack surface of the meter.
Disable webpages and	Disable webpages to deny a web browser to access the meter data. If your meter can be accessed by a web browser outside your protected network, a malicious user could intercept communications.
time sync sources *	Disable the ability to modify the meter's time source to help protect against disguised communication from an unknown source as being trusted and possibly invalidating timestamps.
Define lockouts and event timeouts *	Lock accounts after a predefined number of unsuccessful login attempts. Lockouts help reduce brute-force password attacks from succeeding.
Limit user access*	Limit user access to the minimum, least privilege level of access needed to perform their job functions.
	Revoke user privileges when no longer needed due to role change, transfer, or termination.
Edit meter access event logging *	Edit the default meter access event priorities that are logged to the event log to meet your reporting requirements.

December 1 and 1 and 1	Defense to death and	
Recommended action	Defense-in-depth role	
Create and change user passwords *	Create strong passwords for each user that requires access to the meter. Default account settings and weak passwords are often the source of unauthorized access by malicious users.	
	Follow user account management tasks as described by your organization or contact your network administrator. For example, maximum password age or history policies.	
Set up Advanced security *	Advanced security is the default meter security mode. If your meter uses standard security mode, we recommend you change it to advanced.	
Disable unused protocols	Disable unnecessary and unused communication protocol ports, such as SFTP and network ports, to reduce the meter attack surface.	
and change default port numbers	Change port number default values to reduce the predictability of port use.	
	See "Protocols, ports, and connections" on page 75.	
Revenue-lock the meter and use anti-tamper sealing points	Physical lock switch with tamper-evident seal to prevent remote modification of revenue parameters, settings, and data.	
Validate security settings	Verify the meter security configuration.	
Assign a dedicated reader for event log notifications	Assigning a dedicated reader can help prevent event log entries being overwritten before they are reviewed.	
Configure syslog to store event logs	A syslog server can receive logs from multiple devices and store the log information as needed. Syslog helps maintain meter log information for extended periods of time.	
	See "Syslog" on page 247.	
Operate		
Monitor the event log	Monitor event logs for suspicious activity and to help identify the cause of cybersecurity breaches that could lead to a cybersecurity incident.	
Report a cybersecurity incident or vulnerability	Report suspicious activity, a cybersecurity incident, or a vulnerability to Schneider Electric.	
Maintain		
Apply firmware updates	Keeping your device firmware up to date helps protect you from security vulnerabilities.	
Check the revenue lock and anti-tamper seals	Follow your company's policies and standards by periodically checking your device locks and seals to verify that the device has not been tampered with.	

Recommended action	Defense-in-depth role
	Limit user access to the minimum, least privilege level of access needed to perform their job functions.
Review user accounts on a regular basis	Revoke user privileges when no longer needed due to role change, transfer, or termination.
	See "Limiting user access" on page 42 for details.
Keep your network security up to date.	Helps reduce your attack surface, decreasing the likelihood of a vulnerability.
Perform security audits	Help verify the security status of your system.
Decommission	
Record decommissioning activities	Document disposal actions according to your company's policies and standards to keep a record of activities.
Wipe the device	Help prevent the potential disclosure of data.
	Follow decommission and sanitization tasks as described by your organization or contact your network administrator.
Decommission-related rules and sanitize records	Decommission network and security rules. For example, a firewall rule that could be used to get past the firewall.
	Perform records tracking sanitization tasks to remove records in related systems. For example, monitoring SNMP servers.
Dispose, reuse, or recycle the device	Follow local disposal regulations.

^{*} For detailed information on the default meter security settings, see "Default meter security settings" on page 50.

Plan

Before you install your device, use the following planning information to help you prepare for the installation and commissioning of your meter in your facility.

- "Cybersecurity awareness" on page 29
- "System defense-in-depth assumptions" on page 30
- "Device security capabilities" on page 31
- "Security risks and mitigation strategies" on page 34

Cybersecurity awareness

Knowledge is the first step to help prevent cyber intrusions. Review the following to increase your cybersecurity awareness:

- Cybersecurity Best Practices guide
- EcoStruxure[™] Power Guide for Designing and Implementing a Cyber Secure Digital Power System

Subscribe to Schneider Electric security notifications

Register for Schneider Electric security notifications on the <u>Schneider Electric Cybersecurity</u> Support Portal website.

System defense-in-depth assumptions

Defense-in-depth is an information security strategy integrating people, technology, and operations capabilities to establish variable barriers across multiple layers and dimensions in your information technology and control system.

Defense-in-depth helps minimize data protection gaps, reduces single-points-of-failure, and creates a strong cybersecurity posture. The more layers of security in your system, the harder it is to breach defenses, take digital assets or cause disruption.

Using a defense-in-depth strategy by securing the device in a protected environment will help reduce your attack surface, decreasing the likelihood of a vulnerability.

Before you install your device, review the following system defense-in-depth assumptions. If you have not already adopted these assumptions, we strongly recommend you add them to help improve your cybersecurity posture.

Site security assumptions

- Perimeter security Installed devices, and devices that are not in service, are in an accesscontrolled or monitored location.
- Emergency power The control system provides the capability to switch to and from an emergency power supply without affecting the existing security state or a documented degraded mode.

Network security assumptions

- **Controls against malware** Detection, prevention, and recovery controls to help protect against malware are implemented and combined with appropriate user awareness.
- Physical network segmentation The control system provides the capability to:
 - Physically segment control system networks from non-control system networks.
 - Physically segment critical control system networks from non-critical control system networks.
- Logical isolation of critical networks The control system provides the capability to logically and physically isolate critical control system networks from non-critical control system networks. For example, using VLANs.

- Independence from non-control system networks The control system provides network services to control system networks, critical or non-critical, without a connection to noncontrol system networks.
- Zone boundary protection The control system provides the capability to:
 - Manage connections through managed interfaces consisting of appropriate boundary protection devices, such as proxies, gateways, routers, firewalls, and encrypted tunnels.
 - Use an effective architecture. For example, firewalls protecting application gateways residing in a DMZ.
 - Control system boundary protections at any designated alternate processing sites should provide the same levels of protection as that of the primary site. For example, data centers.
- **No public internet connectivity** Access from the control system to the internet is not recommended. If a remote site connection is needed encrypt protocol transmissions.
- Resource availability and redundancy Ability to break the connections between different network segments or use duplicate devices in response to an incident.
- Manage communication loads The control system provides the capability to manage communication loads to mitigate the effects of information flooding types of DoS (Denial of Service) events.
- Control system backup Available and up-to-date backups for recovery from a control system failure.
- Encrypt protocol transmissions over all external connections Use an encrypted tunnel, TLS wrapper, or a similar solution.

Administrative assumptions

- Cybersecurity governance Available and up-to-date guidance on the secure use of information and technology assets in your company.
- Firmware upgrades Meter upgrades are implemented consistently to the current version of firmware.

For detailed information on the device security capabilities, see "Device security capabilities" on page 31.

Device security capabilities

Your device includes security capabilities that, when combined with other defense-in-depth measures, can help reduce vulnerabilities.

Before you install your device, carefully review the following device security capabilities to understand how you can configure and use the device securely in a protected environment.

Security area	Device security capabilities	Role in defense-in-
Physical	 Revenue-lock switch Anti-tamper sealing points LED lock status indicator on the device Revenue lock icon on the display. 	These capabilities help prevent unauthorized access to revenue-related parameters and settings or leave clear evidence that the device has been physically tampered with.
Information confidentiality	SSH, SFTP, HTTPS support, Secure ION, and Secure EtherGate	These secure protocols employ cryptographic algorithms, key sizes, and mechanisms to help prevent unauthorized users from reading information in transit.
Access	 User authentication identifies and authenticates software processes and devices managing accounts. Least privilege in multiple dimensions: read, peak demand reset, time sync, test mode, meter configuration, and security and communications configuration. User account lockout limits the number of unsuccessful login attempts. Use control restricts allowed actions to the authorized use of the control system. Supervisors can override user authorizations by deleting user accounts. Password strength feedback using ION Setup. 	These capabilities help enforce authorizations assigned to users, segregation of duties, and least privilege.

Security area	Device security capabilities	Role in defense-in- depth
	Internal time synchronization.	
	 Time source integrity protection and meter configuration event logging. 	
	 Timestamps, including date and time, match the meter clock. 	
	 The device embeds user information when a change is made. 	These capabilities support the analysis of
Device configuration	 SSH server hosts an internal SFTP site and stores files in the meter's flash memory, such as webpages, COMTRADE records, and firmware files. 	security and user account events and help protect the device from unauthorized alteration and record configuration changes.
	 Settings can be saved as a Security Configuration File (.scf) using ION Setup. 	
	 Offload information to syslog or a protected storage or retention location. 	
	• Least functionality.	
	 Default port numbers can be changed to lower the predictability of port use. 	
Device hardening	 Unused protocols can be disabled to reduce the attack surface of the device. 	These capabilities help prohibit and restrict the use of unnecessary functions, ports, protocols, and services.
	 Inactivity timeout requires sign in after a time-period of inactivity for webpages, display, and Secure ION protocol. 	
	 Limit the number of consecutive failed login attempts. 	

Security area	Device security capabilities	Role in defense-in- depth
	 Machine and human-readable reporting options for current device security settings. 	
	Audit event logs to identify:	
	 Meter configuration changes. 	
Operation	 Energy management system events. 	These capabilities help provide a method to generate security-related reports and manage event log storage.
	 Audit record storage capacity communication to notify a user when the threshold is approaching. 	
	 Audit storage capacity of 5,000 event logs by default and alternate methods for log management. 	
	 Time source integrity protection and event logged when changed. 	
Maintenance: Upgrade and backup	 Digitally signed firmware is used to help protect the authenticity of the firmware running on the meter and only allows firmware generated and signed by the manufacturer. 	This security capability helps protect the authenticity of the firmware running on the meter and facilitates protected file transfer.
Decommissioning	 Purge shared memory resources through device wiping and other decommissioning tasks. 	These capabilities help prevent the potential disclosure of data when
	 Physical (recommended) or sustainable device disposal possibilities. 	the device is decommissioned.

For detailed information on the system defense-in-depth assumptions, see "System defense-in-depth assumptions" on page 30.

For detailed information on how to help secure your device in a defense-in-depth protected environment, see "Recommended actions" on page 26.

Security risks and mitigation strategies

Review the following issues and security risks and the mitigation strategies to help minimize the risks:

Issue	Security risk	Mitigation strategies
User accounts Default account settings are often the source of unauthorized access by malicious users.	If you do not change the default password, unauthorized access can occur.	Change the default password of 0 (zero) to help reduce unauthorized access. See "Changing the default password" on page 37.
Secure protocols ION, Modbus, DNP, DLMS, IEC 61850 and some IT protocols are unsecure. The device does not have the capability to transmit data encrypted using these protocols.	If a malicious user gained access to your network, they could intercept communications.	For transmitting data over an internal network, physically or logically segment the network. For transmitting data over an external network, encrypt protocol transmissions over all external connections using an encrypted tunnel, TLS wrapper, or Secure ION. See "System defense-in-depth assumptions" on page 30. Disable unused protocols
Self-signed certificates		
Factory shipped meters include a self-signed SSL certificate. An SSL certificate is required to use webpages over HTTPS and Secure ION (ION over TLS).	Self-signed certificates can't be validated. An attacker with access to the network could pose as the device to obtain credentials sent over the TLS tunnel.	Use a Certificate Authority (CA) signed SSL certificate and external network controls.

Configure

This section contains detailed information on the following tasks:

- "Meter security configuration" on page 36 in a protected environment
- "Disabling and enabling protocols and changing port numbers" on page 46
- "Verifying the meter security settings" on page 47
- "Applying security settings to multiple meters" on page 48

This section also includes the following reference information:

- "Default meter security settings" on page 50
- "Advanced security mode" on page 51

Meter security configuration

Meter security configuration using ION Setup consists of the following tasks:

- 1. Open a Security Configuration File
- 2. Configure the meter security settings
- 3. Push the updated security settings to the meter
- 4. Store the updated SCF file

Opening a meter security configuration file

Meter security settings are stored in an encrypted Security Configuration File (SCF).

Use ION Setup to open a SCF file.

Prerequisites:

- Meter connection using ION Setup.
- Login credentials.
- Security configuration access privileges.

To open the meter security configuration file:

- 1. In ION Setup, select the meter, and then open Setup Assistant.
- 2. Click Security > Security Mode > Edit.
- 3. Enter the meter password, and then click **OK**.
- 4. Select the SCF file that you want to edit, and then click **Open**.

NOTE: We recommend that you use Advanced security mode.

For more information on SCF files, see "Storing Security Configuration Files" on page 45.

The meter security configuration settings open in the ION Setup Security wizard.

Next, configure the meter security settings.

Configuring the meter security settings

After you open a SCF file, ION Setup displays the security settings in a Security wizard.

Use the ION Setup Security wizard to complete the following security configuration tasks:

- "Changing the default password" on page 37
- "Disabling and enabling meter configuration options" on page 37
- "Disabling and enabling webpages and time sync sources" on page 38
- "Defining lockout and event timeout" on page 39
- "Editing meter access event logging" on page 40
- "Limiting user access" on page 42
- "Creating and changing user passwords" on page 43

Changing the default password

Change the default password of 0 (zero) to help reduce unauthorized access. Default account settings are often the source of unauthorized access by malicious users.

Prerequisites:

Open a Security Configuration File in the ION Setup Security wizard.

To change the default password:

- In the ION Setup Security wizard, click Next to navigate to Define individual users/passwords.
- 2. Highlight USER1, and then click Password.
- 3. Enter and confirm the new password.

TIP: Use strong passwords to increase the password complexity. A password can be any combination or letters and numbers, up to sixteen characters.

NOTICE

LOSS OF ACCESS

Ensure that the password you set is compatible with the device front panel and any software used to communicate with the device.

Failure to follow these instructions can result in loss of access to the device.

While ION Setup supports up to sixteen character passwords, some ION software clients may not yet support passwords longer than six alphanumeric characters.

- 4. Click OK.
- 5. Next, either:
 - Continue configuring the meter security settings.
 - Click Finish to push your security configuration changes to the meter.

Disabling and enabling meter configuration options

Limiting configuration options, such as Modbus, webpages, and the display, and providing readonly access reduces the attack surface of the meter.

Prerequisites:

Open a Security Configuration File in the ION Setup Security wizard

To disable and enable meter configuration methods:

1. In the ION Setup Security wizard, click **Next** to navigate to **Security Options**.

2. In Security Options:

Select or clear **Enable Web** to enable or disable the ability to view meter settings online using webpages.

Select or clear **Allow setup by webpages** to enable or disable the ability to change meter settings using webpages.

Select or clear **Allow Front Panel programming** to enable or disable the ability to change meter settings using the display.

Select from the Modbus Access drop-down list:

- None Disables built-in Modbus map access.
- Read/Write Enables configuration of basic metering parameters using only Modbus communications protocol.
- Read Only Enables ability to read metering parameters using only Modbus communications protocol. This option is enabled by default.
- 3. Next, either:
 - Continue configuring the meter security settings.
 - Click Finish to push your security configuration changes to the meter.

Disabling and enabling webpages and time sync sources

Disable webpages to deny a web browser to access the meter data. If your meter can be accessed by a web browser outside your protected network, a malicious user could intercept communications. See "Disabling and enabling protocols and changing port numbers" on page 46 for details on enabling HTTPS.

Disable the ability to modify the meter's time source to help protect against disguised communication from an unknown source as being trusted and possibly invalidating timestamps. See "Configuring time information using ION Setup" for detailed steps on setting up the time source.

Prerequisites:

Open a Security Configuration File in the ION Setup Security wizard

To disable and enable webpages and time sync sources:

- 1. In the ION Setup Security wizard, click **Next** to navigate to **Security Options**.
- 2. In Security Options:
 - Select or clear Enable Web to enable or disable webpages for viewing meter data online using a web browser.
 - Select or clear Allow Broadcasting Time Synchronization to enable or disable the ability to modify the meter's time synchronization source.

- 3. Next, either:
 - Continue configuring the meter security settings.
 - Click Finish to push your security configuration changes to the meter.

Defining lockout and event timeout

A lockout prevents logging into a valid user account after a predefined number of unsuccessful login attempts. Lockouts help reduce brute-force password attacks from succeeding.

Event timeout defines the time interval during which identical incorrect credentials are treated as a single login attempt for event recording.

NOTE: Failed user login attempts over Ethernet—and any associated lockouts—will apply to both ION and Secure ION. Failed user login attempts over other communication channels—such as a serial port—are tracked separately.

You can define the following account lockout and event timeout options:


- · Lockout after unsuccessful login attempts.
- Lockout duration.
- Event timeout for ION or Secure ION only, and only when not using ION sessions.

Prerequisites:

Open a Security Configuration File in the ION Setup Security wizard

To define user lockouts and timeouts:

 In the ION Setup Security wizard, click Next to navigate to Select protocol lockout options:



- 2. Select each protocol and click **Edit** to change lockout and timeout values for:
 - User lockout after unsuccessful login attempts.
 - Timeout for ION protocol only.
- 3. Enter a value for the **Lockout duration** in minutes.
- 4. Next, either:
 - Continue configuring the meter security settings.
 - Click Finish to push your security configuration changes to the meter.

Editing meter access event logging

The event log monitors meter access events such as user logins and user account lockouts.

You can edit the default meter access event priorities that are logged to the event log to meet your reporting requirements.


To monitor meter access events, see "Monitoring the event log" on page 53.

Prerequisites:

Open a Security Configuration File in the ION Setup Security wizard.

To configure meter access event logging:

1. In the ION Setup Security wizard, click **Next** to navigate to **Select protocol lockout options**:



2. Click **Events**. The Event Priorities dialog box opens:



3. For each meter access event priority, set the value according to your reporting requirements. The following table describes the priority value ranges:

Priority	Description	Value range
None	Not recorded in the event log.	0
Info Only	The default event log cutoff value is 5. Event values equal to or less than the cutoff value are not recorded in the event log nor in syslog records.	1–5
	Recorded in the event log and in syslog records.	6–63
	Produces low alarm.	
Low	Recorded in the event log and in syslog records.	64–127

Priority	Priority Description	
	Produces medium alarm.	
Medium	Recorded in the event log and in syslog records.	128–191
	Produces high alarm.	
High	Recorded in the event log and in syslog records.	192–255

- 4. Click OK.
- 5. Next, either:
 - Continue configuring the meter security settings.
 - Click Finish to push your security configuration changes to the meter.

You can also change event priorities for cybersecurity events using ION Setup Advanced Mode.

Limiting user access

Limit user access to the minimum level of access needed to perform their job functions.

Revoke user privileges when no longer needed due to role change, transfer, or termination. User credentials do not expire.

NOTE: The maximum number of users is 50. Users can be added or removed at any time.

Prerequisites:

Open a Security Configuration File in the ION Setup Security wizard

To define user access:

1. In the ION Setup Security wizard, click **Next** to navigate to **Define individual** users/passwords.

NOTICE

DATA LOSS

Record your device's user and password information in a secure location.

Failure to follow these instructions can result in loss of data.

Define individual users/passwords × Step 4: User Privileges Define each user's access by selecting the appropriate check boxes and for leach user, enter in a password. NOTE: Users granted Security Config Access. requires all other access rights in this firmware. ■ USER1 Password ☑ Time Sync Access □ Read Access Show Peak Demand Reset Access Comm Config Access ol8712 ☐ Test Mode Access □ Full Meter Config Access ✓ Security Config Access < Back Finish Cancel Help

2. For each user, select the user, and then assign their permissions:

See for "Access " on page 32 information on the device access level permissions.

- 3. Next, either:
 - Continue configuring the meter security settings.
 - Click Finish to push your security configuration changes to the meter.

Creating and changing user passwords

Create strong passwords for each user that requires access to the meter. Default account settings and weak passwords are often the source of unauthorized access by malicious users.

To optimize cybersecurity in a protected environment, follow user account management tasks as described by your organization or contact your network administrator, for example, maximum password age or history policies.

Prerequisites:

Open a Security Configuration File in the ION Setup Security wizard.

To change a password:

1. In the ION Setup Security wizard, click **Next** to navigate to **Define individual** users/passwords.

NOTICE

DATA LOSS

Record your device's user and password information in a secure location.

Failure to follow these instructions can result in loss of data.

- 2. For each user that you want to assign or change a password:
 - a. Highlight the USER, and then click Password.
 - b. Enter and confirm the password.

TIP: Use Password strength to increase the password complexity. A password can be any combination or letters and numbers, up to 16 characters.

- c. Click OK.
- 3. Next, either:
 - Continue configuring the meter security settings.
 - Click Finish to push your security configuration changes to the meter.

You can also change the password using ION Setup Diagnostics tool, Security Options Module using ION Setup Advanced Mode, and Power Monitoring Expert.

Setting up Advanced security

Meter security has strong user login, user access management, and password complexity.

NOTE: We recommend that you use Advanced security mode.

For detailed information on the Advanced security mode capabilities, see "Advanced security mode" on page 51.

Prerequisites:

- Meter connection using ION Setup.
- Login credentials.
- Security configuration access privileges.

To set up Advanced security:

- 1. Open ION Setup > select the meter > **Setup Assistant**.
- 2. **Security > Security Mode > Edit.** The Open Security Configuration file dialog box opens.
- 3. Select the **advanced.scf** security configuration file.
- 4. Click **Open**. If prompted, click **Yes** to use Advanced security.

- 5. Next, either:
 - Continue configuring the meter security settings.
 - Click **Finish** to push your security configuration changes to the meter.

Pushing updated security settings to the meter

After you have completed configuring the meter security settings, push the updated settings to the meter.

To push the updated security settings to the meter:

- 1. In the ION Setup Security wizard, click **Next** until you reach the Security wizard pane that has a **Finish** button.
- 2. Click Finish. A Confirmation message box opens.
- 3. Click Yes to confirm your changes.

ION Setup pushes your security configuration changes to the meter.

Next, store the Security Configuration File.

Storing Security Configuration Files

After ION Setup pushes the security configuration updates to the meter, it prompts you to store the edited security settings to an encoded Security Configuration File (SCF).

We recommend that you store the SCF file using a new filename when you change the meter security settings. If you do not use a new SCF filename, your changes will overwrite the settings in the SCF file that you opened.

NOTE: If you don't store your security changes to a SCF file, your changes are stored on the meter only; no other record of your security configuration is kept.

ION Setup stores SCF files in the following folder: C:\ProgramData\Schneider
Electric\ION Setup\Security

Store your meter's Security Configuration File (SCF) in a protected location.

WARNING

POTENTIAL COMPROMISE OF SYSTEM AVAILABILITY, INTEGRITY, AND CONFIDENTIALITY

Store Security Configuration Files (SCF) to a secure site.

Failure to follow these instructions can result in death, serious injury, equipment damage, or permanent loss of data.

Cybersecurity policies that govern how sensitive system files are securely stored vary from site to site. Work with the facility IT System Administrator to ensure that such files are properly secured.

Security log file

The first time you store a SCF file, ION Setup creates a security log file (SECURITY.LOG) in the \Security folder.

The security log file contains the history of security configuration files saved from ION Setup.

Use SECURITY. LOG to track meter security configuration changes and to select the correct SCF file for a meter whose security settings you want to edit or use in another meter.

NOTE: The security log file is stored as plain text.

Disabling and enabling protocols and changing port numbers

Disable unnecessary and unused communication protocol ports—such as SFTP, standard ION protocol, and network ports—to reduce the meter attack surface. Change port number default values to reduce the predictability of port use. See <u>"Protocols, ports and connections"</u> for port defaults.

Leave Secure ION enabled for configuration changes and upgrades. If Secure ION is disabled, use the display, Modbus programming, or webpages to access the meter.

Prerequisites:

- Meter connection using ION Setup.
- Login credentials.
- · Security configuration access privileges.

NOTICE

LOSS OF ACCESS

Ensure you maintain sufficient access to communicate with and configure your device.

Failure to follow these instructions can result in loss of access to the device.

To disable and enable protocols and change port numbers:

- 1. In ION Setup, select the meter, and then open **Setup Assistant**.
- 2. Click Communications > Advanced Ethernet > Protocols.
- 3. Select the protocol, and then click Edit.
- Change the default port number.
- 5. Enable or disable the protocol.
- 6. Click OK.
- 7. Click Exit.

Verifying the meter security settings

Generate a Meter Configuration Report to verify the meter security settings and user privileges.

Prerequisites:

- · Meter connection using ION Setup.
- · Login credentials.

To verify meter security settings:

- 1. In ION Setup, select the meter, and then open Setup Assistant.
- Click Reports > Meter Configuration > Display. The Meter Configuration Report for your meter opens.
- 3. Scroll down to the Security section to validate the meter security settings. For example:




- 4. Click Close or Save As to save the report as a .txt file.
- 5. (Optional) Edit the meter security settings.

Viewing the Device Configuration Checklist

View the Device Configuration Checklist to verify that the default password is not being used.

To view the checklist:

- 1. Click Tools > Options.
- 2. Click the Assistant tab and select the Configuration Checklist check box.



Applying security settings to multiple meters

A Security Configuration File (SCF) can be applied to other meters. If differences in capabilities between meters exist, ION Setup will indicate a capability is not available.

Prerequisites:

- · Meter connection using ION Setup.
- Login credentials.
- · Saved Security Configuration File (.scf).

NOTICE

DATA LOSS

Record your device's user and password information in a secure location.

Failure to follow these instructions can result in loss of data.

To apply security settings to multiple meters:

- 1. Open ION Setup > select the meter > **Setup Assistant**.
- 2. **Security > Security Mode > Send**. The Open Security Configuration file dialog box opens.
- 3. Open the meter security configuration file.

TIP: Open the security log file to determine the SCF file you want. See "Opening a meter security configuration file" on page 36 for more information.

4. Click **Yes** to confirm the security update.

The security settings in the SCF file are sent to the meter.

5. Click Exit.

Updating passwords on multiple meters

Use the ION Setup Diagnostics tool to update passwords on multiple meters at the same time.

Prerequisites:

- Meter connection using ION Setup.
- Login credentials.
- Security configuration access privileges.

NOTICE

DATA LOSS

Record your device's user and password information in a secure location.

Failure to follow these instructions can result in loss of data.

To update passwords on multiple meters:

- 1. Open ION Setup > select the System.
- 2. **Tools > Diagnostics**. The Systems diagnostics: System dialog box opens.
- 3. Select the **Tools** tab > **Advanced Security Password Updater**.
- 4. Click Open.
- 5. Select the meters that need a password update.
- 6. Click Set Info.
- 7. Click Start.
- 8. Click Allow passwords to be visible.
- Select each user, click **Password**, and then enter a new password.
 If the meter is connected to a display, update the password for the Front Panel.
- 10. Click Start. A Notice message box opens.

- 11. Click **Proceed**. A result is displayed for each device.
- 12. Click **Save As** to save a copy of updated meter passwords in a .txt file. The Save As dialog box opens.
- 13. Save the file with a unique file name to a protected location. An ION Setup message box opens
- 14. Click **OK**.
- 15. Click Exit.
- 16. Click Close.

Default meter security settings

Review the following default meter security settings to understand how you can securely commission your meter:

Area	Setting Default	
	HTTPS with HTTP redirect	Enabled
	SSH Terminal	Disabled
Communications	SFTP	Enabled
protocols	Modbus TCP	Enabled
	ION	Enabled
	ION over TLS (Secure ION)	Enabled
Time and time keeping	Broadcast time synchronization	Enabled
Webpages	Webpages	Enabled
	Configuration using the display	Enabled
Configuration	Configuration using webpages	Disabled
g an amon	Configuration using Modbus programming	Disabled
Meter access event logging	Valid login event priority	0 (No priority)
See "Editing meter access event logging" on	Invalid login event priority	128 (Medium priority)
page 40 for details.	Lockout event priority	255 (High priority)

Area	Setting	Default
Security mode	Advanced security mode (advanced.scf)	Enabled if Advanced security was used before upgrading meter firmware to v3.0.0. See "Advanced security mode" on page 51 for details.
	Legacy security support (standard.scf)	Enabled if Standard security was used before upgrading meter firmware to v3.0.0.
		We recommend that you use Advanced security mode.
		See: • <u>"Legacy security support"</u> for details on Legacy security support.
		 "Setting up Advanced security" on page 44 for information on switching to Advanced security mode.

For recommendations on how to configure and use your meter in a protected environment, see "Recommended actions" on page 26.

Advanced security mode

Advanced security mode lets you add up to 50 users, has strong user login, and privilege management.

NOTE: We recommend that you use Advanced security mode.

This topic lists the advanced mode security capabilities, as well as detailed information on user access permissions, and the default username and password.

Advanced security mode capabilities

The following table lists the security capabilities of advanced security mode:

Security capability	Description	
	Use a single account to access the meter with a numeric password for login.	
User credentials and password robustness	Use multiple user accounts with alphanumeric passwords for login and configuration changes.	
password robustness	Password range and limit: Any combination of letters and numbers, up to 16 characters.	
	Password strength feedback using ION Setup.	
User account lockouts and timeouts	Define user account lockout criteria after unsuccessful login attempts and define event timeout period.	
User privileges	User accounts with variable permissions to read access, test mode, or configuration privileges.	
Webpages	Disable or enable webpages for viewing meter data online using a web browser (Web Server).	
	Disable or enable ability to configure the meter using:	
	 Modbus communications programming or allow read-only viewing. 	
	The display	
Configuration	 Meter webpages (Web Server programming). 	
	Disable and enable time synchronization.	
	Password required for broadcast time synchronization configuration changes using the display or communication protocols.	
Cybersecurity event logs and reports	Set up cybersecurity event logs and alarms using event priorities.	

User access (Advanced security mode only)

The following table lists the Advanced security mode user access details:

Access type	Permission
Time Sync Access	Set the meter's time and time synchronization parameters.
Read Access	View parameters, except security configuration.
Peak Demand Reset Access	Reset peak demand values.
Comm Config Access	Configure communication settings.
Test Mode Access	Switch the meter to test mode, if available with your meter type.
Full Meter Config Access	Configure meter settings.
Security Config Access	Configure security settings.

User accounts (Advanced security mode only)

The following table lists the Advanced security mode user account details:

Username	Default password	Account description
User1	0 (zero)	Default administrator. This account has full meter access, including configuration.
User2	0 (zero)	Default viewer. This account has view only access.
User3, User4, User50	-	These user accounts are not activated; they do not have default passwords.

Related topics:

"Changing the default password" on page 37.

"Legacy security support" on page 280

"Setting up Advanced security troubleshooting" on page 305

Operate

Review the following recommended actions to operate your device in a protected environment:

- "Monitoring the event log" on page 53
- "Revenue lock LED behavior" on page 294
- "Reporting a security incident or vulnerability" on page 54

Monitoring the event log

Monitor event logs for suspicious activity and to help identify the cause of cybersecurity breaches that could lead to a cybersecurity incident.

NOTE: The default event log limit is 5,000 records. When the limit is reached, new log entries overwrite older ones. To be notified when the Event Log record limit is approaching, see Assigning a designated reader for event log notification. To extend log record retention, offload information to syslog or a protected storage or retention location, see Configuring Syslog network settings using ION Setup.

For more information on meter access logging events, see "Editing meter access event logging" on page 40.

Prerequisites:

- · Meter connection using ION Setup.
- Login credentials.

To monitor the event log:

- 1. In ION Setup, select the meter, and then open **Setup Assistant**.
- 2. Click Reports > Event Log > Display.
- 3. Select the range of records you want to view, the type, and then click **OK**.

- 4. Click Save As to save the log to your local machine or print the event log.
- 5. Click Close.

Reporting a security incident or vulnerability

To report suspicious activity or a cybersecurity incident, go to the <u>Schneider Electric Report an</u> Incident website.

To report a security vulnerability affecting your product or solution, go to the <u>Schneider Electric</u> Report a Vulnerability website.

Maintain

This section contains information on the tasks you should perform periodically to help maintain the security of your meter in a protected environment.

Viewing and downloading an event log

Generate an event log report to assist with cybersecurity incident investigations.

Event logs contain meter configuration changes and energy management system events.

Prerequisites:

- · Meter connection using ION Setup.
- Login credentials.
- · Configured event logs and alarms.

To view and download an event log:

- 1. Open > select the meter > **Setup Assistant**.
- 2. Click **Reports > Event Log > Display**. The Log reports dialog box opens.
- 3. Select a record range for the report and click **OK**:



The Event Log for your meter opens.

NOTE: Only All available records and Last options are available for Event Logs.

- 4. Click Save As.
- 5. Select CSV or TXT > Save.
- 6. Click Close.

Upgrades and security configuration

When meter firmware or ION Setup software is upgraded – Security configuration remains the same until changed, including usernames and passwords. It is recommended security configuration is reviewed after an upgrade to analyze privileges for new or changed device features and revoke or apply them according to your company's policies and standards.

For detailed information on upgrading firmware, see "Firmware upgrades" on page 280.

Decommission

Review the following recommended actions to decommission your device in a protected environment:

- Record activities Document disposal actions according to your company's policies and standards to keep a record of activities.
- "Wiping the device" on page 55
- Decommission-related rules and sanitize records:
 - Follow decommission and sanitization tasks as described by your organization or contact your network administrator.
 - Decommission network and security rules. For example, a firewall rule that could be used to get past the firewall.
 - Perform records tracking sanitization tasks to remove records in related systems. For example, monitoring SNMP servers.
- "Disposal, reuse, recycling" on page 58

Wiping the device

Wipe the device before decommissioning it to help prevent potential disclosure of data.

Prerequisites:

- Meter connection using ION Setup.
- Login credentials.
- Security configuration access privileges.

NOTICE

DATA LOSS

Ensure all important data from the device is saved before performing a reset.

Failure to follow these instructions can result in data loss.

NOTICE

LOSS OF ACCESS

Ensure you maintain sufficient access to communicate with your device.

Failure to follow these instructions can result in loss of access to the device.

NOTE: Complete the following tasks in the order listed; overwrite the communications module registers last to maintain meter connectivity.

To wipe the device:

- Overwrite the meter template file. This overwrites the meter template with the default factory template. See "Overwriting the Meter template file" for detailed steps.
- 2. Delete files in the **documents** folder in SFTP file directory using SFTP client software. See "SFTP" for more information.
- Delete the custom SSL certificate. See "<u>Deleting a custom SSL certificate</u>" for more information.
- 4. Delete webpages. See "Deleting custom webpages" for more information.
- 5. Delete the IEC 61850 configuration file. This deactivates functions related to the IEC 61850 protocol. See "Deleting an IEC 61850 configuration file" for more information.
- 6. Restore default security configuration. See <u>"Restoring default security configuration"</u> for more information.
- 7. Overwrite factory module registers. This deletes values for:
 - Device owner.
 - Device tag.
 - Device location.
 - Device name.

See "Overwriting factory module registers" for more information.

- 8. Perform a Master Reset. This deletes values for:
 - Event log, data, and waveform records.
 - Power quality event (COMTRADE) files.
 - Energy, metering, min./max., revenue and test mode, and peak demand values.
 - Disturbance (sag/swell event) counter, EN 50160 parameters and statistics.
- 9. Overwrite communications module registers. This deletes values for network infrastructure details. See "Overwriting communications module registers" for more information.

Overwriting the meter template file

- 1. Go to www.se.com and search for the meter template for your device.
- 2. Download the ZIP file and extract files.
- 3. Open ION Setup.
- 4. Click the meter to select it > Setup Assistant.
- 5. Click Template > Send to Meter tab.
- 6. Click Send.
- 7. Navigate to the extracted files and select the DCF file.

NOTE: FWN file type is also an option.

- 8. Click Open.
- 9. Click Proceed. The Template Paste Options dialog box opens.
- 10. Clear all check boxes and click OK.
- 11. Click Yes. The overwriting process could take a few minutes.
- 12. Click **OK**.
- 13. Click Exit and then OK.

Restoring default security configuration

NOTICE

DATA LOSS

Record your device's user and password information in a secure location.

Failure to follow these instructions can result in loss of data.

- 1. Open ION Setup > select the meter > **Setup Assistant**.
- Click Security > Security Mode > Edit. The Open Security Configuration file dialog box opens.
- Select the standard.scf and click Open. If prompted, click No to use Legacy security support.
- 4. Click **Next** to navigate to the Define individual users/passwords screen.
- 5. Click Finish. The Confirmation message box opens.

Overwriting factory module registers

- 1. Open ION Setup.
- 2. Ctrl + click on the meter to select it. This switches ION Setup to Advanced mode.
- 3. Double-click **Factory Modules** folder > select meter type.
- 4. Select the **Setup Registers** tab.

- 5. Type text or characters to replace values for these setup registers by selecting them and click **Edit**:
 - FAC1 Device Namespace.
 - FAC1 Device Name.
 - FAC1 Owner.
 - FAC1 Tag1.
 - FAC1 Tag2.
- 6. Click Send.

Overwriting communication module registers

- 1. Open ION Setup.
- 2. Ctrl + click on the meter to select it. This switches ION Setup to Advanced.
- 3. Double-click Comm Modules folder > Ethernet > Setup Registers.
- 4. Type text or characters to replace values for network infrastructure setup registers by selecting them and clicking **Edit**. Some registers include:
 - Stored IPv4 Address.
 - Stored IPv4 Subnet Mask.
 - Stored IPv4 Gateway.

NOTE: IP values can be replaced with text.

- Primary DNS.
- Secondary DNS.
- All servers.
- All port numbers.
- Ethernet Device Name.
- Stored IPv6 Global Gateway.
- Domain Name.
- 5. Click Send.

Disposal, reuse, recycling

Before removing the device from its intended environment, follow the recommended actions in "Decommission" on page 55.

Follow device removal tasks described by your organization or contact your network administrator to determine a responsible method of disposal.

Dispose the device according to the legislation of the country. Some regulatory organizations include:

 The United States <u>Environmental Protection Agency (EPA)</u> for guidance on the sustainable management of electronics.

- The EPA provides an <u>Electronic Product Environmental Assessment Tool (EPEAT)</u> that helps assess the environmental attributes of electronics.
- The European Waste Electrical & Electronic Equipment Directive (WEEE Directive) is the community directive on waste electrical and electronic equipment.
- The European Restriction of Hazardous Substances Directive (RoHS) directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment.

NOTICE

UNAUTHORIZED OR UNINTENDED ACCESS TO CONFIDENTIAL DATA

Store devices that are not in service in an access-controlled or monitored location.

Failure to follow these instructions can result in unauthorized or unintended access to sensitive or secure customer data.

Device disposal

It is recommended that the entire device is physically destroyed. Destroying the device helps prevent potential disclosure of data contained in the device that was not removed.

WARNING

HAZARD OF PHYSICAL INJURY

- · Do not destroy devices without the proper safety training.
- Never burn a device, put a device in a microwave, or pour acid on a device.

Failure to follow these instructions can result in death or serious injury.

Device reuse

Store the device in a location that is access controlled or monitored if there is potential for reuse.

Device recycling

Go to www.se.com and search for the Product Environmental Profile for your meter type to get instructions on managing e-waste.

Installation and commissioning

This chapter supplements the meter installation guide and provides guidance on commissioning your meter.

- See your device installation guide for information related to installation.
- See your product catalog pages at Schneider Electric for information about your device, its options, and accessories.
- Download updated documentation from www.se.com.

For the latest information about your product, or for assistance in advanced features and custom functionality, contact your local Schneider Electric representative.

Installation

Installation, wiring, testing and service must be performed in accordance with all local and national electrical codes.

A DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Apply appropriate Personal Protective Equipment (PPE) and follow safe electrical work practices. See NFPA 70E, CSA Z462 or other local standards.
- Turn off all power supplying this device and the equipment in which it is installed before working on or in the equipment.
- Always use a properly rated voltage sensing device to confirm that all power is off.
- Do not use the data from the meter to confirm power is off.
- Do not exceed the maximum ratings of this device.
- Do not short secondary terminals of Voltage Transformer (VT).
- Do not open secondary terminals of Current Transformer (CT).
- · Ground secondary circuit of CTs.
- Use only Low Power Current Transformers (LPCTs) that are approved for use with this
 device.
- Do not connect CT secondary signals to meter low voltage LPCT terminals.
- Do not install CTs or LPCTs in equipment where they exceed 75% of the wiring space of any cross-sectional area in the equipment.
- Do not install CTs or LPCTs in areas where ventilation openings may be blocked or in areas
 of breaker arc venting.
- Do not install CTs or LPCTs using Class 2 wiring methods or connect to Class 2 equipment.
 See NFPA 70.
- Secure CT or LPCT secondary conductors to ensure they do not contact live circuits.
- Assume communications and I/O wiring are hazardous live until determined otherwise.
- Replace all devices, doors and covers before turning on power to this equipment.

Failure to follow these instructions will result in death or serious injury.

Power system wiring

You can connect the meter's voltage inputs directly to the phase voltage lines of the power system if the power system's line-to-line or line-to-neutral voltages do not exceed the meter's direct connect maximum voltage limits.

The maximum voltage allowed for direct connection may be lower than the manufacturerspecified limits, depending on the local electrical codes and regulations.

If your system voltage is greater than the specified direct connect maximum voltage, you must use voltage (potential) transformers (VTs/PTs) to step down the voltages. Use high-bandwidth voltage transformers in high-speed transient capture applications (ION9000T only).


Residual current measurement

The meter can calculate or measure the residual current, depending on how the inputs are wired.

3 CT wiring


For a 3-phase 3-wire system, the meter calculates residual current for Ground.

For a 3-phase 4-wire system, the meter calculates residual current for Neutral.




For a 3-phase 3-wire system, the meter measures the residual current for Ground at I4.

For a 3-phase 4-wire system, the meter measures the residual current for Neutral at I4.




4 CT wiring

For a 3-phase 4-wire system, the meter calculates residual current for Ground.




For a 3-phase 4-wire system, the meter measures the residual current for Ground at I5.



Functional ground

The meter's functional ground terminal must be wired for optimal performance.

Use the supplied ferrite when terminating the functional ground terminal to earth ground. Make sure the ground wire is looped through, around and back through the ferrite as shown.



LVCS overview

The Low Voltage Current Sensor (LVCS) hardware option is used with external low voltage current transformers to sense current in each phase of a power feed. Use the LVCS option to:

- Measure and monitor individual phases.
- · Help reduce installation costs for new or retrofitted installations.
- Provide non-intrusive load monitoring.

LVCS only works with voltage output Low-Power Current Transformers (LPCTs) and is intended for use with listed Energy-Monitoring current transformers rated for the application. To use LVCS, an ION9000 LVCS meter is required. See "ION9000 meter models and accessories" on page 24 for a list of meters that support LVCS.


LPCT configuration

This section assumes your meter and LPCTs are already installed. For more information related to installation, refer to the ION9000 series – LVCS installation guide at www.se.com.

This section illustrates two common LPCT configuration scenarios and how they are configured using ION Setup. You can also configure LPCTs using the meter webpages or display.

Configuration scenario 1: LPCT connected directly to conductor

The LPCT is connected directly to the line to be measured.



LPCT transformation ratio 10A:1V

Meter transformation ratio (default) 1A:1V

Example:

Set the meter CT ratio to 10:1 to match the transformation ratio of the LPCT and report the conductor primary current.

CT ratio:

= LPCT ratio x Meter ratio = 10:1 x 1:1 = 10:1

Configuring LPCT connected directly to conductors

I1-I3

- 1. Open ION Setup > select the meter > **Setup Assistant**.
- 2. Click Metering Setup > Basic tab.
- 3. Set the LPCT CT primary value:
 - a. Select PM1 CT Prim > Edit. The LVCS Configuration Setup dialog box opens.
 - b. Enter the LPCT primary value.
 - c. Click OK.
- 4. Set the LPCT CT secondary value:
 - a. Select PM1 CT Sec > Edit. The LVCS Configuration Setup dialog box opens.
 - b. Enter the LPCT secondary value.
 - c. Click OK.


The CT Prim and CT Sec values are stored to the device register.

14, 15

Configure these settings in Metering Setup > Advanced tab.

Configuration scenario 2: LPCT connected to secondary side of conventional CT

The LPCT is connected to the secondary side of a conventional transformer.



CT1 (L1) transformation ratio 500A:5A
LPCT transformation ratio 10A:1V
Meter transformation ratio (default) 1A:1V

Example:

The total transformation ratio is the product of all component transformation ratios. Set the meter CT ratio to match the total transformation ratio and measure the primary current at CT1. CT ratio:

= CT1 ratio x LPCT ratio x Meter ratio = 500:5 x 10:1 x 1:1 = 5000:5 (or 1000:1)

Configuring LPCT connected to secondary side of conventional CT

I1-I3

- 1. Open ION Setup > select the meter > **Setup Assistant**.
- 2. Click Metering Setup > Basic tab.
- 3. Set the LPCT and conventional CT primary values:
 - a. Select PM1 CT Prim > Edit. The LVCS Configuration Setup dialog box opens.
 - b. Enter the LPCT primary value.
 - c. Click OK.
 - d. Select the Conventional CT check box.
 - e. Enter the conventional CT primary value. The calculated PM1 CT Prim value is displayed.
 - f. Click OK.
- 4. Set the LPCT and conventional CT secondary values:
 - a. Select **PM1 CT Sec > Edit**. The LVCS Configuration Setup dialog box opens.
 - b. Enter the LPCT secondary value.

- c. Click OK.
- d. Select the Conventional CT check box.
- e. Enter the conventional CT secondary value. The calculated PM1 CT Sec ratio is displayed.
- f. Click OK.

The calculated CT Prim and CT Sec values are stored to the device register.

14, 15

Configure these settings in **Metering Setup > Advanced** tab.


LPCT compensation

Minor phase and magnitude compensation can be made using the Instrument Transformer Correction (ITC) module. For more information on the ITC module, see *ION Reference*, available on www.se.com.


Removing the display from back-to-back mounting adapter

Instructions on how to remove the display, for example, if you want to connect it to another meter.


NOTE: Refer to the display installation sheet QGH42230 for installation instructions.




 Holding the display, turn the tightening wheel with a flat-head screwdriver until it disengages from the display.



2. Carefully pull the display away, far enough to access the cable connector on the display.




3. Disconnect the display cable.




Removing the meter from back-to-back mounting adapter

You can uninstall the meter from the optional back-to-back mounting adapter.


NOTE: Refer to the meter installation guide for installation instructions.



1. Use a flat-head screwdriver to unlock the meter retainer clips.



2. Holding the meter firmly, swing it outwards and pull slightly upwards to detach it from the top retaining hooks.




Option modules

Option modules are ordered separately from your meter and can be connected to your meter without specialized equipment.

Option modules are identified based on how they are physically connected to the meter's external I/O bus.

The first connected module, attached directly to the meter, is Module A. The second module, attached to Module A, is Module B. The meter supports up to four external modules:



Option modules are monitored and controlled by the meter's ION modules. External I/O modules are mapped to the corresponding ION modules:

Option module physical position	ION module mapping
Module A to Module D	Port A to Port D

Option module terminal connector label	ION module mapping
Analog inputs A1 to A(n)	Analog Input module A1 to A(n)
Analog outputs Q1 to Q(n)	Analog Output module Q1 to Q(n)
Digital inputs S1 to S(n)	Digital Input module S1 to S(n)
Digital/relay outputs R1 to R(n)	Digital Output module R1 to R(n)

Maximum number of option modules

Up to four option modules are supported per device.

Limitations:

- Only one 4-wire RS-485 module and one Fiber Ethernet module may be installed.
- Depending on the type and quantity of option modules attached to your meter, you may need
 to reduce your meter's maximum operating temperature or limit the number of option
 modules. See "Maximum operating temperature with option modules" on page 312 for more
 information.

Commissioning

Factory default settings

Use these default values the first time you connect to your meter.

Parameter	Default value
Username to log onto meter webpages	USER1
Password to log onto meter webpages or access display	0
IP address ¹	169.254.0.10
Subnet mask	255.255.0.0
Gateway	0.0.0.0
RS-485	COM1 Unit ID: 100
NO-400	COM4 Unit ID: 103
Language	English

¹ The IPv6 link local address can also be used. See Self-discovery over Ethernet for details.

Commissioning using ION Setup

Use ION Setup to commission the meter for integration into your energy management system.

Connect to your meter using ION Setup then use the Setup Assistant to configure the meter. Setup parameters are arranged in logical groupings and category folders.

Before exiting the Setup Assistant, ION Setup performs a meter configuration test and displays the results. You can review the results and make changes as needed.

To turn off the meter configuration test:

- 1. Click Tools > Options.
- 2. Click the Assistant tab and clear the **Configuration Checklist** check box.

NOTE: ION Setup also performs a configuration test and displays results when configuring certain features such as the Sag/Swell or Transient Logging wizard in the Power Quality setup assistant.

Configuring metering parameters

Use ION Setup to configure the meter's metering functionality.

- 1. Start ION Setup and open the Setup Assistant for your meter.
- 2. Configure the parameters in **Metering Setup > Basic**.

Basic tab

Parameter	Values	Description
Volts Mode	4W-WYE, DELTA, 3W- WYE, SINGLE, DEMO ¹	Power system type
PT Prim	1–999,999	Potential transformer's primary winding voltage rating
PT Sec	1–999,999	Potential transformer's secondary winding voltage rating
CT Primary	1–999,999	Current transformer's primary winding current rating
CT Secondary	1–999,999	Current transformer's secondary winding current rating
Nominal Voltage	1–999,999	Nominal voltage (V) used for metering functions such as harmonic calculations and sag/swell detection
Nominal Current	1–999,999	Nominal current (A) used for metering functions such as harmonic calculations and sag/swell detection
Nominal Frequency	50, 60	Nominal frequency (Hz) used for metering functions such as alarms

3. Configure the parameters in **Metering Setup > Advanced**, if appropriate.

Advanced tab

Parameter	Values	Description
PhaseOrder	ABC, ACB	Power system's rotation order of voltage phases
V4 PT Prim	1–999,999	V4 potential transformer's primary winding voltage rating
V4 PT Sec	1–999,999	V4 potential transformer's secondary winding voltage rating
I4 Prim	1–999,999	I4 current transformer's primary winding current rating

Parameter	Values	Description
I4 Sec	1–999,999	I4 current transformer's secondary winding current rating
I5 Prim	1–999,999	I5 current transformer's primary winding current rating
I5 Sec	1–999,999	I5 current transformer's secondary winding current rating
Scale Rev Param	ON, OFF	Specifies whether revenue readings are presented as primary or secondary side values (ON = primary side, OFF = secondary side)

¹ Demo mode is for demonstration only, and does not use the meter input terminals to display values.

Using the Phasor Viewer

Phasor diagrams can help verify or troubleshoot issues with voltage and current input wiring.

Use ION Setup's Phasor Viewer to display a real-time phasor diagram of the voltage and current input signals.

To use the Phasor Viewer:

- 1. Start ION Setup and open the **Setup Assistant** for your meter.
- 2. Click Metering Setup > Phasor.
- 3. Select **Phasor Viewer** and click **Show**.
- 4. To change the polarity of the voltage or current inputs, click **Show Setup** to display the Polarity Settings.

Select the box beside the input you want to invert polarity, then click **Apply to Meter**.

Basic setup using the webpages or display

You can use the meter webpages or display to configure basic metering parameters.

- Using the webpages: Navigate to Setup > Metering.
- Using the display: Navigate to **Setup Menu > Meter Setup**.

Communications

Communications overview

Communications is the transfer of data to and from the meter and is controlled by a combination of hardware and software components in the meter.

For each connected communications port, the meter uses the applicable communications protocol to establish communications with other devices or software. The protocol manages the communications session and defines the set of rules, commands, and packet structure of the transmitted data. You can also control which protocols are enabled or disabled on the meter.

NOTE: To maximize the performance of your power management system, it is recommended that devices be connected directly to an Ethernet network.

Other means of controlling communications, such as who can access certain types of meter data, are discussed in the security topics for the meter.

Your meter's default protocol settings meet the needs of most systems with only basic configuration. You can customize these settings to meet your specific needs. These are advanced procedures that require an understanding of your meter's architecture, supported protocols, and the communications network and power system that your meter is connected to.

Ethernet communications

Your Ethernet connection source should be installed in a location that helps minimize the overall Ethernet cable routing length and complexity of your network.

The meter supports a single IP address for both physical Ethernet connections.

Your device's second Ethernet port acts as an Ethernet switch to help simplify network connections and reduce installation time and costs, by having shorter Ethernet cable runs between devices without needing additional Ethernet routers or repeaters. You cannot connect your meter to two different Ethernet networks. The two Ethernet ports do not split the signal, so connecting both ports should not impact your communications speed.

The meter uses dual-stack IPv4/IPv6 routing technology to manage network communications and allow network hosts to communicate with the meter using either IPv4 or IPv6.


Ethernet communications connections

Your meter's dual port Ethernet connections enable you to use straight-line or network loop (ring) topology.

If local network loop Ethernet topology is required, you must enable RSTP for your meter's Ethernet communications to function.

Use CAT5 (or higher) Ethernet cables with unshielded RJ45 modular connectors to wire your meter's Ethernet communications.

Ethernet loop topology



- A Ethernet switch or hub
- B Ethernet connected meters
- C LAN/WAN

Protocols, ports, and connections

The Ethernet protocols supported by your device allow simultaneous connections through the IP service ports.

By enabling or disabling TCP/IP protocols, you can control whether your meter accepts new socket connection requests. Changing settings for one port does not impact the other existing connections. Depending on the protocol, you can also change the port number.

NOTE: Some protocol port numbers are read-only and not configurable.

Protocol, ports, and connections

Protocol	Port (default)	Number of connections
ION (ION over TCP)	7700	8 1
Secure ION (ION over TLS)	7443	8 ¹
Modbus TCP ²	502	8 ¹
Modbus RTU over Ethernet ²	7701	8 ¹
DNP	20000	8 ¹
DLMS	4059	8 ¹
Modbus TCP (dedicated) 2	502	32
EtherGate (Com1)	7801	1
EtherGate (Com4)	7802	1
DHCP	67 (68)	1
SFTP	22	2
Webserver (HTTPS) ³	443	10
SNMP	161	N/A
SMTP server (email) outgoing only	25	1
NTP	123	1
IEC 61850	102	5

¹ – These eight simultaneous connections are shared by ION, Secure ION, Modbus TCP, Modbus RTU over Ethernet, DLMS and DNP. You can have a maximum of three DNP connections. You can have a maximum of one DLMS connection.


Self-discovery over Ethernet

Your meter supports Devices Profile for Web Services (DPWS) which allows for self-discovery of the meter when it is connected to your local area network.

² – These protocols must be enabled for Modbus gateway functionality.

³ – These are used for the meter's webpages.

When you connect your meter to your network, your meter automatically appears in your network in Windows Explorer under Other Devices. By default, the meter is named <meter type>-<last six digits of MAC address>. For example, a meter with a MAC address of 006078173393 appears on the network as <meter type>-173393.



- A Computer connected to the network with IPv6 enabled
- B LAN / WAN (Local Area Network / Wide Area Network), common subnet, no routers
- C Meters with self-discovery over Ethernet connected to the network

Considerations for using self-discovery over Ethernet

- For self-discovery, the meter must be connected directly to the network using only a cable or switches, and not going through a router.
- You must use a computer running Windows 7 or later with IPv6 enabled to use self-discovery over Ethernet.
- The computer and the meter must be on the same subnet.
- You do not need to configure your meter's IP address for self-discovery over Ethernet. An IPv6 address is automatically generated from your meter's MAC address and self-discovery takes place over IPv6.

Accessing the meter through self-discovery

Use Windows Explorer to locate and access the meter on your Local Area Network (LAN).

NOTE: Some networks restrict device self-discovery over a wireless connection. If this is the case, make sure your computer is connected to the network using an Ethernet cable.

To access the meter through self-discovery:

- 1. Connect the meter's Ethernet port to the LAN.
- 2. Start Windows Explorer.
- Click Network.

The connected network devices display.

- 4. Locate your meter with the name < Device Name >-< Last 6 digits of MAC address >.
- 5. Double-click the icon to open the meter webpages.

Ethernet configuration

To use Ethernet communications, you must configure your device's IP settings.

You need to enter network information for any Ethernet servers used by the device (for example, a DNS or email server). Contact your network system administrator for your IP address and other Ethernet network configuration values.

NOTE: For meters that do not have a display, you must connect your meter directly to your computer to set a unique IP address for each device or configure the meter to use a DHCP server to acquire IP addresses.

It is recommended that you test your communications with the meter after changing any communications-related settings (for example, communicating with the meter using the fully-qualified domain name if using DNS or with assigned addresses after these are provided by the DHCP server). In addition, make sure that any software or other devices communicating with the meter are using the new settings.

Initial Ethernet configuration versus changing existing Ethernet settings

There are two scenarios when configuring your meter's Ethernet communications settings: initial configuration and changing the existing addresses when the meter is in use.

- Initial configuration: Configure your device's Ethernet settings manually using the display or by connecting your meter directly to your computer and using a web browser to access the device's webpages. Alternately, you can connect your meter to the network and configure it to use a DHCP server to acquire an IP address.
 - **NOTE**: It is recommended during initial configuration that you use a connection method other than the one you are trying to configure. For example, if you are configuring DHCP IPv4 settings, connect to the meter using the IPv6 Link Local address or a serial connection. This allows you to configure the meter without being disconnected.
- Changing existing IP settings: After the meter's Ethernet port is configured and connected to the LAN, you can use ION Setup to configure meter settings, in addition to using the display or meter webpages.

In either case, modify your meter's Ethernet settings to those provided by your network system administrator before connecting the device to your local area network (LAN).

IP address format and ranges

When you set your meter's IPv4 or IPv6 addresses, make sure you use the correct format and valid ranges.

Protocol	Format
IPv4	0.0.0.0 to 255.255.255.255
	:: to FFFF:FFFF:FFFF:FFFF:FFFF
IPv6	The double colon indicates that gaps are filled with zeroes to make the IPv6 address the correct length (32 hexadecimal numbers)

All meters ship from the factory with the IPv6 global address and IPv6 gateway undefined (set to "::"). To communicate with the meter using IPv6 outside the local network, you must configure these settings manually or use DHCP to assign the addresses to the meter. Within the local network, you can use the meter's IPv6 Link Local address.

IP addresses and network port numbers

To specify a port for an outgoing IP address, append a colon then the port number to the end of the IP address. For IPv6 addresses, enclosed the address in square brackets then add the port number. For example, to specify the default port for SFTP (port 22):

IPv4: 169.254.0.10:22

IPv6: [FE80::260:78FF:FE04:5943]:22

Configurable Ethernet settings

NOTE: Some additional Ethernet settings are available in the Advanced Ethernet menu in ION Setup and on the meter webpages.

"W" indicates the setting can be configured (written) while "R" indicates it is read-only.

Ethernet configuration settings

Setting	Display	ION Setup	Webpages
IPv4 address	W	W	W
IPv4 Subnet mask	W	W	W
IPv4 Default gateway	W	W	W
IPv4 Assignment Mode (DHCP/Stored)	W	W	W
IPv6 Assignment Mode (DHCP/Stored)	W	W	W
Ethernet Device name	R	W	W
Domain name	R	W	W

Setting	Display	ION Setup	Webpages
IPv6 enabled	W	W	W
IPv6 Link Local Address	R	R	R
IPv6 global address	R	W	W
IPv6 gateway	R	W	W
Ethernet Rx timeout	_	W	W
Modbus TCP timeout	_	W	W
Modbus gateway	_	W	_
MAC address	R	R	R
Ethernet primary DNS	R	W	W
Ethernet secondary DNS	R	W	W

Configuring IPv4 / IPv6 communications settings using ION Setup

You can configure your device's IPv4 and IPv6 address settings, such as stored addresses or address assignment mode, using ION Setup.

When configuring communications parameters, ensure you maintain at least one communication path that allows full access to your device; otherwise, you may permanently lose the ability to change your device's configuration and access additional data.

NOTICE

LOSS OF ACCESS

Ensure you maintain sufficient access to communicate with and configure your device.

Failure to follow these instructions can result in loss of access to the device.

Contact your network system administrator for your IP addresses and other Ethernet network configuration values.

To configure IPv4 / IPv6 communications settings using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your device.
- 3. Click Communications > Basic Ethernet > IPv4 (or IPv6).
- 4. Select the IP address then click Edit.

5. Select your IP address assignment mode.

IPv4

Selection	Mode	Description
Use DHCP to obtain an IPv4 address	DHCP	The meter acquires its IP addresses from your network's DHCP server. The Device Name and Domain Name fields are used to define the meter's fully-qualified domain name (FQDN).
Use the following IPv4 address	Stored	The meter uses the IP addresses that you manually enter for IPv4 (address, subnet mask and gateway).

For IPv6, select the **IPv6 Enabled** check box to enable IPv6 communications or clear it to disable IPv6 communications.

NOTE: The IPv6 Link Local address is factory set and is read-only.

IPv6

Selection	Mode	Description
Use DHCP to obtain an IPv6 address	DHCPv6	The meter acquires its IP addresses from your network's DHCPv6 server. The Device Name and Domain Name fields are used to define the meter's fully-qualified domain name (FQDN).
Use the following IPv6 address	Stored	The meter uses the IP addresses that you manually enter for IPv6 (global address and default gateway).

You can have different assignment modes for IPv4 and for IPv6.

6. Configure the settings for the selected mode then click **OK**.

The changes are saved to the meter. If ION Setup detects that the connection information is already in use, you are prompted to confirm the change.

7. Click **Yes** to confirm the change or **No** to cancel.

An example of an instance where you might want to confirm the change is if you are programming the meter to replace another meter already in service.

DHCP settings available using ION Setup

Parameter	Value	Description
Device name	Contact your local network administrator for parameter values.	The Ethernet device name is used by DPWS for self-discovery over Ethernet and as the hostname to uniquely identify your meter for DHCP and DNS. By default, this is set to the meter model plus the last six-digits of the MAC address.
Domain name	Contact your local network administrator for parameter values.	The Ethernet domain name for the network that the meter resides on.

Stored IPv4 settings available using ION Setup

Parameter	Value	Description
IP address	Contact your local network administrator for parameter values.	The IP address of your device.
Subnet Mask	Contact your local network administrator for parameter values.	The subnet IP address of your network.
Gateway	Contact your local network administrator for parameter values.	The gateway IP address of your network.

Stored IPv6 address settings available using ION Setup

Parameter	Value	Description
Global Address	Contact your local network administrator for parameter values.	The Internet protocol address of your device.
Contact your local network	The address the meter uses to route communications to a different network or subnet.	
Default Gateway	administrator for parameter values.	If you do not set this or the address is incorrect, you may see slow communications or communications errors.

ION Setup reconnection

If you change the settings for the Ethernet connection method you are currently using to connect to the meter, ION Setup tries to reconnect to the meter using the updated information. You can view the process in the **Device reconnection** dialog box that appears.

- If ION Setup can successfully communicate using the new setting, this setting appears in the IP Address drop-down list box and the check box is selected. Click OK to copy this information into the IP address field in Device Properties. ION Setup will now use this address to communicate with the device.
- If ION Setup cannot successfully communicate using the new setting, the new address appears in the IP Address but the check box is not selected. Either select the check box and click OK (for example, you may want to use the new setting if you are replacing a meter in service) OR select another address option from the drop-down list box. Click Test to check that ION Setup can communicate with the meter using the new address, select the check box, then click OK.

Configuring basic Ethernet settings using ION Setup

To configure your device's basic Ethernet settings using ION Setup:

- 1. Start ION Setup.
- 2. Open the Setup Assistant for your device.
- 3. Click Communications > Basic Ethernet > TCP/IP.
- 4. Select a setting and then click Edit.

NOTE: Contact your network system administrator for the appropriate values.

General Ethernet settings available using ION Setup

Parameter	Value	Description
Ethernet device name		This name is associated with your meter when using DPWS.
Ethernet device name	configurable	By default, it is the meter type and the last 6 characters of its MAC address.
Rx timeout	configurable	Specifies the number of seconds the meter waits for communication acknowledgments.
Modbus TCP Timeout	configurable	Specify number of seconds the meter waits before disconnecting an idle Modbus TCP connection.
Modbus Gateway ¹	Disabled COM1 (CM1 Protocol) COM4 (CM4 Protocol)	Specify the port on which Modbus Gateway sends/receives Modbus TCP requests. For Modbus Gateway to function properly, the serial port protocol must be set to Modbus Master. For example, change CM1 Protocol from factory to Modbus Master.
MAC address	Read-only	The media access control (MAC) address is factory set and is for reference only.

¹ Modbus Gateway is supported only on one serial port at any given time

Configuring basic Ethernet settings using the meter webpages

You can use the meter webpages to configure the IPv4, IPv6 and TCP/IP settings for the meter.

When configuring communications parameters, ensure you maintain at least one communication path that allows full access to your device; otherwise, you may permanently lose the ability to change your device's configuration and access to additional data.

NOTICE

LOSS OF ACCESS

Ensure you maintain sufficient access to communicate with and configure your device.

Failure to follow these instructions can result in loss of access to the device.

Contact your network system administrator for your IP addresses and other Ethernet network configuration values.

To configure basic Ethernet setting using the meter webpages:

- 1. Connect to your meter's webpages.
 - Until you configure other Ethernet connection settings, you can connect to the meter using its default IPv4 address or its IPv6 link local address, or by using self-discovery over Ethernet by double-clicking the meter's network icon.
- 2. Navigate to **Setup > Ethernet**.
- 3. Enter the appropriate value for the settings.
- 4. Click **Advanced Settings** to configure additional Advanced Ethernet settings, such as timeouts and enabling/disabling certain protocols over Ethernet, if needed.
- 5. Click Apply.

NOTE: If you are changing the address you used to access the webpages, you will need to reconnect to the webpages after you click **Apply**.

Ethernet settings available using the webpages

Parameter	Value	Description
MAC address	Read-only	The media access control (MAC) address is factory set and is for reference only.
Ethernet device name co	configurable	The Ethernet device name is used by DPWS for self-discovery over Ethernet and as the hostname to uniquely identify your meter for DHCP and DNS.
		By default, this is set to the meter model plus the last six-digits of the MAC address.

Parameter	Value	Description
Domain name	Contact your local network administrator for parameter values.	The Ethernet domain name for the network that the meter resides on.
Primary DNS	Contact your local network administrator for parameter values.	The IP address of your network's primary DNS server, if your network uses DNS.
Secondary DNS	Contact your local network administrator for parameter values.	The IP address of your network's secondary DNS server, if your network uses DNS.

IPv4 settings available using the webpages

Parameter	Value	Description
IPv4 Assignment mode	Stored DHCP	Stored: The meter uses the IP addresses that you manually enter for IPv4 (address, subnet mask and gateway).
		DHCP: The meter acquires its IP addresses from your network's DHCP server.
Stored IPv4 address	Contact your local network administrator for parameter values.	The Internet protocol address of your device.
Stored IPv4 Subnet Mask	Contact your local network administrator for parameter values.	The Ethernet IP subnetwork address of your network.
Stored IPv4 Gateway	Contact your local network administrator for parameter values.	The Ethernet IP gateway address of your network.

The webpage also displays the acquired IPv4 settings if the Assignment mode is set to DHCP.

NOTE: To disable communications using IPv4, set the Assignment mode to Stored and the IPv4 Address to 0.0.0.0.

IPv6 settings available using the webpages

Parameter	Value	Description
IPv6 Assignment Mode	Stored DHCPv6	Stored: The meter uses the IP addresses that you manually enter for IPv6 (Global address, gateway address).
		DHCPv6: The meter acquires its IP addresses from your network's DHCP server.
IPv6 Link Local Address	Read-only	TheIPv6 Link Local address is factory set and is read-only.
Stored IPv6 Global Address	Contact your local network administrator for parameter values.	The Internet protocol address of your device.
Stored IPv6 Gateway	Contact your local network administrator for parameter values.	The address the meter uses to route communications to a different network or subnet. If you do not set this parameter or the address is incorrect, it may result in slow communications or communications errors.

The webpage also displays the acquired IPv6 settings if the Assignment mode is set to DHCP.

NOTE: To disable communications over IPv6, set Enable IPv6 in Advanced Settings to No.

NOTE: You must enclose an IPv6 address in square brackets when typing it in a web browser, for example: "http://[fe80::260:78ff:fe04:5943]".

Configuring Ethernet communications settings using the display

You can configure basic Ethernet communications settings using the display.

You can use the display to select the IP address assignment mode for IPv4 and IPv6, configure stored IPv4 addresses, and view other settings. To configure the Ethernet settings that are not available on the display or are read-only, use the meter's webpages or ION Setup.

Prerequisites:

 Obtain your meter's IP address and other network information from your network administrator or IT department. To configure Ethernet communications settings using the display:

- 1. Press Setup Menu > Communications Setup.
- 2. Scroll through the screens until you reach the setting you want to configure then press the **Edit** button.
- 3. Select the IPv4 or IPv6 **Assignment Mode**, if required.

Option	Description
Stored	The meter uses the IP addresses that you manually enter for IPv4 (address, subnet mask and gateway) and IPv6 (Global address, gateway address).
DHCP/DHCPv6	The meter acquires its IP addresses from your network's DHCP server.

You can have different assignment modes for IPv4 and for IPv6.

If you set the **IPv4 Assignment Mode** to Stored, continue with the remaining steps to configure stored IPv4 addresses. If you are using addresses acquired from a DHCP server, press the down arrow to view the assigned addresses.

- 4. Go to the Stored IPv4 Address Setup screen and press Edit.
- 5. Configure your meter's stored IPv4 Addresses, as required.

Stored IPv4 address settings available using the display

Parameter	Values	Description
	Contact your local	Sets the IP address for the meter
IP Address	network administrator for parameter values.	Your meter's default IP address is 169.254.0.10
	Contact your local	Used if subnetting applies to your network
Subnet Mask network administrator for parameter values.	Your meter's default subnet address is 255.255.0.0	
	Contact your local	Used in networks with multiple segments
Gateway	network administrator for parameter values.	Your meter's default gateway address is 0.0.0.0
MAC Address	Read-only	Your meter's media access control (MAC) address

DHCP

The meter can function as a DHCP (Dynamic Host Configuration Protocol) client, allowing a DHCP server to assign IP addresses to the meter.

The meter supports assignment of the following addresses by a DHCP server when the Assignment Mode is set to DHCP:

- IPv4 IP Address
- IPv4 Subnet mask
- IPv4 Gateway
- IPv6 Global Address
- IPv6 Gateway

Considerations for using DHCP

- It is recommended that you also set up a DNS server and configure software and other
 devices to use the meter's name to communicate with it. Alternatively, you can configure the
 DHCP server to always provide the same address to the meter.
- When you switch the assignment mode from DHCP to Stored, the meter reverts to using its
 default IP addresses as the Stored addresses.
- When you switch the assignment mode from Stored to DHCP, the acquired addresses display
 as None until the meter receives addresses from the DHCP server.
- When using IPv6, the meter's fully-qualified domain name (FQDN) is not sent to the DHCP server. It is important that you make sure what is configured on the meter matches what is configured on your network.
- If the meter is not able to communicate to the DHCP server:
 - When using IPv4, the meter will try to connect to the DHCP server for approximately one
 minute. If the meter cannot connect to the DHCP server, it will revert to the default IP
 address, but the Assignment Mode will remain DHCP.
 - When using IPv6, the meter will continue to try to connect to the DHCP server, even if it does not receive an address.

NOTE: If the DHCP server has not assigned an IP address and you need to reconnect to the meter, use the meter's IPv6 link local address.

For IPv4, if the meter's fully-qualified domain name (FQDN) is not found on the DHCP server, an event is logged in the event log. For IPv6, if the meter's fully-qualified domain name (FQDN) is not found on the DHCP server, no event is logged; this is important to keep in mind when troubleshooting communications issues in a system using DHCP.

Meter domain name

A DNS (domain name system) server maps domain names to IP addresses. If you configure the meter to use a DNS server, the meter can communicate with other network resources using their domain names, rather than their IP addresses, and vice versa. For example, if your network has an SMTP server with the domain name of smtp.company.com, you can enter smtp.company.com as the SMTP Server address in the meter's communications settings.

The meter's Fully-Qualified Domain Name (FQDN)

To allow other network resources to communicate to the meter using its domain name, you must configure the meter's Ethernet Device Name setting to match that used by the DNS server. The meter's fully-qualified domain name is its Ethernet name plus its Domain name. For example, if the meter's Ethernet name is ElectricityHQ and its Domain name is companyXYZ.com, the FQDN will be ElectricityHQ.companyXYZ.com.

NOTE: This domain name is used for both IPv4 and IPv6 communications. It is used to identify the meter in a system using DNS and to identify the meter when using DPWS for self-discovery over Ethernet.

Network protocol control

The network protocol control feature allows you to enable, disable or change the port number of the network protocols supported on your meter.

Disabling unused ports is considered a cybersecurity best practice to help minimize unauthorized access to your meter.

NOTE: The protocol port number may not be configurable on all protocols.

Managing network protocol control using ION Setup

Use ION Setup to enable, disable or change the port number of the network protocols supported on your meter.

When configuring communications parameters, ensure you maintain at least one communication path that allows full access to your device; otherwise, you may permanently lose the ability to change your device's configuration and access to additional data.

NOTICE

LOSS OF ACCESS

Ensure you maintain sufficient access to communicate with and configure your device.

Failure to follow these instructions can result in loss of access to the device.

To manage network protocol control using ION Setup:

- 1. Open the **Setup Assistant** for your meter.
- 2. Click Communications > Advanced Ethernet > Protocols.
- 3. Select a protocol from the list and click Edit.
- 4. Select the **Enabled** check box to enable the port. Clear the check box to disable the port.

NOTE: The IEC61850 port is enabled when a valid CID file is uploaded to the meter. The port is disabled by removing the CID file.

NOTE: For EtherGate functionality, the EtherGate protocol must be enabled and the applicable serial port set to **EtherGate**. For Secure EtherGate functionality, select Secure EtherGate instead of EtherGate.

- 5. Select a port number from the **Port Number** drop-down list box or by clicking in the **Port Number** field and entering a port number.
- 6. Click OK.

If multiple ports are set to the same number, ION Setup responds with a message indicating that the port is already in use by another protocol.

Managing network protocol control using the meter webpages

Use the meter webpages to enable, disable or change the port number of the network protocols supported on your meter.

The Setup tab contains configurable elements for enabling, disabling, and changing the port numbers for your network protocols.

When configuring communications parameters, ensure you maintain at least one communication path that allows full access to your device; otherwise, you may permanently lose the ability to change your device's configuration and access to additional data.

NOTICE

LOSS OF ACCESS

Ensure you maintain sufficient access to communicate with and configure your device.

Failure to follow these instructions can result in loss of access to the device.

To manage network protocol control using the meter webpages:

- Open a web browser and enter your meter's IP address in the address bar.
 The webpage login is displayed.
- 2. Enter your login credentials.
- 3. Navigate to **Setup > Ethernet**.
- 4. Click **Advanced Settings** at the bottom of the screen.
- 5. Select YES or NO to enable or disable each configurable protocol.
- 6. Enter the port number for each configurable protocol.
- 7. Click **Apply** to send these settings to your meter.

Managing network protocols using the display

The Ethernet Port Enable Setup allows you to enable or disable your network protocols through the display.

When configuring communications parameters, ensure you maintain at least one communication path that allows full access to your device; otherwise, you may permanently lose the ability to change your device's configuration and access to additional data.

NOTICE

LOSS OF ACCESS

Ensure you maintain sufficient access to communicate with and configure your device.

Failure to follow these instructions can result in loss of access to the device.

NOTE: You cannot change the Ethernet port number assignments through the display.

To manage network protocol control using the display:

- 1. Press the **Home** button on the display.
- 2. Navigate to **Setup Menu > Ethernet Port Enable Setup**.
- 3. Press Edit. Enter your meter's password, if prompted.
- 4. Press the up or down icons to navigate available Ethernet protocols. A gray bar appears behind the active selection.
- 5. Press Enable/Disable.
- 6. Press Select to accept the change.
- 7. Press **Select** to confirm.

Serial communications

The meter supports serial communications through its onboard RS-485 ports. Your meter supports the 4-wire RS-485 option module through use of the existing Com1 port.

RS-485

In an RS-485 network, there is one client device, typically an Ethernet to RS-485 gateway. It provides the means for RS-485 communications with multiple server devices, such as meters. For applications that require only one dedicated computer to communicate with the server devices, a USB to RS-485 converter can be used to connect to the server device.

Up to 32 devices can be connected on a single RS-485 bus.

RS-485 wiring

Connect the devices on the RS-485 bus in a point-to-point configuration, with the (+) and (-) terminals from one device connected to the corresponding (+) and (-) terminals on the next device.

NOTE: If using the 4-wire RS-485 option module follow the wiring instructions in your installation guide. Your wiring may depend on serial or gateway configuration.

RS-485 cable

Use a shielded 2 twisted pair or 1.5 twisted pair RS-485 cable to wire the devices. Use one twisted pair to connect the (+) and (-) terminals and use the other insulated wire to connect the C terminals.

The total distance for devices connected on an RS-485 bus should not exceed 1200 m (4000 ft).

RS-485 terminals

- C Common. This provides the voltage reference (zero volts) for the data plus and data minus signals
- Shield. Connect the bare wire to this terminal to help suppress signal noise that may be present. Ground the shield wiring at one end only (either at the client or the last server device, but not both).
- Data minus. This transmits/receives the inverting data signals.
- + Data plus. This transmits/receives the non-inverting data signals.

NOTE: If some devices in your RS-485 network do not have the C terminal, use the bare wire in the RS-485 cable to connect the C terminal from the meter to the shield terminal on the devices that do not have the C terminal.

RS-485 configuration

Before connecting your device to the RS-485 bus, use ION Setup, meter webpages or the display to configure your meter's default RS-485 settings.

Your meter has two RS-485 connections.

Each RS-485 connection must have a unique unit identifier (Unit ID) and have the following settings match the rest of the devices on the RS-485 bus:

- Protocol
- Baud rate
- · Parity and stop bits

You can configure the following settings to help optimize communications performance:

- RTS delay
- RS-485 bias

You can use a communications converter (USB to RS-485 or RS-232 to RS-485) or an Ethernet gateway device to connect to your meter.

RS-485 bias

You can use the RS-485 bias setting to fine-tune communications.

Set the RS-485 bias to ON when the meter is acting as a client over RS-485 communications and set the RS-485 bias to OFF when the meter is acting as a server. You can configure RS-485 biasing through ION Setup, the meter webpages or the display.

Serial protocols and ports

Your meter supports serial communications protocols on the RS-485 ports.

- ION
- Modbus RTU
- Modbus Master
- DNP 3.0
- DLMS
- EtherGate ¹

- Secure EtherGate ¹
- GPS: Truetime/Datum²
- GPS: Arbiter²
- GPS: Arbiter-Vorne²
- None³
- 1 These are serial port protocol settings that allow protocols to work with other connected RS-485 devices.
- 2 These protocol settings are used for connecting to a GPS receiver communicating in serial ASCII format.
- 3 This protocol setting stops communications using this port.

Configuring serial communications settings using ION Setup

Use ION Setup to configure the meter's serial communications settings.

Prerequisites:

Make sure you have a unique unit ID for your meter and know the serial network settings (protocol, baud rate, parity and stop bits).

To configure the meter's serial communications settings using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your device.
- 3. Click Communications > Serial Settings.
- 4. Select Com1 or Com4 tab, depending on which hardware serial port you are configuring.
- 5. Select a setting, and then click **Edit** to configure the setting to match your communications system.

Serial communications settings available using ION Setup

Parameter	Values	Description
Protocol	ION, Modbus RTU, Modbus Master, DNP v3.00, DLMS, EtherGate, GPS: Truetime/Datum, GPS: Arbiter, GPS: Arbiter-Vorne, Factory, None	Sets the communications protocol for your meter's RS-485 port The NONE setting stops communications using this port.
Baud Rate	2400, 4800, 9600, 19200, 38400, 57600, 115200	Sets the data rate, in bits per second
Rx Timeout ¹	0.1–15	Sets the transmit delay (timeout for receiving an entire message from a device) in seconds.
Unit ID	1–9999	Sets the meter's unique ID on the RS-485 network Note: Modbus serial device range 1 to 247
Serial Port	8N1, 8N2, 8E1, 8E2, 8O1, 8O2	Sets the parity and stop bits for the port
RS485 Bias	OFF, ON	Turns on biasing on the client device over the RS-485 port

¹ Only applies to a subset of protocols.

Configuring serial communications settings using the webpages

You can use the meter's webpages to configure your serial communications settings.

Before configuring serial parameters, make sure you have a unique unit ID for your meter and know the serial network settings (protocol, baud rate, parity and stop bits).

To configure the meter's serial communications settings using the meter webpages:

- 1. Connect to your meter's webpages using the meter's IPv4 address or its IPv6 link local address, or use self-discovery then double-clicking the meter's network icon.
- 2. Navigate to Setup > Serial Port.
- 3. Enter the appropriate value for the settings.
- 4. Click **Advanced Settings** to configure additional settings, if needed (for example, RS485 biasing or Rx Timeout).

Basic serial communications settings available using the webpages

Parameter	Values	Description
Protocol	ION, Modbus RTU, Modbus Master, DNP v3.00, DLMS, EtherGate, GPS: Truetime/Datum, GPS: Arbiter, GPS: Arbiter-Vorne, Factory, None	Sets the communications protocol for your meter's RS-485 port The NONE setting stops communications using this port.
Baud Rate	2400, 4800, 9600, 19200, 38400, 57600, 115200	Sets the data rate, in bits per second
Unit ID	1–9999	Sets the meter's unique ID on the RS-485 network NOTE: Modbus serial device range 1 to 247

Advanced serial communications settings available using the webpages

Parameter	Values	Description
RTS Delay	0–1	The delay in seconds before the transmission of the packet.
Rx Timeout ¹	0.1–15	Sets the transmit delay (timeout for receiving an entire message from a device) in seconds.
Serial Port	8N1, 8N2, 8E1, 8E2, 8O1, 8O2	Sets the parity and stop bits for the port
RS485 Bias	OFF, ON	Turns on biasing on the client device over the RS-485 port

¹Only applies to a subset of protocols.

Configuring serial communications using the display

You can configure your meter's basic serial communications settings using the display.

Before configuring serial parameters, make sure you have a unique unit ID for your meter and know the serial network settings (protocol, baud rate, parity and stop bits).

To configure the meter's serial communications settings using the display:

- 1. Press the **Home** button.
- 2. Press Setup Menu > Communications Setup.

- 3. Press the up and down icons to scroll and select **COM1 Setup** or **COM4 Setup**.
- 4. Configure your meter's serial settings as required.

Serial communications settings

Parameter	Values	Description
Protocol	ION, Modbus RTU, Modbus Master, DNP v3.00, DLMS, EtherGate, GPS: Truetime/Datum, GPS: Arbiter, GPS: Arbiter-Vorne, Factory, None	Sets the communications protocol for your meter's RS-485 port The None setting stops communications using this port.
Baud Rate	2400, 4800, 9600, 19200, 38400, 57600, 115200	Sets the data rate, in bits per second
Rx Timeout	0.1–15	Sets the transmit delay in seconds
Unit ID	1–9999	Sets the meter's unique ID on the RS-485 network NOTE: Modbus serial device range 1 to 247
Serial Port	8N1, 8N2, 8E1, 8E2, 8O1, 8O2	Sets the parity and stop bits for the port
RS485 Bias	OFF, ON	Turns on biasing on the client device over the RS-485 port

Disabling serial communications ports

You can disable serial communications ports using ION Setup, meter webpages, or the display.

Disabling serial communications using ION Setup

NOTE: Disabling unused ports is considered a cybersecurity best practice to help minimize unauthorized access to your meter.

To disable serial communications using ION Setup:

- 1. Open the **Setup Assistant** for your meter.
- 2. Click Communications > Serial Settings.
- 3. Click the Com1 or Com4 tab.
- 4. Select Protocol and click Edit.
- 5. Select **None** from the drop-down list box and click **OK**.

Disabling serial communications using the webpages

NOTE: Disabling unused ports is considered a cybersecurity best practice to help minimize unauthorized access to your meter.

To disable serial communications using ION Setup:

- Open a web browser and enter your meter's IP address in the address bar. The webpage login prompt is displayed.
- 2. Enter your login credentials.
- 3. Navigate to **Setup > Serial Port** and expand the **Basic Settings** section.
- Choose COM1/ RS485#1 Protocol or COM4/ RS485#2 Protocol from the drop-down list box and select None to disable the port.
- 5. Click **Apply**. When prompted, click **Yes** to save the changes.

Disabling serial communications using the display

NOTE: Disabling unused ports is considered a cybersecurity best practice to help minimize unauthorized access to your meter.

To disable serial communications using ION Setup:

- 1. Press the **Home** button.
- 2. Press Setup Menu > Communications Setup.
- 3. Press Select.
- 4. Scroll then select COM1 Setup or COM4 Setup.
- 5. Press the navigation icon to scroll and select **Protocol**.
- 6. Press the Edit button. Enter user credentials if prompted.
- 7. Press the down icon and then select **None** to disable the port.
- 8. Press the **Select** button when you are finished. If prompted, press **Select** button again to accept the changes.

ION

ION is the architecture of your meter.

The basic building blocks of ION architecture are the ION modules, each of which is specialized to perform a specific task and contains data and instructions on how to manage that data. ION modules are linked together to create the meter's functions and features. ION modules that are linked together to perform a specialized task are called a framework, such as the Power Quality framework. These different functional frameworks are then grouped together to define the entire meter and are collectively referred to as the device template.

Your meter ships with a default device template which provides extensive capabilities. You can also configure the meter's template to modify existing meter functions or to create new functions.

Related resources:

For more information on ION architecture and a detailed description of the different ION modules, see *ION Reference*, available from www.se.com.

Secure ION

Secure ION, or ION over TLS, enhances the security of the ION protocol by using a Transport Layer Security (TLS) encrypted tunnel between the device and the software client.

NOTE: The additional TLS layer applies to a TCP/IP based connection (Ethernet) only. It does not apply to serial communications.

To use Secure ION your IT infrastructure must be configured to allow the traffic on the Secure ION port to pass. The default port for Secure ION is 7443.

Connecting to a device using Secure ION

Use ION software to connect to a device using Secure ION.


If you are using ION Setup in Network mode or Power Monitoring Expert, configure the device to use the Secure ION programmed IP port.

Prerequisites:

Your IT infrastructure must be configured to allow the traffic on the Secure ION port to pass.

To connect to a device using Secure ION:

1. In Device Properties, set the IP Port to the Secure ION port:



2. Click OK.

NOTE: If you connect to a device in ION Setup using Single ION Device mode, ION Setup will try to connect to the Secure ION port automatically. If the defined port isn't available on your network, the device will connect using ION over TCP. You can use ION software to configure devices to override the default connection process, see "Setting the ION protocol connection and port number" on page 99 for details.

Secure ION security certificates

Devices that support Secure ION include a self-signed SSL certificate. When you connect to a device using Secure ION, a certificate must be associated with the TLS connection.


You can upload a Certificate Authority (CA) signed certificate. For details, see "Uploading a custom SSL certificate" on page 118.

NOTE: To reduce cybersecurity risk, use a Certificate Authority (CA) signed SSL certificate and external network controls. To learn more about this risk, see "Security risks and mitigation strategies" on page 34.

In ION Setup, you can view the certificate information—including its SHA1 thumbprint—by clicking **View Certificate Info**.



For example:



ION Setup stores the certificate when using Network mode. In Single Device mode, you must accept the certificate every time you connect to a device using Secure ION.

Setting the ION protocol connection and port number


When connecting to a device in ION Setup using Single ION Device mode, ION Setup will try to connect to the Secure ION port automatically. If your IT infrastructure isn't configured to allow traffic on the Secure ION port to pass, the device will connect using ION over TCP.

You can override the default ION connection on a device that supports Secure ION by manually appending the IP address connection options to the IPv4 address. Doing so explicitly defines the connection process.

The following table describes the override values you can use and the resulting connection process:

Example override value	Connection process
10.168.68.245/7443	Explicitly connects to port 7443. If the registry dictates that ION over TLS = 7443, this will be a TLS connection.
10.168.68.245/TLS	Explicitly uses the registry to connect to what is specified as the ION over TLS port. By default: 7443.
10.168.68.245/TLS:7443	Explicitly uses a TLS connection to the specified port. In this example, 7443.

For example:



ION sessions

An ION session uses a session token ID to authenticate ION requests to a device. The first ION request sends the user credentials to the device. Upon successful validation, the device creates a unique, non-transferable ION session token ID. Subsequent ION requests are validated using the ION session token ID, not the user credentials.

An ION session token ID has a fixed inactivity session timeout of 5 minutes.

There is no configuration required to enable ION sessions.

NOTE: Both the ION over TCP and ION over TLS (Secure ION) include ION session authentication.

Modbus

Modbus is a client-server communications protocol where the client initiates transactions and the server or servers respond with the requested information or action.

Your device can function as a Modbus client or Modbus server, depending on how it is configured. Your device comes with Modbus server functionality configured and ready to use. You can add custom Modbus information to the default Modbus server data provided by your device.

Key terms

Term	Definition
Modbus gateway	A communications method that lets you communicate through an Ethernet gateway device to a Modbus serial network connected to that device.
Modbus client (historically known as Modbus master)	A device that issues commands and receives responses from Modbus server devices. Serial Modbus networks can only have one Modbus client per network.
Modbus RTU	Serial Modbus protocol format; Modbus RTU transmits data using binary. Server and client devices must use the same format.
Modbus register/address	Identifies the data to read/write. Modbus register maps are available for Modbus client devices and detail the information available from the client device. More than one register may be used to store a single value.
Modbus server (historically known as Modbus slave)	A device that responds to Modbus commands and performs actions or provides information back to the Modbus client. Most Modbus networks contain multiple server devices.
Modbus TCP	The Ethernet Modbus protocol format.
Modbus unit ID	The identifier for a client Modbus device.

You can download your device's Modbus map from www.se.com and get additional information about the Modbus protocol from www.modbus.org.

Ethernet Modbus device prerequisites

For your meter to operate as an Ethernet Modbus device, you must complete some prerequisite configuration.

NOTE: You do not need to perform any Modbus-specific configuration for your meter to function as a Modbus client device over Ethernet.

Prerequisite	Description
Ethernet	All devices must have a working Ethernet connection.
IP address	All devices must have a unique IP address.
Port	All devices must be communicating over Ethernet port 502 for Modbus TCP.

NOTE: Devices supporting multiple simultaneous Modbus TCP connections can have communications delays. Adjust your network timeout settings to accommodate this.

Serial Modbus device prerequisites


For your meter to operate as a serial Modbus device, you must complete some prerequisite configuration.

Prerequisite	Description
	The device's serial connection must be wired correctly.
Wiring	The Modbus server devices must have communications wiring to the Modbus client.
Protocol	Servers – For your meter to be a serial Modbus server, the meter's protocol must be set to Modbus RTU. Client and server devices must use the same format.
	Client – For your meter to be a serial Modbus client, the meter's protocol must be set to Modbus Master.
Baud rate	The baud rate must be the same for all devices on the serial Modbus network.
Stop bits and parity	The communication stop bits and parity (for example, 8N1) must be the same for all devices on the serial Modbus network.
Unit ID	Each device on the serial Modbus network must have a unique unit ID (also called the device address). Note: Modbus serial device range 1 to 247

Your meter as a Modbus client

Your meter as a Modbus client with Ethernet Modbus server devices

Your meter can function as a Modbus client with Ethernet Modbus server devices.




Α	Ethernet	
В	Your meter	
С	Modbus servers	

To use the Modbus client-server architecture, add the Modbus server devices using ION Setup.

Your meter as a Modbus client with serial Modbus server devices

Your meter can function as a Modbus client with serial Modbus server devices.



Α	Ethernet
В	Your meter
С	RS-485 Modbus RTU
D	Modbus servers

To use the Modbus client-server architecture, add the Modbus server devices using ION Setup.

Modbus client best practices

For your meter to operate as a Modbus client, you must complete some prerequisite configuration.

NOTE: These settings are required in addition to the serial or Ethernet Modbus prerequisites.

Prerequisite	Description	
Modbus client devices	All Modbus client devices must be communicating and appropriately configured.	
	 Modbus client-server serial devices – The client's serial port protocol must be set to Modbus Master. 	
Protocol	 Modbus client-server Ethernet devices – The client must be communicating to the server devices over Ethernet port 502. 	
	NOTE : Having more than one Modbus client on a serial Modbus network may cause communication conflicts.	
Modbus server devices	The Modbus client device must have the server device information entered.	

Configuring your meter as a Modbus client using ION Setup

You can configure your meter to Modbus client-server devices over serial or Ethernet.

Make sure your client and server devices have the prerequisite communications wiring and configuration before configuring your meter as a Modbus client.

If the meter is a Modbus client over TCP/IP, the Modbus TCP/IP and Modbus RTU protocols must be enabled.

NOTE: Devices supporting multiple simultaneous Modbus TCP connections can have communications delays. Adjust your network timeout settings to accommodate this.

The meter as a Modbus client over TCP/IP attempts to communicate with a server device for up to 100 seconds (as per the RFC 1122 standard) before moving on to the next server device.

To configure your meter as a Modbus client over serial or Ethernet:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Communications > 3rd Party Protocols > Modbus Master.
- 4. Click Add to add a Modbus server device.

The Modbus Device dialog appears.

- 5. Enter the Modbus server information:
 - Enter the Modbus server device's name and a label suffix (if applicable).
 - Select the device type of the server device from the **Device Type** drop-down list box.

- Enter the unit ID of the Modbus server device into the **Slave ID** text box.
- Select the serial or TCP connection from the Connected via drop-down list box. This is the connection from the Modbus client to the server device.
- 6. Click Connections. The Modbus Master Connections dialog appears.
- 7. Select the tab that corresponds to the connection you are configuring.

For example, if you selected TCP Connection 1 from the **Connected via** drop-down list box, select the TCP 1 tab.

8. Configure the connection type:


Connection type	Configuration	
Serial connection	Select the serial communications port that is connected to the Modbus server devices from the Assigned Port list.	
TCP connection	Enter the IP address of the Modbus server device, making sure that the IP port is set to 502.	
	Make sure that the Modbus RTU and Modbus TCP/IP protocols are enabled.	

- 9. Click **OK** to return to the Modbus Device dialog.
- 10. Click **OK** to add the server device. The device now appears on the list.
- 11. Repeat steps 4 through 10 to add all your Modbus server devices.

Your meter as a Modbus server

Your meter as a Modbus server over Ethernet

Your meter can function as a Modbus server over Ethernet.




Α	Modbus client	
В	Ethernet Modbus TCP	
С	Your meter	

Your meter does not require any Modbus-specific configuration to act as a Modbus server device over Ethernet.

Your meter as a Modbus server on a serial network

Your meter can function as a Modbus server on a serial network.



Α	Modbus client
В	RS-485 Modbus RTU
С	Your meter
D	Modbus servers

Your meter's serial connection must be wired and configured correctly. The same mode of serial communication must be used for all devices on the network.

Configuring your meter as a Modbus server using ION Setup

To configure your meter as a Modbus server using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click **Communications > Serial settings**. Select the tab for the serial port you want to configure.
- 4. Highlight the parameter, and then click **Edit** to configure the serial port's Modbus parameters as required:

Parameter	Setting
Protocol	Modbus RTU or Modbus Master
RS485 Bias	OFF if the meter is a Modbus server
NO400 DIAS	ON if the meter is a Modbus client

5. Configure the meter's other serial port parameters as required.

Next, add the Modbus server devices using ION Setup.

See your device's Modbus map, available from www.se.com for Modbus register information.

Configuring your meter as a Modbus server using the webpages

To configure your meter as a Modbus server using the meter webpages:

- 1. Connect to your meter's webpages.
- 2. Navigate to Setup > Serial Port.
- 3. Expand Basic Settings or Advanced Settings, and then configure the serial port's Modbus parameters as required:

Parameter	Setting
Protocol	Modbus RTU or Modbus Master
RS485 Bias	OFF if the meter is a Modbus server
NO400 Dias	- ON if the meter is a Modbus client

4. Configure the meter's other serial port parameters as required.

Next, add the Modbus server devices using ION Setup.

See your device's Modbus map, available from www.se.com for Modbus register information.

Configuring your meter as a Modbus server using the display

To configure your meter as a Modbus server using the meter display:

- 1. Press the **Home** button.
- Navigate to Setup Menu > Communications Setup, scroll and select COM1 or COM4 Setup.
- 3. Configure the Modbus parameters as required:

Parameter	Setting
Protocol	Modbus RTU or Modbus Master
RS485 Bias	OFF if the meter is a Modbus server

4. Configure the meter's other serial port parameters as required.

Next, add the Modbus server devices using ION Setup.

See your device's Modbus map, available from www.se.com for Modbus register information.

Supported Modbus features

Your meter supports specific Modbus data classes, data formats, function codes, and commands.

Modbus data classes

Class	Description
Coils	Digital bits that can be read and written to
Input status	Digital bits that can be read
Input registers	16-bit integers that can be read
Holding registers	16-bit integers that can be read and written to

Modbus data formats

Format	Туре	# of Modbus registers used
Unsigned 16-bit	Integer	1
Signed 16-bit	Integer	1
Unsigned 32-bit	Integer	2
Signed 32-bit	Integer	2
Unsigned 32B-M10K	Integer	2
Signed 32B-M10K	Integer	2
IEEE float ¹	Floating point	2
Packed Boolean for inputs	Integer	1
Packed Boolean for coils	Integer	1
Unsigned 16-bit read/write	Integer	1
Signed 64 bit	Integer	4

¹ A device acting as a Modbus client supports two versions of IEEE float with different word orders: high/low = Big Endian, low/high = Little Endian.

16-bit data (one word) is transmitted with most-significant byte first and least-significant byte second.

32-bit data (two words) is transmitted with the most-significant word first and the least-significant word second.

Modbus function codes

Function	Description	Client / Server
1	Read coil status	Client and server
2	Read input status	Client and server
3	Read holding registers	Client and server
4	Read input registers	Client
5	Write to a coil	Client
6	Write to a holding register	Client and server
15	Write to multiple coils	Client
16	Write to multiple holding registers	Client and server
17	Report slave ID (serial only)	Client and server
43 (sub code 14)	Read device identification	Client and server
100	Read scattered holding registers	Client and server

Modbus commands

A Modbus client command to unit ID 0 is broadcast (sent to) all Modbus server devices. The only supported broadcast command is preset multiple registers.

For serial Modbus networks with only one server device, the client can send commands using the single connection, one-to-one address of unit ID 248, regardless of the server device's actual unit ID.

Modbus implementation

Your meter's Modbus implementation includes exception codes, invalid register responses, fixed and configurable register maps, and security.

Modbus exception codes

Code	Name	Description
01	Illegal function	The requested command is invalid.
02		This code indicates one of the following:
		The requested address is invalid for that function.
	Illegal address	The requested address is not within the valid register range for this device.
		 The requested address is protected by device security.
03	Illegal value	This code indicates one of the following:
		The requested value is not allowed for that register in the device.
		The requested register is part of a multi- word value.

Modbus invalid read registers responses

Invalid type	Read response	
Unmapped (unused)* register	0x8000	
Reserved* register responses by type		
Signed integer 16-bit	0x8000	
Unsigned integer 16-bit	0xFFFF	
Signed integer 32-bits	0x80000000	
Unsigned integer 32-bits	0xFFFFFFF	
Signed integer 64-bits	0x800000000000000	
Float32	0xFFC00000	
1 Idaid2	(NaN = Not a number)	

* IRIG-B can only be connected to one of the digital inputs located on the meter base, not an option module. Unmapped (unused) registers are registers that will never be used by the meter, and therefore have no defined format. Reserved registers have a defined format and are intended for use by the meter, its options, or its variants.

Modbus invalid write registers response

If the meter receives a write command to a Modbus register address that does not have a register mapped, the meter will not respond. No data is written or stored, and the meter will not send back a rejection to the request.

If the meter receives a write command to a read-only Modbus register address, exception code 03 (illegal value) is returned.

Fixed and configurable Modbus map

Your meter has a fixed (static) register map for meter data and a flexible, user-configured register map.

Modbus security

Your meter's onboard security options include Modbus-specific settings. These security settings may need to be configured to write Modbus data to the meter.

Modbus map

Your meter's default Modbus register information (map) is available on www.se.com.

The Modbus register information includes:

- · Registers and mapped values
- Formats and scaling
- · Additional details where applicable

NOTE: Your meter's Modbus registers are specified differently than previous devices using ION architecture. If you are configuring Modbus client information on your meter, confirm you are using the appropriate Modbus register addressing. For more information, refer to your meter's Modbus map.

Your meter has a fixed (static) register map which contains the most common metering values. This map is defined by a series of Data Mapping modules, which also determine the values shown on the meter webpages or the display. The Data Mapping modules are named based on the type of information they map to Modbus:

Data Mapping module	Description	
Data Mapping Dmd	Maps kW, kVA and kVAR demand data such as kW sd del (sliding demand kilowatts delivered), as well as current demand such as I a sd (sliding demand phase A current).	

Data Mapping module	Description
Data Mapping Egy	Maps kWh, kVAh, and kVARh delivered, and received data, including conditional, quadrant, and incremental energies.
Data Mapping EN	Maps present interval EN 50160 power quality compliance data.
Data Mapping EN Prev	Maps previous interval EN 50160 power quality compliance data.
Data Mapping IEEE519	Maps IEEE 519 harmonics compliance data.
Data Mapping I/O	Maps input metering data, alarms, resets, and reset counts.
Data Mapping Meas	Maps voltage, current, power, power factor, and frequency data for one second and half-cycle measurements.
	The Cfg Modbus Map Enable setup register may exist in this module.
Data Mapping PQ	Maps power quality data such as Crest Factor, K Factor, and total harmonic distortion, including IEC 61000-4-30 power quality compliance data.
Data Mapping Stats	Maps statistical low, mean, and high data values, such as I a mean (phase A current average value).
Data Mapping TOU	Maps time-of-use (TOU) data, such as seasons, rates, and per-season demand, such as kW sd rec A (sliding demand kilowatts received in season A).

You can add extra Modbus information or duplicate information that is already in the fixed map to different Modbus registers using Modbus Slave modules.

For more information on Data Mapping modules and Modbus Slave modules, see *ION Reference*, available on www.se.com.

Configuring custom Modbus data using ION Setup

You can add custom data to your meter's default Modbus map, completely customize your meter's Modbus map, or revert your meter's Modbus map back to its default configuration using ION Setup.

Download your meter's Modbus map information from www.se.com.

To configure custom data using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.

3. Click Communications > 3rd party protocols > Modbus Slave.

The name of the meter's current Modbus map is displayed, along with the quantity of custom registers and their start and end addresses.

4. Select the map name and click Edit.

The Modbus Slave Mode Setup screen is displayed.

 Select your meter's method of Modbus client mapping. If you select **Default** or **Disabled**, click **Finish** to configure your meter and return to the **Setup Assistant**, otherwise select **Next** to access the **Modbus Slave Map Setup** screen.

Option	Description
Default	Sets your meter to use the default Modbus map. Any custom Modbus client data is removed. NOTE: You can download your meter's Modbus map information from www.se.com.
Modified	Add Modbus information in addition to the meter's default Modbus map.
Custom	Removes the meter's default Modbus map so that all registers are available, and you can create a completely custom Modbus map. NOTE: Use this option if you want to make your meter's Modbus map identical to a device that it is replacing, for example in a retrofit application.
Disabled	Removes your meter's Modbus data map. Modbus functions are unaffected, but no meter Modbus data is available.

6. In the **Modbus Slave Map Setup** screen, you can modify parameters by clicking **Edit**, or add parameters by clicking **Add**.

The **Modbus Register** screen is displayed.

- 7. Configure the Modbus register information and click **OK** to return to the **Modbus Slave Map Setup** screen.
 - a. Source: Click Select and chose a source from the Parameter Selection screen. Select Show all available registers to see a complete list of the parameters available on your meter. Click OK.
 - b. Address: Enter the Modbus address that will hold the Source data.

NOTE: If you hover your mouse over the Address field, a tooltip indicates the Modbus function code and start address to send for retrieving the data.


- c. Format: Select the Modbus data format from the list.
- d. **Scaling**: Select the scaling value from the list or select **Custom** and click **Scales** to configure custom scaling.

- 8. In the **Modbus Slave Map Setup** screen you can click **Delete** to remove a Modbus register, **Set Name** to create a new name for the set of additional data mapped to Modbus, or **Save As** to save the additional data you have mapped to Modbus as a separate file.
- Click Finish to complete your meter's Modbus client configuration and return to the Setup Assistant.

Ethernet gateway

Ethernet gateway is a communications method that allows you to communicate through a gateway device to a serial network.

When a meter with gateway capabilities is installed on an Ethernet network, a client device (such as an energy management system) can communicate through the gateway meter to a serial network of devices connected to the gateway meter's serial port(s). The maximum number of devices on the serial network is determined by the limitations of the gateway meter's serial port.



Α	LAN/WAN
В	Ethernet gateway meter
С	Serial RS-485 network of devices
D	Terminating resistor

There are two types of Ethernet gateways that you can configure on your meter:

- EtherGate A single TCP connection communicates through the gateway meter to a serial network of devices.
- Modbus gateway Up to a maximum of 32 Modbus client TCP connections communicate through the gateway meter to a serial network of Modbus devices.

EtherGate configuration

The meter can function as an Ethernet gateway (EtherGate).

When a meter with gateway capabilities in installed on the Ethernet network, a client device can communicate through the gateway meter to a serial network of devices wired to the gateway meter's COM port. You must create an additional communications connection to the gateway meter to read its information.

NOTE: EtherGate supports only one client device.

Before configuring EtherGate, confirm the following:

- The serial network of devices are wired to the gateway meter's serial communication port.
- All serial devices are configured to have the same baud rate, serial port settings (for example: 8N1), and protocol (ION).
- Each serial device has a unique unit identifier (unit ID/address).
- Your gateway meter is communicating over Ethernet.

You can then configure the gateway meter's serial port to use the EtherGate protocol, create the EtherGate site in ION Setup or an energy management system, and add the serial devices to the EtherGate site.

Secure EtherGate

Secure EtherGate enhances the security of the EtherGate protocol by using a TLS encrypted tunnel between the device and the software client.

Secure EtherGate is an option available in the Protocol setup register of the serial communication modules on the device.

The Secure EtherGate is available at port 7801/7802. If Secure ION is disabled, Secure EtherGate will continue to accept and parse incoming data to the serial port.

NOTE: The additional TLS layer applies to the TCP/IP based connection (Ethernet side) only. It does not apply to the serial side of the EtherGate connection.

Configuring EtherGate or Secure EtherGate using ION Setup

To configure EtherGate or Secure EtherGate communications using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Communications > Serial settings.
- 4. Select the tab (**Com1** or **Com4**) for the serial port you want to configure.
- 5. Highlight the parameter, and then click Edit. Enter the meter password if prompted

6. Change the settings, and then click **OK** to save the changes.

Parameter	Setting
Protocol	EtherGate or Secure EtherGate
Baud Rate	Serial port settings must match the settings for all connected
Serial Port	serial devices.

7. Create an Ethernet gateway site to access the serial network of devices through your gateway meter.

Configuring EtherGate or Secure EtherGate using the webpages

To configure EtherGate or Secure EtherGate communications using the meter webpages:

- 1. Connect to your meter's webpages.
- 2. Navigate to Setup > Serial Port.
- 3. Expand Basic Settings or Advanced Settings and modify the settings for the serial port you are configuring for EtherGate communications (COM1 / RS485#1 or COM4 / RS485#2).
- 4. Change the settings, then click **Apply**. Click **Yes** to save the changes.

Parameter	Setting
Protocol	EtherGate or Secure EtherGate
Baud Rate	Serial port settings must match the settings for all connected
Serial Port	serial devices

You can use ION Setup to create an Ethernet gateway site and access the serial network of devices connected through the EtherGate meter.

Configuring EtherGate or Secure EtherGate using the display

To configure EtherGate or Secure EtherGate communications using the meter display:

- 1. Press the **Home** button.
- 2. Navigate to **Setup Menu > Communications Setup**.
- 3. Press the Select button.
- 4. Scroll then select **COM1 Setup** or **COM4 Setup**.
- 5. Highlight the parameter and press **Edit**. Enter the meter password if prompted, change the setting, then press **Select** to save the changes.

Parameter	Setting
Protocol	EtherGate or Secure EtherGate

Parameter	Setting
Baud Rate	Serial port settings must match the settings for all connected
Serial Port	serial devices

You can use ION Setup to create an Ethernet gateway site and access the serial network of devices connected through the EtherGate meter.

Modbus Ethernet gateway

A Modbus Ethernet gateway allows multiple Modbus client devices on the LAN/WAN to connect to downstream serial Modbus server devices.

A Modbus client device, such as an energy management system, can communicate through the gateway meter to a serial network of devices connected to the gateway meter's serial port(s). The meter receives Modbus TCP/IP data on TCP port 502, translates it to Modbus RTU then forwards it to the addressed server device.

This functionality allows the use of monitoring software to access information from server devices for data collection, trending, alarm/event management, analysis, and other functions.

Modbus Ethernet gateway implementation

There are some specific aspects to your meter's Modbus Ethernet gateway implementation.

A Modbus request is sent through Ethernet using Modbus/TCP to the gateway meter. If this request is addressed with the slave ID of one of the downstream serial devices, the meter forwards the message to that device using Modbus RTU. When the downstream device responds, the gateway meter forwards the response back to the Modbus client. In addition to Modbus server addresses 1 to 247, the Modbus gateway supports server address 255, which sends a Modbus request to the gateway meter only.

For Modbus gateway, you must install the serial Modbus server devices, configure them and connect them to your Ethernet-connected Modbus gateway meter. Ensure that each serial device is configured to communicate over Modbus with the same baud rate and has a unique unit ID. Configure the gateway meter's serial port to use the Modbus Master protocol and enable the Modbus gateway feature, create a Modbus gateway site in ION Setup or an energy management system, and add the serial devices to the Modbus gateway site.

NOTE: Modbus Ethernet gateway supports up to 32 Modbus TCP connections.

Configuring a Modbus gateway using ION Setup

You can configure Modbus gateway on your meter using ION Setup.

Before you begin, make sure you have completed the following tasks:

- Confirm the serial network of devices are wired and configured to have the same baud rate, serial port settings (for example, 8N1), and protocol (Modbus).
- Confirm each serial device has a unique unit identifier.

- Confirm the serial network of devices are connected to the gateway meter's serial communication port.
- Confirm your gateway meter is communicating over Ethernet.
- Confirm that the Modbus RTU and Modbus TCP/IP Ethernet protocols are enabled on your gateway meter.

To configure a Modbus gateway using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click **Communications** > **Serial settings** and select the tab for the communications port that the serial network is connected to.
- 4. Select Protocol and click Edit.

The protocol selection screen appears.

- 5. Set the protocol to **Modbus Master**.
- 6. Click Communications > Basic Ethernet > TCP/IP.
- 7. Select Modbus Gateway and click Edit.

The Modbus gateway selection screen is displayed.

- 8. Select the communications port that the serial network is connected to (and you just set to use the Modbus Master protocol) and click **OK**. The Modbus gateway connection is created.
- 9. Create an Ethernet gateway site to access the serial network of devices through your gateway meter.

Creating an Ethernet gateway site using ION Setup

You can create an EtherGate or Modbus gateway site in ION Setup to view serial devices connected to your meter when it is functioning as an Ethernet gateway.

You must have Ethernet gateway communications configured and your gateway and serial devices connected and communicating.

- 1. Start ION Setup.
- 2. Right-click on your workstation icon and select Insert Item.

The **New Network Item** dialog appears.

3. Select Site and click OK.

The **New Site** dialog appears.

4. Select the **General** tab and configure the site.

Parameter	Values/Options	Description
Name	-	Ethernet gateway site name
Comm Link	Ethernet	Ethernet communications
Ethernet options	Gateway	Ethernet gateway communications

Parameter	Values/Options	Description
Gateway Info: IP Addr	-	IP address of the Ethernet gateway meter
		- 7801 for EtherGate (Com1)
Gateway Info: Port	7801, 7802, 502	- 7802 for EtherGate (Com4)
		 502 for Modbus gateway

- 5. Click **OK** to create the site.
- 6. Right-click on your newly created site and select Insert Item.

The **New Network Item** dialog appears.

- 7. Ensure the new Ethernet gateway site is selected in the **Attach to** drop-down list box.
- 8. Select **Device** and click **OK**.

The New Device dialog appears.

- 9. Enter the details of your serial device. Click **OK** to add the serial device to your Ethernet gateway site.
- 10. Repeat for all the serial devices on the gateway meter.

NOTE: Use a separate standard Ethernet connection in ION Setup to connect to and read data from your Ethernet gateway meter.

HTTPS

HTTPS (Hypertext Transfer Protocol Secure) is an extension of HTTP and is used by a web browser to establish communication between a client computer and the meter's web server hosting webpages.

HTTPS uses Transport Layer Security (TLS) encryption to secure the communications channel and protect exchanged data between the client and the server. When configured to use HTTPS, the meter uses the self-signed certificate installed on its web server.

You can view the meter's webpages by entering the meter's IP address on a web browser.

The meter uses port 443 for HTTPS by default.

Changing web protocol settings using ION Setup

Web protocol settings	Description
HTTPS With HTTP Redirect	Redirects all HTTP requests to use HTTPS.
HTTPS	Allows only secure access and encrypted communications between the client computer and the meter's internal web server hosting webpages.
Disabled	Turns off the meter's web functionality and blocks all access to the meter's web server.

To change web protocol settings using ION Setup:

- 1. Open ION Setup and select the **Setup Assistant** for your meter.
- 2. Click Communications > Advanced Ethernet > Protocols tab.
- 3. Select the Web protocol and click Edit.
- 4. Select a web protocol setting.
- 5. Change the default Assigned Port Numbers for HTTPS With HTTP Redirect and HTTPS. This requires appending the changed port number for HTTPS access to the meter's webpages, for example: <meter IP address>:<changed https port number>.

Secure website indicator

A secure website displays a visible indicator such as a lock icon on the web browser.

The web address prefix https:// also indicates that the website is secure.

Web browsers typically prompt or display a message to warn you if a website you are trying to access is not secure. For https connections, this indicates that the website's SSL certificate is not configured properly or is missing.

Default SSL certificate and webpages security

The meter web server protocol is factory-set to HTTPS with HTTP Redirect.

The meter ships from the factory with a self-signed certificate installed and is set to use HTTPS protocol when accessing the webpages. Because the SSL certificate is self-signed and not signed by a trusted Certificate Authority (CA), almost all browsers will flag the webpages as unsafe.

- If your meter is accessible only inside a secure network, you can add a security exception to override how the browser identifies the webpages.
- If your meter is outside a secure network, you can install an SSL certificate issued by a CA.

Uploading a custom SSL certificate

You can upload a custom SSL certificate through the meter webpages.

Your meter supports .pem certificate file formats.

To upload a custom SSL certificate:

- 1. Use a web browser to log in to your meter.
- Navigate to Setup > HTTPS.
- 3. Click Upload certificate.
- 4. Browse to the custom certificate, select it, then click **Open**.

The certificate is uploaded to the meter and the browser session is restarted.

Generating a new self-signed SSL certificate

A self-signed certificate is valid during the lease period. Generating a new certificate renews the lease.

To generate a new self-signed SSL certificate using the meter webpages:

- 1. Use a web browser to log in to your meter.
- 2. Navigate to **Setup > HTTPS**.
- 3. Click Generate new self-signed certificate.

The meter prompts that the custom certificate will be deleted and that you will be logged out.

4. Click **OK** to proceed.

Deleting a custom SSL certificate

- 1. Use a web browser to log in to your meter.
- 2. Navigate to Setup > HTTPS.
- 3. Click Delete custom certificate.

The meter prompts that you will be logged out and that a self-signed certificate will be used.

4. Click **OK** to proceed.

Secure File Transfer Protocol (SFTP)

Your meter has an internal SSH (Secure Shell) server that can be accessed using an encrypted connection with SFTP (Secure File Transfer Protocol) client software. The SSH server hosts an internal SFTP site and stores files in the meter's flash memory, such as webpages, COMTRADE records and firmware files.

Transferring files using SFTP

Prerequisites:

- Your meter's IP address, username, and password.
- SFTP port number, see "Protocols, ports, and connections" on page 75.
- SFTP client software, such as FileZilla or WinSCP.

To transfer files using SFTP:

- 1. Start the SFTP client software.
- 2. Navigate to the desired folder > select files for upload.
- 3. Close the SFTP client software to disconnect from the meter.

Free up flash memory

Error messages related to available site space for storing files can be resolved by deleting files using an SFTP client application. Available site space is affected by the number and size of stored files and by features that use flash memory, such as increasing the number of COMTRADE waveform records.

SFTP folders and file permissions

SFTP folder structure:

Folder	Description
COMTRADE_1 to COMTRADE_3	View COMTRADE files from these folders. Users have read permission of files.
documents	Add any file type to this folder. Users have full control of files.
IEC61850	Add an IEC 61850 configuration (CID) file to this folder to activate IEC 61850 functionality. Users have full control of files in the root and read permission of files in the log folder.
optionModuleUpg and rmdUpg	Upload firmware upgrade files for your meter's display or option modules to these folders. Users have full control of files.
web	Add custom webpages to the meter by transferring them into web subfolders. This folder is where default meter webpages are stored. Users have full control of files.

SFTP file name restrictions

The names of files sent to the meter using SFTP:

- Cannot include spaces
- Cannot include \ / , * ? < >
- Cannot exceed 50 characters (including the file extension)

Simple Network Management Protocol (SNMP)

Your meter supports Simple Network Management Protocol (SNMP) after you have enabled SNMP on your meter. You need to upload the meter's Management Information Base (MIB) file (available from www.se.com) into the Network Management System (NMS) managing your meter.

SNMP is part of the Transmission Control Protocol/Internet Protocol (TCP/IP) protocol suite. SNMP is an application layer protocol that enables the exchange of network management information between devices, allowing you to manage network performance and to identify and solve problems on networks with devices of various types.

SNMP configuration assumes that you have an advanced understanding of SNMP and the communications network and power system that your meter is connected to.


Key terms

Term	Definition
Agent	Software resident on the managed device which interfaces between the device and the NMS.
Managed device	Your meter in the SNMP network.
Community name/string	A text string that helps authenticate requests between the managed device and the NMS.
Managed object	Any parameter referenced in the MIB file.

Term	Definition
MIB	A management information base which organizes the OIDs in a hierarchical tree.
NMS	A network management station, manager or client that executes applications to monitor and control devices. An NMS must have the standard and custom MIB files and SNMP manager software.
OID	An object identifier that uniquely identifies and labels a managed object in the MIB.
Trap receiver	An NMS that is configured to receive traps and whose IP address is an SNMP trap destination.

Your meter in an SNMP system

Your meter is a managed device with an SNMP agent in an SNMP network.



Α	Trap receivers
В	SNMP agent (meter)
С	NMS with SNMP manager software and MIB file installed

NOTE: The NMS computer can also function as a trap receiver.

SNMP trapping

SNMP trapping allows your meter's agent to notify the NMS of events with an unsolicited SNMP message (a "trap" of the meter's alarm event).

You can enter up to four IP addresses for SNMP trap notification for generic and enterprisespecific traps. For enterprise traps, you must also define the number of events or maximum time delay before SNMP traps are sent to the NMS.

SNMP trapping is only supported on SNMP v2.

Configuring SNMP using ION Setup

You can enable SNMP and configure SNMP trapping using ION Setup.

Download the ION MIB file from www.se.com.

To configure SNMP using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Communications > Advanced Ethernet > SNMP.
- 4. Configure your meter's SNMP parameters by selecting the parameter and clicking **Edit**. Click **OK** in the editing screen to set the parameter value.

Parameter	Description
Enable SNMP	Enables or disables SNMP on your meter.
Enable Traps	Enables or disables SNMP trapping on your meter.
Trap Rcvr1 Addr to Trap Rcvr4 Addr	Enter up to four trap receiver IP addresses where trap messages will be sent.
Read only community	Enter the community string used for SNMP get (read-only) requests.
Read write community	Enter the community string used for SNMP set (read/write) requests. Note: You can use the read/write community string for SNMP get (read-only) requests.
System contact	Enter the name of your SNMP system administrator.
System name	Enter a descriptive name for your meter.
System location	Enter your meter's location.

5. Review the rest of the SNMP information and modify if necessary.

Configuring SNMP using webpages

You can configure SNMP trapping using your meter's webpages.

Download the ION MIB file from www.se.com.

- 1. Connect to your meter's webpages.
- 2. Go to Setup > SNMP Parameters.

3. Configure your meter's SNMP parameters by selecting the parameter value.

Parameter	Range	Description
Enable SNMP	Yes/no	Enables or disables SNMP on your meter.
SNMP Port Number	161 (default)	Enter your meter's SNMP port number.
System contact	-	Enter the name of your SNMP system administrator.
System name	-	Enter a descriptive name for your meter.
System location	-	Enter your meter's location.
Read-only Community Name	-	Enter the community string used for SNMP get (read-only) requests.
Read-write Community Name	-	Enter the community string used for SNMP set (read/write) requests. NOTE: You can use the read/write community string for SNMP get (read-only) requests.
Enable SNMP Traps	Enable/disable	Enables or disables SNMP trapping on your meter.
Enable High Priority Alarms	Yes/no	Enables trapping of events that create high priority alarms.
Enable Med Priority Alarms	Yes/no	Enables trapping of events that create medium priority alarms.
Enable Low Priority Alarms	Yes/no	Enables trapping of events that create low priority alarms.
Report Buffer Size	1–30	Enter the maximum number of trap messages to be stored before the trap messages are sent. Traps are sent when the number of trap messages is equal to or greater than this value.
Report Hold Time	1–300 seconds	Enter the maximum duration for trap messages to be held. Trap messages are sent when the time after a trap event has occurred is equal to or greater than this value.
Trap Rcvr1 Addr to Trap Rcvr4 Addr	-	Enter up to four trap receiver IP addresses, where trap messages will be sent.

4. Click **Apply** to configure the meter's SNMP parameters.

SNMP implementation

MIB files

Your meter is compliant with MIB-II as defined by the standard MIB file RFC 1213.

SNMP requires that you load your meter's ION MIB file (available for download from www.se.com) into the NMS.

You must install RFC 1213, which is required to read basic network information for the meter (for example, TCP/IP traffic or number of packets received), if it is not included with your SNMP manager software.

Community strings

A community string is a text string which acts to help authenticate requests from the NMS to your meter.

There are two community strings on your meter:

- Read Only Community: this community string is used by SNMP get (read-only) requests. The read only community string's initial factory-set value is **public**.
- Read Write Community: this community string is used by SNMP set (read/write) requests.
 The read write community string's initial factory-set value is private.

NOTE: You can also use the read write community string for SNMP get (read-only) requests.

If your meter receives an incorrect community string, it generates an AuthenticationFailure trap.

System strings

A system string is a text string which can be configured to provide information about your meter.

There are three system strings on your meter:

- System contact: Enter the name of the SNMP system administrator.
- System name: Enter a descriptive name for your meter.
- System location: Enter a description of your meter's location.

SNMP trapping implementation

Generic SNMP traps supported by your meter are:

- Coldstart: The meter (SNMP agent) is starting.
- Linkup: The SNMP agent is enabled.
- AuthenticationFailure: The meter (SNMP agent) has received an incorrect community value.

Enterprise-specific SNMP traps supported by your meter are:

- · Low: Trap of events with a low event priority.
- Medium: Trap of events with a medium event priority.
- High: Trap of events with a high event priority.

Trap	Event priority range	
Low	64–127	
Medium	128–191	
High	192–255	

NOTE: The number of events or maximum time delay settings only apply to enterprise SNMP traps.

See *ION Reference*, available from www.se.com, for detailed information on the SNMP Mapping, SNMP Options and Alarm Options modules.

Default SNMP mapping

Enabling SNMP provides SNMP access to the meter values linked to the SNMP Mapping module.

You can configure the SNMP Mapping module to link to different meter values. By default, the following meter values are linked to the SNMP Mapping module:

la	kVAR tot	VII ca	VIn avg	lb mean	kW sd mx del- rec
lb	kVA tot	VII avg	Freq	lc mx	kW sd del
Ic	PF sign tot	VIn a	la mx	lc mean	kW sd rec
Lavg	VII ab	VIn b	la mean	kW sd mx del	kW sd del-rec
kW tot	VII bc	Vln c	lb mx	kW sd mx rec	kVAR sd mx del
kVAR sd mx rec	kVAR sd mx del- rec	kVAR sd del	kVAR sd rec	kVAR sd del- rec	kVA sd mx del
kVA sd mx rec	kVA sd mx del-rec	kVA sd del	kVA sd rec	kVA sd del-rec	kWh del
kWh rec	kWh del-rec	kVARh del	kVARh rec	kVARh del-rec	kVAh del
kVAh rec	kVAh del-rec				

The following meter information is always provided by default and cannot be configured:

Volts mode	Model number
Serial number	Device name
Firmware version	MIB version

If you change your meter's default values, you must modify the custom MIB file to reflect the new values.

Changing your meter's default SNMP configuration assumes that you have an advanced understanding of ION architecture, SNMP, and the communications network and power system that your meter is connected to.

See *ION Reference*, available from www.se.com, for detailed information on the SNMP Mapping module.

Configuring SNMP MIB files

You must configure your MIB file if you modify the default SNMP information provided by the meter for the MIB file labels to reflect the modified values.

Download the ION MIB file from www.se.com.

NOTE: You should only configure the variable name and description. Changing other fields in your MIB file may cause the client software to report problems or return errors when trying to retrieve or view parameters.

The variable name must conform to the following rules:

- The first character must be a letter.
- The first character must be lower case.
- The name must not contain any special characters such as *, ?, &.
- The name must not contain spaces.

To configure your SNMP MIB file:

- 1. Open your meter's MIB file in a text editing program (such as Notepad).
- 2. Update the variable name and description so they match the meter values connected to the SNMP Mapping module.
- 3. Save your meter's MIB file. Keep the original file extension of .MIB.

Example:

This example shows an original and an updated OID entry in an MIB file, where the default meter value of voltage line-to-neutral phase A is modified in the meter's SNMP Mapping module and is now connected to voltage line-to-neutral phase C.

Original OID entry VIn_a OBJECT-TYPE SYNTAX DisplayString (SIZE (0...255)) ACCESS read-only STATUS mandatory DESCRIPTION "Host Meter Voltage Line A to Neutral Units = V (Volts)" ::= { Schneider Electric 34 }

You must update the variable name and description to match the meter values connected to the SNMP Mapping module:

Value	Original	Updated
Variable name	Vin_a	Vin_c
Description	"Host Meter Voltage Line A to Neutral Units = V (Volts)" ::= { 34 }	Host Meter Voltage Line C to Neutral Units = V (Volts)" ::= { Schneider Electric 34 }

The SNMP client software reads the original and updated file as follows:

Original	Updated
variable name: Vln_a	variable name: VIn_c
Description: "SNM1 Input 1 - Voltage (line-to-neutral) phase A"	Description: "SNM1 Input 1 - Voltage (line-to-neutral) phase C"

IEC 61850

IEC 61850 is an Ethernet-based communications protocol designed for electrical substations.

Your meter can be integrated into an IEC 61850 system as an Intelligent Electronic Device (IED) or server that supports concurrent IEC 61850 client connections and an SFTP connection.

Go to the IEC International Electrotechnical Commission website at www.iec.ch for more information on the IEC 61850 protocol.

Refer to the *IEC 61850 and ION technology* protocol document at www.se.com for information about setup and configuration.

Mapping additional data to IEC 61850

Map additional data, such as Inputs and Outputs, to IEC 61850. You do not need to have IEC 61850 enabled on your meter to perform this procedure.

To map additional data to IEC 61850:

- Open ION Setup > select the meter > Setup Assistant.
- 2. Communications > 3rd Party Protocols > IEC 61850.
- 3. Highlight a parameter to add to IEC 61850 data. Select analog for numeric information and digital for Boolean or binary information.
- 4. Click Edit. The custom configuration screen is displayed.
- 5. Select the desired meter value. If the value you want is not shown, select **Show all available registers**.
- 6. Select an IEC 61850 item:
 - Click >> to map the value.
 - Click << to unmap values.
- 7. Click OK.

Enabling IEC 61850 functionality

Your meter is configured with a default set of data available to IEC 61850 that can be integrated into an IEC 61850 system. To enable this functionality, upload a CID (Configured IED Description) file to your meter.

If more than one CID file is stored in the meter, IEC 61850 functionality is deactivated until additional files are deleted.

Prerequisites:

- CET850 IEC 61850 configuration tool installed on your computer. Download the software at www.se.com.
- Meter connection using ION Setup over IPv4 Ethernet.
- Download the firmware package for your meter and select an ICD (IED Capability
 Description) file that matches your meter's profile. Go to www.se.com and search for firmware
 and associated files (ZIP) for your meter.

Enabling IEC 61850 functionality consists of 2 steps:

- 1. Build the CID file using the CET850 IEC 61850 configuration tool.
- 2. Upload the CID file using ION Setup.

Step 1 – Build the CID file:

- 1. Open the CET850 IEC 61850 configuration tool.
- 2. File > New.
- 3. Add > IED. The Add IED dialog box opens.
- 4. Click more options ... in the IED identification area. The Add a Device dialog box opens.
- 5. Select Other device.
- Click more options
- 7. Browse to the location of the ICD file, select it and click **Open**.
- 8. Click OK.
- 9. Enter values for the device in the IED dialog box and click **OK**.
- 10. File > Build a CID file.
- 11. Click Yes on the CET850 message box.
- Save the file as an SCD file. The Save as dialog box opens.
- Ensure CID files (*cid) is selected and click Save.
- 14. Close the CET850 IEC 61850 configuration tool.

Step 2 - Upload the CID file:

1. Open ION Setup > select the meter > Setup Assistant.

NOTE: The CID file can also be uploaded using SFTP. Refer to "SFTP folders and file permissions" on page 119 for more information.

- 2. Communications folder > 3rd Party Protocols > IEC 61850 > Upload CID.
- 3. Navigate to the CID file, select it and click **Open**. CID file validation can take several minutes.

The CID status on the IEC 61850 tab indicates if the meter is operating as an IEC 61850 IED or server.

Watch the video on How to Enable IEC 61850 Functionality on Your Meter.

Configuring digital outputs for IEC 61850 control

Configure default settings for digital outputs to use IEC 61850 for non-critical control of the meter's digital outputs.

This procedure is optional. Your meter has comprehensive default settings for IEC 61850 that meet the needs of most systems without configuration. This is an advanced procedure that requires in-depth knowledge of your meter, its underlying architecture, and the system in which it is installed.

WARNING

UNINTENDED OPERATION

Do not use this device for critical control or protection of persons, animals, property, or equipment.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

To configure digital outputs for IEC 61850 control:

- 1. Open ION Setup.
- 2. Ctrl + click on the meter to select it. This switches ION Setup to Advanced mode.
- 3. IEC 61850 GGIO Onb Modules folder > double-click module > Setup Registers.
- Select the desired SPCS Control Mode register > Edit. A dialog opens.
- 5. Select IEC 61850 CtIVAL from the drop-down list box > **OK** > **Inputs**.
- Select the digital output Status register > Delete.
 Note: This digital input register must be deleted to prevent a circular reference that will cause the affected modules to go offline.
- 7. Click Send.
- Navigate to the **Digital Out Modules** folder > double-click on the module selected to control via IEC 61850.
- 9. Select the Setup Registers tab and confirm that the Digital Output module's setup registers are configured.
- 10. Inputs > Source register > Edit.
- 11. Navigate to the IEC 61850 GGIO Onb folder and select the *SPCS.stVal* output register that corresponds to the digital output.
- 12. Click OK > Send.

See *ION Reference*, available from www.se.com, for information about IEC 61850 GGIO and Digital output modules.

Deleting an IEC 61850 configuration file

- Open SFTP client software. See "Secure File Transfer Protocol (SFTP)" on page 119 for information about connecting with SFTP client software.
- 2. Connect to the meter using the meter's IP address and SFTP port number. See "Protocols, ports, and connections" on page 75 for information on port numbers.
- 3. Open the IEC61850 folder in SFTP file directory and delete the CID file.
- 4. Close SFTP client software.

Distributed Network Protocol (DNP)

Your meter can be integrated into a DNP network as a DNP slave.

The Distributed Network Protocol Version 3.0 (DNP 3.0) is an open protocol used in the electric utility industry for communications and interoperability among substation computers, Remote Terminal Units (RTUs), Intelligent Electronic Devices (IEDs, for example: meters), and master stations.

DNP supported features and default implementation

Your meter is pre-configured for basic DNP slave functionality.

Your meter supports a maximum of three concurrent connections (sessions) using the DNP 3.0 protocol; one for each serial port, up to three using Ethernet, or a combination of both. Combinations available depend on the meter's communications options. A session consists of all incoming and outgoing DNP master-slave traffic on one of the meter's communications ports.

For serial DNP communications, you must assign the DNP protocol to the appropriate serial communication port on your meter; you do not have to configure your meter's Ethernet ports.

You can modify your meter's default DNP map using configuration software.

Data can be imported into the meter from a DNP control relay or analog output device. This is an advanced feature intended for users with an in-depth understanding of the DNP 3.0 and ION protocols.

See the online ION Setup help for instructions on connecting to your meter and accessing the Setup Assistant, which can be used to modify your meter's DNP port settings and default DNP map.

For more information, see the <u>Multiport DNP 3.0 and ION Technology</u> technical note, available on www.se.com.

DLMS/COSEM

The Device Language Message Specification (DLMS) is described by the international standard IEC 62056. It defines structured modeling and meter data exchange for an interoperable environment.

DLMS supports applications such as remote meter reading, remote control, and value-added services for metering different kinds of energy, such as electricity, water, gas, or heat.

COSEM stands for Companion Specification for Energy Metering. It is an interface model for communicating with energy metering equipment, providing a view of the functionality available through the communications interfaces. The model uses an object-oriented approach.

The COSEM model allows for a manufacturer-independent and controlled method to identify, retrieve, and interpret the information held in any meter.

For more information, see the <u>DLMS/COSEM and ION technology</u> technical note, available on www.se.com.

Inputs/Outputs

Inputs/Outputs overview

Your meter has onboard digital Input/Output (I/O) which can be increased by adding optional digital and analog I/O modules to expand your meter's I/O capabilities.

A WARNING

UNINTENDED OPERATION

Do not use this device for critical control or protection of persons, animals, property, or equipment.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Your meter base has:

- Eight digital inputs
- · Four form A digital outputs
- Two form C relays
- kWh energy pulsing LEDs (one visible, one infrared)
- kVARh energy pulsing LEDs (one visible, one infrared)

You can view information about your meter's I/O through the display or webpages and configure your meter's I/O using ION Setup.

Input/output ION modules

ION modules are used to configure your meter's digital or analog inputs/outputs (I/O).

You need to configure the following ION modules to use the meter's digital or analog I/O.

- Digital input: uses the Digital Input module, which tells the meter how to interpret incoming signals.
- Digital output: uses one of three ION modules depending on the application.
 - Digital Output module: Monitors a change of state to control relay operation via a hardware output device.
 - Pulser module: Transfers high-speed pulses to a hardware pulse counting device that is used to track energy usage.
 - Calibration Pulser module: Integrates instantaneous power inputs, then outputs highspeed pulses to an LED that can be monitored for energy accuracy verification.
- Analog input: uses the Analog Input module, which tells the meter how to interpret an incoming analog voltage or current signal from transducers.

 Analog output: uses the Analog Output module to deliver a continuous direct voltage or current analog signal to transducers.

NOTE: All of these modules can act as intermediaries between the physical hardware port and the other modules in the meter. They define the characteristics of the incoming and outgoing signals.

Input/output ION modules, ports, and labels

You can configure the Digital Output, Digital Input, Analog Input, Analog Output, Pulser and Calibration Pulser ION modules to specify which port handles the outgoing or incoming signals.

To assign a port to one of these modules, modify the *Port* setup register by picking a port from the enumerated list.

NOTE: If the port you want to use does not appear in the *Port* setup register list, that port is in use by another module. Edit the *Port* setup register of the module using that port and set it to **Not Used**. The port is then available to other modules.

Factory configured settings

Onboard input and output ports

ION module type	ION module name	Hardware port (device label)	Port setup register name	Description
Digital	Port D1–D4	D1-D4	Port D1–D4	Form A relay
Output	Port R1–R2	R1–R2	Port R1–R2	Form C relay
Calibration Pulser	WATT LED	kWATT	WATT LED	kW energy pulsing (total)
	VAR LED	kVAR	VAR LED	kVAR energy pulsing (total)
Digital Input	Port S1–S8	S1–S8	Port S1–S8	Internally/externally excited

Option module(s) input and output ports

ION module type	ION module name	Hardware port (device label)	Port setup register name	Description
Digital Input Port A/B/C/D S1–S6	S1–S6	Port A S1–S6	Option module digital inputs	
		Port B S1–S6		
		Port C S1–S6		
			Port D S1–S6	

ION module type	ION module name	Hardware port (device label)	Port setup register name	Description
	Port A/B/C/D D1–D2	Relay 1–Relay 2	Port A D1–D2	Option module digital output
Digital			Port B D1–D2	
Output			Port C D1-D2	
			Port D D1-D2	
Analog Input	Port A/B/C/D A1–A4	A1–A4	Port A A1-A4	
			Port B A1-A4	Option module
			Port C A1-A4	analog input
			Port D A1-A4	
Analog Output	Port A/B/C/D Q1–Q2		Port A Q1–Q2	
		01.02	Port B Q1–Q2	Option module
		Q1–Q2	Port C Q1–Q2 analog output	analog output
			Port D Q1–Q2	

NOTE: When configuring your meter, the configuration interface may show all the possible ports, regardless of what is physically available on your meter.

For more information, see *ION Reference*, available on www.se.com.

I/O option modules

I/O option modules provide increased digital and analog input/output (I/O) capabilities for your meter.

These I/O modules can be used to monitor the status of breakers, control analog or digital transducers, or receive signals that can be interpreted to provide WAGES data for your energy system. For applications requiring high accuracy, such as energy pulsing to verify accuracy, the digital output on the meter base is recommended.

NOTE: Your meter's digital and analog outputs may change state during a firmware upgrade. Option modules are offline during an option module firmware upgrade; they will not communicate to the meter and the outputs may change state during the upgrade process.

Your meter's analog I/O option modules can measure and output either low voltage or current using standard analog transducers such as 4–20 mA current transducers.

Viewing I/O option module data

View I/O option module data using ION Setup, meter webpages, or the display.

To view option module data using ION Setup:

- 1. Start ION Setup.
- 2. Open the Setup Assistant for your meter.

- 3. Select **Expansion Modules > Option I/O Modules**, and then select the desired I/O option module tab.
- 4. If there are no I/O option modules connected, no information other than column headers is displayed.

To view option module data using meter webpages:

- 1. Connect to your meter webpages.
- 2. Go to Monitoring > Inputs/Outputs, and then select Digital Inputs, Digital Outputs, Analog Inputs or Analog Outputs.
- 3. If there are no I/O option modules of the specified type, no entries other than column headers are displayed.

To view option module data using the display:

Go to Inputs/Outputs, and then select Digital Inputs, Digital Outputs, Analog Inputs or Analog Outputs.

I/O option module configuration

You can configure your meter's I/O option modules using ION Setup.

The Option I/O Modules screen has tabs corresponding to the possible option modules, which are identified based on how the option modules are connected to the meter. Each tab indicates the module's type and status and has an area where the module's ports are listed for viewing and configuration. You can also reset your meter's option modules using ION Setup.

Status examples	Description
None	No option module detected
Normal	The option module is operating normally
Option module added	A new option module is detected
Option module removed	The option module has been removed
Invalid S19	The option module's firmware is not supported
Invalid card	The option module type is not supported

Analog inputs

Analog input applications

You can use an analog input to monitor an analog signal, for example a flowmeter, to monitor how much water flows through a pipe.

For analog input operation, your meter takes an analog input signal and provides the resulting scaled value.

Your meter's analog I/O option modules can measure either low voltage or current using standard analog transducers such as 4–20 mA current transducers.

Analog input voltage and current mode

You can set the analog input's mode for voltage or current sensing.

In current mode, the analog inputs have a low input resistance while the meter is powered on, and a high input resistance when the meter is powered off. In voltage mode, the analog inputs have a high input resistance regardless of whether the meter is powered or not.

NOTE: When unpowered, your meter's analog inputs act like they are in voltage mode (high input resistance).

When connected to a current output transducer, this high resistance can create a high voltage. Standard (i.e., 4–20 mA) current transducers have open circuit protection and can handle a high input resistance; however, if non-standard transducers are used high voltages may be generated. Your meter's analog input has circuitry to limit this voltage, but it may not be sufficient with a very high-power current source.

NOTICE

EQUIPMENT DAMAGE

- Ensure the analog input is configured for the correct voltage or current mode before connecting or activating the current transducer.
- Do not exceed the device's ratings for maximum limits.

Failure to follow these instructions will result in equipment damage.

Analog input behavior

Analog inputs may show a value below zero scale if an open circuit is detected on the input port.

Analog input zero scale and full scale values

In most cases the output range of the sensor feeding the analog input matches the hardware limits of your meter's analog input port. In that case, the analog input's zero scale and full scale values are the same as the sensor's represented range. For example:

Analog sensor	Meter's analog input signal	Analog input register values
0. 50 pai represented by a	4. 20 mA analog input range	Full scale = 50 (psi)
0–50 psi represented by a	4–20 mA analog input range Input value: 12 mA	Zero scale = 0 (psi)
4–20 mA signal		Scaled value: 25 (psi)
0. 50 pai represented by a	0. 20 mA analog input rango ¹	Full scale = 50 (psi)
0–50 psi represented by a	0–20 mA analog input range ¹ Input value: 12 mA	Zero scale = 0 (psi)
0–20 mA signal In		Scaled value: 30 (psi)

¹ Analog I/O option module must have firmware version v1.2 or later.

If the sensor's output range does not match your meter's hardware limits, you must calculate the full scale and/or zero scale values by analyzing the system.

For more information on the Analog Input module, see ION Reference, available on www.se.com.

Configuring option module analog inputs using ION Setup

You can configure analog inputs using ION Setup.

Analog inputs are available on the optional I/O modules.

Calculate your zero scale and full scale values based on the analog source and the input range of your meter.

Make sure that the analog input port that you want to use is properly configured and connected to a valid external analog signal source.

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click **Expansion Modules > Option I/O Modules** and select the module tab that corresponds to the option module with the analog input you want to configure.
- 4. Select the analog input channel and click **Edit**. Enter the meter password if prompted. The setup screen for that analog input is displayed.
- 5. Configure the analog input by selecting the parameter and clicking **Edit**.

Parameter	Value/Range	Description
Zero scale	0 to ±10 ⁹	The minimum source value that matches the minimum analog input signal.
Full scale	0 to ±10 ⁹	The maximum source value that matches the maximum analog input signal.
Port	-	The physical analog input port connection.
Mode	Voltage, current	Determines whether the analog input is monitoring voltage or current.
Update Rate	One Second/High Speed	Defines how frequently the input is updated.

Analog outputs

Analog output applications

You can use an analog output to send a signal to an external analog input, for example an analog-controlled valve, to modify a water pipe's valve position to change the flow rate.

For analog output operation, your meter takes an input value and scales it to the appropriate signal value to send out the physical analog output port.

Your meter's analog I/O option modules can output either low voltage or current using standard analog transducers such as 4–20 mA current transducers.

Analog output behavior

Your meter's analog output, after it is configured, outputs voltage or current signals. If your meter's analog output source becomes unavailable (N/A) the analog output level should go to zero (0 V/0 mA) under most conditions.

When your meter is powered off or configured to send voltage, the meter registers as a high impedance.

The electrical signal on the analog output is DC; make sure proper polarity is observed when wiring external devices to the analog output ports.

Analog output zero scale and full scale values

In most cases, your meter's analog output range matches the range of the analog sensors that your meter's outputs are connected to. In that case, your meter's analog output zero scale and full scale values are the maximum and minimum values of the source driving your meter's analog output. These values are used to normalize the source value to a value between 0 and 1 which is applied to the operating range of the analog output port to determine the analog output current or voltage. For example:

Source value	Analog output register values	Meter's analog output signal	
0–120 kW range 100 kW	Full scale = 120 (kW)	4–20 mA range	
	Zero scale = 0 (kW)		
	Normalized: 0.83	Output: 17.33 mA	
0. 120 kW rango	Full scale = 120 (kW)	0–20 mA range ¹	
0–120 kW range 100 kW	Zero scale = 0 (kW)	G	
	Normalized: 0.83	Output: 16.67 mA	

¹ Analog I/O option module must have firmware version v1.2 or later.

If your meter's analog output range does not match the range of the connected analog sensor, you must calculate the full scale and zero scale values by analyzing the system.

For more information on the Analog Output module, see *ION Reference*, available on www.se.com.

Configuring option module analog outputs using ION Setup

You can configure option module analog outputs using ION Setup.

Analog outputs are available on the optional I/O modules.

Calculate your zero scale and full scale values based on the measured value and the analog output range of your meter.

Make sure that the analog output port that you want to use is properly connected to an analog receiver.

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.

- 3. Click **Expansion Modules > Option I/O Modules** and select the module tab that corresponds to the option module with the analog output you want to configure.
- 4. Select the analog output channel and click **Edit**. Enter the meter password if prompted. The setup screen for that analog output is displayed.
- 5. Configure the analog output by selecting the parameter and clicking **Edit**.

Parameter	Value/Range	Description
Zero scale	0 to ±10 ⁹	The minimum source value that matches the minimum analog output signal.
Full scale	0 to ±10 ⁹	The maximum source value that matches the maximum analog output signal.
Port	-	The physical analog output port connection.
Mode	Voltage, current	Determines whether the analog output is monitoring voltage or current.

Digital inputs


Digital input applications

Digital inputs are typically used for monitoring the status of switches or contacts, such as status contacts on circuit breakers.

They can also be used for pulse counting or input metering applications, such as WAGES (water, air, gas, electricity, steam) monitoring, or conditional energy applications, or IRIG-B time synchronization.


Pulse mode

If you set Input Mode to PULSE, a pulse is generated at the Trigger output when the State output changes from OFF-to-ON. No pulse is generated when State changes from ON-to-OFF.




KYZ mode

If you set Input Mode to KYZ, a pulse is generated at the Trigger output for each change of state transition, for example from OFF-to-ON and from ON-to-OFF transitions.



A/C mode

If you set Input Mode to A/C, the digital input port is configured to detect the presence of a low voltage AC signal. The next illustration shows how a digital input can be used to monitor the operation of a low voltage AC fan controller.



IRIG-B time synchronization

You can use a digital input to synchronize the meter time to an IRIG-B time source.

You can connect an IRIG-B time source to one of meter's digital inputs for IRIG-B time synchronization. For IRIG-B time synchronization, you must configure both the meter's digital input and the meter's clock.

NOTE: For improved accuracy use the digital inputs on the meter base.

Configuring onboard digital inputs using ION Setup

You can use ION Setup to configure your meter's digital inputs.

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click **Onboard I/O > Digital Inputs**. The tabs correspond to each digital input. Click on the tab for the digital input you want to edit.
- 4. Configure the digital input by selecting the parameter and clicking **Edit**.
- 5. After the parameter is configured, click **OK** to save the setting to the meter.

Parameter	Value/range	Description
	Pulse, KYZ, A/C,	Specifies how the meter processes the signal:
		 Pulse: the meter counts an entire pulse (from off-on to on-off) as one input.
Input Mode		 KYZ: the meter counts a transition (from off-on or from on-off) as one input.
mpat.mede	IRIG-B*	 A/C: the meter detects analog signals where the ON condition is based on the presence of an AC signal.
		 IRIG-B*: the meter detects an IRIG-B time synchronization signal.
Polarity	Inverting/Non-Inverting	Specifies if the signal from the digital port is inverted or not inverted.
Debounce	0.000-1.000	Specifies how long (in seconds) the signal must remain in a state to be considered a valid state change.
Assigned Port	Defined by your meter's hardware	Your meter's physical digital input port.
EventLog Mode	Log Off/Log On	Specifies if events generate log entries.
State	OFF/ON	Indicates the status of the digital input.

^{*} You must also configure your meter's clock to use IRIG-B time synchronization.

Configuring option module digital inputs using ION Setup

You can configure option module digital inputs using ION Setup.

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click **Expansion Modules > Option I/O Modules** and select the module tab that corresponds to the option module with the digital input you want to configure.
- 4. Select the digital input channel and click ${f Edit}$.
 - The setup screen for that digital input is displayed.
- 5. Configure the digital input by selecting the parameter and clicking **Edit**.
- 6. Once the parameter has been configured, click **OK** to save the setting to the meter.

Parameter	Value/Range	Description
		Specifies how the meter processes the signal:
	Pulse, KYZ, A/C, IRIG-B*	 Pulse: the meter counts an entire pulse (from off- on to on-off) as one input.
Input Mode		 KYZ: the meter counts a transition (from off-on or from on-off) as one input.
input inoue		 A/C: the meter detects analog signals where the ON condition is based on the presence of an AC signal.
		 IRIG-B*: the meter detects an IRIG-B time synchronization signal.
EvLog Mode	Log Off/Log On	Specifies if events generate log entries.
Event Priority	0–255	Specifies the priority of an event.
Polarity	Inverting/Non- Inverting	Specifies if the signal from the digital port is inverted or not inverted.
Debounce	0.000-1.000	Specifies how long (in seconds) the signal must remain in a state to be considered a valid state change.
Port	Defined by your meter's hardware	Your meter's physical digital input port.
Enable	Enabled/Disabled	Specifies whether the module is enabled or disabled.
Alarm Trigger Mode	Alarm on ON/Alarm on OFF	Specifies the behavior of the digital input alarm.
* IRIG-B time synch	ronization is not supp	orted on the option module digital inputs.

WAGES monitoring

WAGES monitoring lets you record and analyze all energy sources and utilities usage.

Your system may use several different types of energy. For example, you may consume steam or compressed air for industrial processes, electricity for lights and computers, water for cooling and natural gas for heating. WAGES monitoring collects the usage information from all these different energy sources to enable a more complete energy analysis.


WAGES information can help you:

- Identify losses or inefficiencies.
- Modify demand to reduce costs.
- · Optimize energy source usage.

WAGES monitoring example

The following example shows WAGES monitoring for a water flow meter.

You can connect your meter's digital input to a transducer that sends a pulse for every 15 kiloliters (4000 US Gal) of water. After configuring an input metering channel and assigning it to the digital input, the meter can detect and record the incoming pulses. An energy management system can then use the information from the meter to perform WAGES analysis.



- A Water flow meter (15 kL/pulse)
- B Energy meter with digital input 1 assigned to input metering channel 1 and configured with unit kL (kiloliters)
- C Energy management system with WAGES analysis capabilities

Input metering

Your meter's digital inputs can be used to count pulses from transducers and convert the pulses to energy measurements.

Your meter's input metering channels count pulses received from the digital inputs assigned to that channel. The incoming pulses are used in calculating and measuring consumption data (e.g., BTU, kWh, L, kg). Each channel must have the following values configured to match the pulse data:

- · Pulse Weight: the pulses per unit value.
- Unit Code: the unit of measure associated with the monitored value.
- Demand Code: for time-based values (such as kWh), this provides the associated demand units (kW) for demand calculations; for other values (such as kg), this can be configured to provide rate information (kg/h or kg/s).
- Mode: whether a pulse is based on a complete pulse or a transition.

For example, if each complete pulse represents 125 Wh, you can configure for Wh pulsing as follows:

- Pulse Weight = pulses/Wh = 1/125 = 0.008
- Unit Code = Wh
- Demand Code = kW (this is automatically set)
- Mode = pulse

If you want to configure for kWh pulsing, you must adjust the pulse weight calculation and unit code as follows:

- Pulse Weight = pulses/kWh = 1/0.125 = 8
- Unit Code = kWh

Configuring standard input metering using ION Setup

You can configure input metering with standard units and rates using ION Setup.

When configuring your meter, the configuration interface may show all the possible ports, regardless of what is physically available on your meter.

NOTE: Your device's digital input must be connected to the input metering pulse source. Review the digital inputs assigned to applications to help you understand your existing configuration.

NOTE: To disable an input metering channel and remove any port associations, set Assigned Input to No connection.

- 1. Start ION Setup.
- 2. Open the Setup Assistant for your meter.
- 3. Click Energy Applications > Digital Input Based.
- 4. Select the input metering channel you want to configure and click **Edit**. The **Input Metering Channel Setup** screen is displayed.
- 5. Select **Enabled** to enable the input metering feature.
- 6. Click **Select** to define which digital input is the pulse source for the input metering channel.
- 7. Configure the remaining parameters as required.
- 8. Click **OK** to save your configuration.
- 9. Configure your meter to log the input metering data if required.

Parameter	Description
Pulse Weight	Enter the value per pulse.
Units	Select the measurement units associated with the pulse.
Demand Period	Enter the frequency in minutes that input metering data is calculated in your energy management system.
Rate	Select the rate associated with the defined Units.
Source ID	Enter a data identifier. This value is added to the input metering channel's output register labels to uniquely identify the data within your energy management system.
	NOTE: You must select a Unit for this field to appear.

Configuring custom input metering using ION Setup

You can configure input metering with custom units and rates using ION Setup.

When configuring your meter, the configuration interface may show all the possible ports, regardless of what is physically available on your meter.

NOTE: Your device's digital input must be connected to the input metering pulse source. Review the digital inputs assigned to applications to help you understand your existing configuration.

NOTE: To disable an input metering channel and remove any port associations, set **Assigned Input** to **No connection**.

- 1. Start ION Setup.
- 2. Open the Setup Assistant for your meter.
- 3. Click Energy Applications > Digital Input Based.
- 4. Select the input metering channel you want to configure and click **Edit**. The **Input Metering Channel Setup** screen is displayed.
- 5. Select **Enabled** to enable the input metering feature.
- 6. Click Select to define which digital input is the pulse source for the input metering channel.
- 7. Clear the **Standard quantity** check box. The screen changes to display custom input metering parameters.
- 8. Configure the remaining parameters as required.
- 9. Click **OK** to save your configuration.
- Configure your meter to log the input metering data if required.

Parameter	Description
Pulse Weight	Enter the value per pulse.
Units	Select the measurement units associated with the pulse. Note: Include source identification information by entering "@" followed by the source identifier.
Demand Period	Enter the frequency in minutes that input metering data is calculated in your energy management system.
Rate	Select the rate associated with the defined Units.
Scaling	Select the scaling value based on the relationship between Units and Rate.
Time Base	Select the value and units to match the Rate.

Digital outputs

Digital output applications

Digital outputs are typically used in switching applications, for example, to provide on/off control signals for switching capacitor banks, generators, and other external devices and equipment.

The digital output can also be used in demand synchronization applications, where the meter provides pulse signals to the input of another meter to control its demand period. The digital output can also be used in energy pulsing applications, where a receiving device determines energy usage by counting the kWh pulses coming from the meter's digital output port.

Configuring onboard digital outputs using ION Setup

To configure the meter's digital outputs using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- Click Onboard I/O > Digital Outputs and select a digital output tab. Configure the digital
 output by selecting the parameter and clicking Edit. Enter the meter password if prompted.

Parameter	Value/range	Description
Source	Digital/Boolean	Link this input to the value that drives the state of the digital output.
Source		If Source is not linked, the digital output state is driven by the Force ON, Force OFF values.
Force ON	Pulse	Link this input to a pulse that forces the digital output on for the PulseWidth duration, regardless of the Source input.
Force OFF*	Pulse	Link this input to a pulse that forces the digital output off.
Normal*	Pulse	Pulsing this input will switch the driver of the digital output from Force ON to Source.
Polarity	Inverting/non-inverting	Specifies if the signal to the digital port is inverted or not inverted.
PulseWidth	0-2,000,000	Specifies the duration of the pulse, in seconds. Setting this parameter to 0 sets the digital output continuously on.
Assigned Port	-	The physical digital output port connection. Only available ports are shown.
State	Open/Closed/Not Available	Indicates the status of the digital output.

^{*} These parameters are only valid when pulse width is set to 0.

Configuring option module digital outputs using ION Setup

To configure the option module digital outputs using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click **Expansion Module > Option I/O Modules** and select the module tab that corresponds to the option module with the digital output you want to configure.
- Select the digital output channel and click Edit. The setup screen for that digital output is displayed.
- 5. Configure the digital output by selecting the parameter and clicking Edit.

Parameter	Value/Range	Description
Source	Digital/Boolean	Link this input to the value that drives the state of the digital output.
		If Source is not linked, the digital output state is driven by the Force ON, Force OFF values.
Force ON	Pulse	Link this input to a pulse that forces the digital output on for the PulseWidth duration, regardless of the Source input.
Force OFF*	Pulse	Link this input to a pulse that forces the digital output off.
Normal*	Pulse	Pulsing this input will switch the driver of the digital output from Force ON to Source.
EventLog Mode	Log Off/Log On	Specifies if events generate log entries.
Polarity	Inverting/non-inverting	Specifies if the signal to the digital port is inverted or not inverted.
		Specifies the duration of the pulse, in seconds.
PulseWidth	0-2,000,000	Setting this parameter to 0 sets the digital output continuously on.
Port	-	The physical digital output port connection. Only available ports are shown.

^{*} These parameters are only valid when pulse width is set to 0.

Energy pulsing

You can configure the meter's energy pulsing LEDs or onboard digital outputs for energy pulsing applications.

When an LED or output is set to energy pulsing, the meter sends a readable pulse or signal based on the measured energy source value. This pulse can be used for accuracy verification or as an input to another energy monitoring system.

Default energy pulsing LED sources

Your meter's energy pulsing LEDs have default energy source values configured for accuracy verification testing.

For LED locations, see your meter's installation guide.

Calibration Pulser LED	LED	Default energy pulsing source
WATT LED	kWh pulse LED	kW del-rec
WATTLED	kWh pulse infrared LED	KVV del-lec
VAR LED	kVARh pulse LED	kVAR del-rec
VAR LED	kVARh pulse infrared LED	KVAR del-rec

NOTE: The energy pulsing LEDs are configured in pairs. For example, changing the energy source value will change it for both the regular and infrared LEDs.

NOTE: To modify your default energy source value, go into the advanced mode of ION Setup and modify the associated Calibration Pulser module. This is an advanced procedure that should only be performed if you have advanced knowledge of ION and the power system your meter is connected to.

For more information on the Calibration Pulser module, see *ION Reference*, available on www.se.com.

For more information on other LED indicators, see "Alarm and status LED indicators" on page 169.

Configuring LED energy pulsing using ION Setup

You can configure your meter's energy pulsing LEDs for energy pulsing using ION Setup.

- 1. Start ION Setup.
- 2. Open the Setup Assistant for your device.
- 3. Select LED pulsing.
- 4. Select the tab that corresponds to the energy pulsing LED you want to configure.
- 5. Configure the following basic parameters for your meter's energy pulsing LEDs.

Energy pulsing LED parameters available through ION Setup

	<u> </u>
Parameter	Description
Source	Link this input to the value that you want to pulse on the LED.
Enable	Configuring this setting should only be performed by users with advanced knowledge of ION, the device template and the power system the device is connected to.
Int Mode	Specifies the integration mode for the LED (forward, reverse, absolute or net).
Kt	The amount of source energy required to make the LED pulse.
Pulse Width	The minimum time in seconds between LED pulse transitions.
	Select when the energy pulsing LEDs will pulse:
Pulser Mode	 Always: the energy pulsing LEDs are always pulsing based on their energy source value.
	Pulsing normally indicates that the energy pulsing LED should be operating normally.
Pulse ovrld	Pulsing suspended indicates that the energy pulsing LED is not able to pulse quickly enough. Modify the Kt value to decrease the number of energy pulses or decrease the pulse width, if supported by the device collecting pulses.

NOTE: To perform specialized configuration go into the advanced mode of ION Setup and modify, disable or add a new Calibration Pulser module. These are advanced procedures that should only be performed if you have advanced knowledge of ION and the power system your meter is connected to.

For more information on the Calibration Pulser module, see *ION Reference*, available on www.se.com.

Configuring digital output energy pulsing using ION Setup

You can configure your meter's onboard digital outputs for energy pulsing using ION Setup.

When configuring your meter, the configuration interface may show all the possible ports, regardless of what is physically available on your meter.

Ensure that the digital output port is available for energy pulsing and not associated with another function.

NOTE: For applications where accuracy is important, use the digital output located on the meter base.

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your device.
- 3. Select Energy pulsing.
- 4. Select an energy pulsing source tab (such as Wh Del) to configure energy pulsing using your meter's digital output.

Digital output energy pulsing parameters available through ION Setup

Parameter	Description
Kt	The amount of energy source required to trigger the digital output. For example, in the Wh Del tab, the Kt value would be amount of real energy delivered (Wh Del) per pulse.
Pulse Width	The minimum time in seconds between pulse transitions.
	Select the desired output mode:
OutputMode	 Pulse: the digital output sends a complete pulse when triggered.
Outputwode	 KYZ: the digital output makes a transition (off-to-on, or on-to-off) when triggered.
Port	Select an output port from the list. Only available output ports are shown (ports that are not associated with another function).
(oporav source)	Pulsing normally indicates that the output port should be operating normally.
(energy source) ovrld	Pulsing suspended indicates that the output port is not able to pulse quickly enough. Modify the Kt value to decrease the number of energy pulses.

NOTE: To perform specialized configuration go into the advanced mode of ION Setup and modify or add a new Calibration Pulser module. This is an advanced procedure that should only be performed if you have advanced knowledge of ION and the power system your meter is connected to.

For more information, see ION Reference, available on www.se.com.

Calculate your maximum kWh/pulse (pulse weight) value

To calculate the kWh/pulse (pulse weight) value, divide the highest kW value you can expect by the required pulse rate.

Make sure the required pulse rate does not exceed the maximum pulse rate for the digital output.

NOTE: To convert from kWh/pulse to pulse/kWh you must invert (take the reciprocal) of the value. For example, 1.8 kWh/pulse becomes 0.556 pulse/kWh.

Example pulse weight calculation

For a maximum load of 1600 kW and a pulse rate of two pulses per second, calculate the kWh/pulse value as follows:

1. Convert 1600 kW load into kWh/second:

```
(1600 \text{ kW})^*(1\text{hr}) = 1600 \text{ kWh}

(1600 \text{ kWh})/(3600 \text{ sec}) = (X \text{ kWh})/(1\text{sec})

X = 0.444 \text{ kWh/sec}
```

2. Calculate the kWh required per pulse:

```
(0.444 kWh/sec)/(2 pulses per second) = 0.222 kWh/pulse
```

3. If using KYZ Output Mode, adjust for the KY giving one pulse per two transitions if necessary.

```
(0.222 \text{ kWh/pulse})/(2) = 0.111 \text{ kWh/pulse}
```

For more information on the Calibration Pulser module, see *ION Reference*, available on www.se.com.

Webpages

Webpage interface

Your meter comes with default webpages that contain typical elements.



Α	Meter type and model, device name
В	Username
С	Main menu
D	Webpage menu
Е	Webpage content

NOTE: This graphic is representative only. Your meter's webpages may appear differently than shown.

Default meter webpages

The following table lists the available webpages and their content.

Monitoring

Webpage	Content
	Basic Readings
	Energy Readings
Instantaneous Readings	Demand Readings
	Voltage Readings
	Power Quality
Trending & Forecasting	Select the target and interval for trending and forecasting and view the results.

Webpage	Content	
	Harmonics Chart	
	• ITI (CBEMA)-SEMI	
Davier Ovality Comment	NEMA Motor Derating Curve	
Power Quality Summary	• EN50160	
	IEEE 519 Harmonics	
	HSTC (ION9000T only)	
	Digital Inputs	
Innuta/Outnuta	Digital Outputs	
Inputs/Outputs	Analog Inputs	
	Analog Outputs	
Waveforms	View waveforms from your meter, using the meter's COMTRADE files.	

Control

Webpage	Content
Resets	Perform resets, and view when previous resets were performed.

Diagnostics

Webpage	Content
	Communications
	• Ethernet
Statistics	Serial Port
	Meter - Basic
	Meter - Advanced
Phasor Diagram	View the phasor diagram and numeric values.

Setup

Webpage	Content
Ethernet	Basic Settings
Ethernet	Advanced Settings
Serial Port	Basic Settings
Seliai Foit	Advanced Settings
SNMP Parameters	Configure your meter's SNMP parameters.
NTP	Configure your meter's NTP parameters.

Webpage	Content	
SMTP	Configure your meter's SMTP parameters.	
Date & Time Configure your meter's time and time synchronization.		
Preferences Enter your meter's nameplate information.		
Matarina	Basic Settings	
Metering	Advanced Settings	
HTTPS	Certificate Management.	

Maintenance

Content		
Custom. No default content.		
By default, the Maintenance menu is empty and the menu is not displayed until information is added to it.		

Accessing webpages for data viewing and meter configuration

You can access the meter's webpages through the meter's Ethernet connection using a web browser.

You must have cookies enabled to access your meter's webpages.

You may need to configure your meter's security settings to view webpages and configure your meter using webpages.

On a hardware-locked meter, you cannot add, delete, or modify any webpage files.

If you are connected to your device over Ethernet, changing Ethernet configuration parameters without another method of configuration enabled may cause loss of communications with your device and render it inaccessible.

NOTICE

LOSS OF ACCESS

Ensure you maintain sufficient access to communicate with and configure your device.

Failure to follow these instructions can result in loss of access to the device.

- 1. Open a web browser and enter your meter's IP address in the address bar. The webpage login prompt is displayed.
 - If the browser cannot connect to the webserver, check the web protocol setting.
- 2. Enter a valid username and password.

3. Select your desired Language from the drop-down list box, and click Log In.

Your meter's webpages are displayed. The default page is the **Monitoring** webpage, showing real-time data.

Select the main menu tab that corresponds to the category of information you want to view and select the webpage menu from the list.

The webpage content is displayed.

- 5. Click the webpage content headings to expand and view the meter's data.
- 6. Select **Setup** to view and edit your meter's configuration.

Embedding images and files in meter webpages

Upload images, documents, audio and video files to meter webpages using SFTP.

NOTE: Images cannot be scaled after they are uploaded. Format images to the desired size before uploading.

- 1. Access your meter's internal SFTP site.
- 2. Open the **web** folder. Copy your file into the subfolder that corresponds to the webpage main menu tab you want to access your file from.
- 3. Connect to your meter's webpages. Select the main menu item that corresponds to the folder you previously selected. Your file is listed in the webpage menu.
- 4. Select your file from the webpage menu to view it.

Creating custom webpages

Create custom webpages to view data or access configuration parameters from your meter.

Download the meter's Modbus registers map from www.se.com.

- 1. Open SFTP client software.
- 2. Go to **web > examples**. Select samplereadings.html to create a data value webpage or select sampleconfiguration.html to create a configuration parameters webpage.
- 3. Save a copy of the sample file. This filename is the webpage name.
- 4. Open your webpage in an HTML or webpage editor program.
- 5. Modify the webpage to reference the desired meter data or parameters from the Modbus registers map, and update the other fields where required.
- 6. Save your custom webpage.

The meter will display translated content if it exists in the meter's memory. If translated content is not available, English is displayed.

- 7. Connect to your meter's internal SFTP site.
 - If you have created a data viewing webpage, copy your custom webpage to web > monitoring.

- If you have created a configuration webpage, copy your custom webpage to web > setup.
- 8. Login to your meter's webpages.

Your custom webpage is available from the webpage menu under the **Monitoring** (data viewing) or **Setup** (configuration) tab.

Watch the video on how to create custom webpages: <u>How to Create Custom Webpages for Your Meter</u>

Deleting custom webpages

- 1. Open the SFTP client software.
- 2. Connect to the meter using the meter's IP address and SFTP port number. See "Protocols, ports, and connections" on page 75 for information on port numbers.
- 3. Open the web folder in SFTP file directory and delete all files in subfolders.
- 4. Close the SFTP client software.

Loading webpages using ION Setup

Prerequisites:

- Webpage files in the upgrade .zip folder. Go to www.se.com to download upgrade files.
- Meter connection using SFTP client application.

To load webpages using ION Setup:

- 1. Obtain the webpage upgrade files (.zip folder) that you want to upload onto your meter. Save the files where they can be accessed by the computer running ION Setup.
- 2. Start ION Setup.
- 3. Open the Setup Assistant for your meter.
- 4. Click Template > Web.

NOTE: You can preview meter webpages using the **Test Web Viewing** feature. Select an IP addressing method from the drop-down list box to generate a test link using your default web browser.

- 5. Click **Upload** to navigate to the folder (.zip) containing the meter upgrade files. Select the folder and click **Open**.
- 6. An ION Setup dialog box will open. Click Yes to confirm uploading of the webpage files.

NOTE: The upload process replaces files with matching filenames only.

Confirmation of uploaded files is displayed in the bottom status bar.

Loading webpages using SFTP

You can upgrade your meter's webpages using your meter's internal SFTP site.

Prerequisites:

- Your meter's webpage upgrade files. Go to www.se.com to download upgrade files.
- Access to your meter's internal SFTP site.

To load webpages using SFTP:

- 1. Connect to your meter's internal SFTP site and open the **web** folder.
- 2. Navigate to the location on your local machine where you saved the webpage .zip file.

NOTE: Extract the contents of the upgrade file.

Drag the resources and examples folders into the web folder. Confirm to overwrite existing files when prompted.

The files are transferred to the meter.

Sample data viewing webpage

You can create custom data viewing webpages using the sample webpage stored on your meter.

The sample webpages are stored in the **documents** folder on your meter's internal SFTP site.

Your meter's Modbus register map is available from www.se.com.

If required, your meter's ION handles document is packaged with the meter firmware file which is available for download from www.se.com.

The data viewing webpage must be stored on your meter's internal SFTP site in the **web/monitoring** folder. The custom webpage is viewed by selecting the **Monitoring** main menu tab on your meter's webpage.

Configuring the HTML code other than where described is an advanced procedure and should only be performed by those with an advanced understanding of webpages and how your meter processes them.

Sample webpage data viewing result

NOTE: The following graphic is representative only. Your meter's webpages may appear different than shown.



A HTML filename

B Content pane title

С	Row heading
D	Units
E	Column heading
F	Named register instantaneous value
G	Second content pane A title

Sample HTML code for data viewing webpage content

Content and formatting of a data viewing webpage is controlled by its HTML code.

Sample data viewing webpage content

```
SampleMonitorPane.html
1
2
      <div class="content-fit">
3
      <div class="accordion">
4
   <h3 target="sample-readings">$%localizedString(Basic Readings)#$</h3>
5
      <div id="sample-readings">
6
      7
        8
         
9
        $%localizedString(Minimum)#$
10
        $%localizedString(Present)#$
11
        $%localizedString(Maximum)#$
12
        13
        $%localizedString(I a)#$ <span unitsreg="I a"></span>
14
        15
        16
17
        18
        19
        20
        $\langle \langle \text{localizedString(I b)} #$ <\span unitsreg="I b"></span>
21
        22
        23
        24
        25
      26
      </div>
27
   <h3 target="sample-energy">$%localizedString(Energy Readings)#$</h3>
28
      <div id="sample-energy">
29
      30
        31
         
        $%localizedString(Present)#$
32
33
        34
        35
        $%localizedString(Active Energy)#$ <span unitsreg="kWh del-rec"></span>
36
        37
        38
        39
        $%localizedString(Reactive Energy)#$ <span unitsreg="kVARh del-rec"></span>
40
        41
        42
43
      </div>
44
      </div>
45
46
47
   <script type="text/javascript">
48
49
   instantaneousReadings.initInstantaneousReadings('sample-readings');
50
51
   </script>
   </div>
52
```

Sample webpage data viewing content description

Line #	Description
	SampleMonitorPane.html
1	The HTML filename, including the HTML extension (.html). This filename must comply with SFTP filename requirements (no spaces or special characters). The filename (without the HTML extension) is the name shown on the webpage menu.
	<h3 target="sample-readings"></h3>
4	This creates the first webpage content pane. "sample-readings" is the name of the webpage content. This name must be unique.
	\$%localizedString(Basic Readings)#\$
	Basic Readings is the title of the webpage content pane. This title is translated if possible.
5	<div id="sample-readings"></div>
5	This must match the name of the webpage content in line 4.
9	\$%localizedString (Minimum) #\$
9	Minimum is the heading for the first column. This heading is translated if possible.
10	\$%localizedString(Present) #\$
10	Present is the heading for the second column. This heading is translated if possible.
11	\$%localizedString(Maximum) #\$
	Maximum is the heading for the last column. This heading is translated if possible.
	\$%localizedString(I a) #\$
14	I a is the row heading. This heading is translated if possible.
14	<pre></pre>
	This displays the units that the meter has defined for the named register I a.
15	
15	This displays the instantaneous value of the named register I a mn.
16	
16	This displays the instantaneous value of the named register I a.
17	
17	This displays the instantaneous value of the named register I a mx.

Line #	Description
	\$%localizedString(I b) #\$
20	I b is the second row heading. This heading is translated if possible.
20	<pre></pre>
	This displays the units that the meter has defined for the named register I b.
21	
21	This displays the instantaneous value of the named register I b mn.
22	
22	This displays the instantaneous value of the named register I b.
23	
23	This displays the instantaneous value of the named register I bmx.
	<h3 target="sample-energy"></h3>
27	This creates the second webpage content pane. Sample-energy is the name of the webpage content. This name must be unique.
	<pre>\$%localizedString(Energy Readings)#\$</pre>
	Energy Readings is the title of the webpage content pane. This title is translated if possible.
28	<div id="sample-energy"></div>
20	This must match the name of the webpage content in line 27.
32	\$%localizedString(Present) #\$
32	Present is the heading for the last column. This heading is translated if possible.
	\$%localizedString(Active Energy) #\$
35	Active Energy is the row heading. This heading is translated if possible.
33	<pre></pre>
	This displays the units that the meter has defined for the named register kWh del-rec.
36	
	This displays the instantaneous value of the named register kWh del-rec. ¹
	\$%localizedString(Reactive Energy) #\$
39	Reactive Energy is the row heading. This heading is translated if possible.
	<pre></pre>
	This displays the units that the meter has defined for the named register kVARh del-rec.

Line #	Description
40	
40	This displays the instantaneous value of the named register kVARh del-rec.1
	<pre>instantaneousReadings.initInstantaneousReadings('sample-readings');</pre>
49	Sample-readings is the unique name of the first webpage content name. This HTML code updates all the webpage's values.

¹ Named registers are listed in the Modbus registers map. You can also reference a value by its ION handle using the following format: .

Sample setup webpage

You can create custom setup webpages using the sample webpage stored on your meter.

Sample webpages are stored in the documents folder on your meter's internal SFTP site.

Your meter's Modbus register map is available from www.se.com.

If required, your meter's ION handles document is packaged with the meter firmware file which is available for download from www.se.com.


Custom setup webpages must be stored on your meter's internal SFTP site in the **web/setup** folder. The custom webpage is viewed by selecting the **Setup** main menu tab on your meter's webpage.

Configuring the HTML code other than where described is an advanced procedure and should only be performed by those with an advanced understanding of webpages and how your meter processes them.

Sample webpage setup result

NOTE: The following graphic is representative only. Your meter's webpages may appear different than shown.





E Named register value

Second content pane title

Sample HTML code for setup webpage content

Content and formatting of a setup webpage is controlled by its HTML code.

```
Sample setup webpage content
   SampleSetupPane.html
 1
 2
 3
   <div class="content-fit">
 4
   <form id="formSampleSettings">
 5
 6
   <div class="accordion">
 7
   <h3 target="sample-basic">$%localizedString(Basic Settings)#$</h3>
   <div id="sample-basic">
 8
 9
   10
   11
    
12
    
13
   14
   $%localizedString(Ethernet)#$
15
16
    
17
   18
   19
   $%localizedString(MAC Address)#$
20
   21
   22
   23
   $%localizedString(Ethernet Device Name)#$
24
   <input name="Ethernet Device Name" type="text" />
25
   26
   27
   $\localizedString(IP Address)#$
28
   <input name="IP Address" type="text" />
29
   30
   31
   </div>
32
33
   <h3 target="sample-advanced">$%localizedString(Advanced Settings)#$</h3>
34
   <div id="sample-advanced">
35
   36
37
   38
    
39
    
40
   41
   $%localizedString(TCP Keep Alive Minutes)#$
42
   <input type="text" name="TCP Keep Alive Minutes" class="small" /> <span unitsreg="TCP Keep
43
   Alive Minutes"></span>
   44
45
   $%localizedString(Enable Web Server)#$
46
47
   <select name="Enable Web Server"></select> 
48
   49
   50
51
   </div>
52
   </div>
53
54
   <input type="submit" class="apply" value='$%localizedString(Apply)#$' />
55
```

```
56 |
    </form>
57
58
59
    <script type="text/javascript">
60
61
    SetupPane.init('formSampleSettings');
    formChangeDetection.initFormChangeDetection('#formSampleSettings', '#dialogFormChanges');
62
63
64
    </script>
65
    </div>
```

Sample setup webpage content description

Line #	Description
	SampleSetupPane.html
1	The HTML filename, including the HTML extension (.html). This filename must comply with SFTP filename requirements (no spaces or special characters). The filename (without the HTML extension) is the name shown on the webpage menu.
4	<form id="formSampleSettings"></form>
4	"formSampleSettings" is the name of the webpage content. This name must be unique
	<h3 target="sample-basic"></h3>
7	This creates the first webpage content pane. "sample-basic" is the name of the webpage content. This name must be unique.
	<pre>\$%localizedString(Basic Settings)#\$</pre>
	Basic Settings is the title of the webpage content pane. This title is translated if possible.
8	<div id="sample-basic"></div>
0	This must match the name of the webpage content in line 7.
15	\$%localizedString(Ethernet) #\$
13	Ethernet is the subheading. This heading is translated if possible.
19	\$%localizedString(MAC Address) #\$
19	MAC Address is the row heading. This heading is translated if possible.
20	
20	This displays the value of the read-only named register MAC Address.
23	\$%localizedString(Ethernet Device Name) #\$
23	Ethernet Device Name is the row heading. This heading is translated if possible.

Line #	Description
	<input name="Ethernet Device Name" type="text"/>
24	This displays the instantaneous value of the configurable named register Ethernet Device Name in a text-edit field.
	The type must match the named register type, in this case, an alphanumeric string.
0.7	\$%localizedString(IP Address) #\$
27	IP Address is the row heading. This heading is translated if possible.
	<input name="IP Address" type="text"/>
28	This displays the instantaneous value of the configurable named register IP Address in a text-edit field.
	The type must match the named register type, in this case, an alphanumeric string.
	<h3 target="sample-advanced"></h3>
34	This creates the second webpage content pane. Sample-advanced is the name of the webpage content. This name must be unique.
	\$%localizedString(Advanced Settings)#\$
	Advanced Settings is the title of the webpage content pane. This title is translated if possible.
25	<div id="sample-advanced"></div>
35	This must match the name of the webpage content in line 34.
40	\$%localizedString(TCP Keep Alive Minutes) #\$
42	TCP Keep Alive Minutes is the row heading. This heading is translated if possible.
	<input class="small" name="TCP Keep Alive Minutes" type="text"/>
	This displays the instantaneous value of the configurable named register TCP Keep Alive Minutes in a text-edit field.
43	The type must match the named register type, in this case, an alphanumeric string.
	
	This displays the units that the meter has defined for the named register TCP Keep Alive Minutes.
	NOTE: There are no defined units for TCP Keep Alive Minutes, so no units are displayed.
40	\$%localizedString(Enable Web Server)#\$
46	Enable Web Server is the row heading. This heading is translated if possible.
	<select name="Enable Web Server"></select>
47	Enable Web Server is the named register that is displayed. Named registers are listed in the meter's registers map.
	The type must match the named register type, in this case, an enumerated value that is displayed as a drop-down list box.

Line #	Description	
61	<pre>SetupPane.init('formSampleSettings');</pre>	
01	This must match the webpage content name from line 4.	
60	<pre>formChangeDetection.initFormChangeDetection('#formSampleSettings', '#dialogFormChanges');</pre>	
62	This must match the webpage content name from line 4. This HTML code updates all the webpage's values.	


Display

Display overview

The display allows you to view meter data and perform basic configuration.

NOTE: The display backlight dims after a defined period of inactivity. When the meter detects an unacknowledged active high priority alarm, the display flashes until the alarm is acknowledged.

Display



Α	Display port	K	Home button
В	Optional 24 V DC AUX power input (label not pictured)	L	Power/status LED, green or red
С	Date and time	М	Alarm LED, red
D	Mode indicator	N	VAR visible energy pulsing LED, orange
Е	Revenue lock icon	0	VAR infrared energy pulsing LED, 940 nm
F	Alarm icon	Р	Watt visible energy pulsing LED, orange
G	Touch-screen display	Q	Watt infrared energy pulsing LED, 940 nm
Н	USB ports cover	R	ANSI optical port
I	USB host port (Type A)	S	IEC optical port adapter (optional)
J	USB device port (Mini-B)		

Mode indicator

The display mode indicator identifies whether the meter is in normal (NORM), alternate display (ALT) or test (TEST) mode.

Home button

Press the Home button to access display menus or return to the active menu.

Press the Home button twice to access the last data screen displayed or the Summary screen, if in ALT mode.

The function of the home button varies:

- NORM mode: Displays Energy and Demand screens.
- ALT mode: Displays ALT mode display and setup menus. Select Normal Display Mode from the ALT display menu to exit the ALT display mode.
- TEST mode: Displays Test mode and Setup menus.
- · Setup Menu: Displays active menu item.

Revenue lock icon

The revenue lock icon indicates the lock status of the meter.

When gray and open, the meter is unlocked. When green and closed, the meter is locked. You can lock and unlock your meter using the revenue lock switch located on the body of your meter.

Alarm icon

The alarm icon indicates the highest level and state of alarms detected by your meter.

For example, if the meter detects a low priority and a high priority active alarm, the alarm icon indicates a high priority active alarm.

NOTE: Alarms can only be viewed and acknowledged through the display.

lcon	Description
	Active alarm indicator:
	Red: high priority alarm state detected
	Yellow: medium priority alarm state detected
	Blue: low priority alarm state detected
	The alarm indicator flashes until you acknowledge the alarm.
	The alarm indicator changes to the historic alarm indicator of the appropriate level when the alarm state is no longer detected by the meter.
	NOTE : The display backlight flashes for unacknowledged high priority active alarms.

Icon	Description	
	Unacknowledged historic alarm indicator:	
	Red: unacknowledged high priority historic alarm	
\wedge	Yellow: unacknowledged medium priority historic alarm	
4.4	NOTE: Low priority historical alarms are not indicated.	
	The active alarm indicator changes to the historic alarm indicator of the appropriate level when the alarm state is no longer detected by the meter.	
A	Gray: no active or unacknowledged high or medium priority historic alarms	

Alarm and status LED indicators

Your meter has alarm and status LEDs.

These LEDs cannot be configured for other uses.

LED	Description		
	Off: unpowered		
	Steady green: normal operation		
Status	Flashing red: no communications (remote display only)		
	Steady red: firmware upgrade required (remote display only)		
	Flashing red/green: startup or firmware upgrade sequence in progress		
Off: no active or unacknowledged historic alarms			
	On: acknowledged active alarm		
Alarm	Flashing: active alarm		
	NOTE : The display backlight flashes for unacknowledged high priority active alarms.		

Display icons

Icons are displayed on the bottom of the screen.

NOTE: If the icon is gray, the function is not available.

Icon	Description	
+	Tap More to access additional screens.	
<	Tap Left arrow to select item to the left or to return to the previous screen.	
>	Tap Right arrow to select item to the right.	
^	Tap Up to navigate menu items or screens.	

Icon	Description	
~	Tap Down to navigate menu items or screens.	
ਂ	Tap Select to confirm selection or change.	
8	Tap Cancel to exit and return to previous screen.	
Ш	Tap Graphic to view graphical representation of data.	
888	Tap Numeric to view numerical representation of data.	
•	Tap Info to display screen details.	
	Tap Edit to enter parameter values or select setting.	
\square	Tap Check Box to perform an action.	
○< >	Tap double-arrow to select parameter.	

More screens access

You can access additional screens.

Pressing the More icon opens a list of additional screens related to the active screen. Press **Cancel** to close the list. If you do not select a screen, you are returned to the last data screen displayed.

Overrange indication

If any value measured by the meter is too large to fit on the display, the meter initially reduces the size of the text to try and make the value fit.

If the value is still too large to be displayed, the meter truncates the value starting with the least significant digit and encloses the truncated value in a red box.

Interrupted display data

The meter updates the display data every second during normal operation.

If the display detects a data interruption, the following occurs:

- · Date/time information is cleared.
- Display mode indicator is set to normal (NORM) mode.
- · Revenue lock icon indicates a locked state (green and closed).
- Alarm icon indicates an unacknowledged high priority historic alarm (red outline bell).
- All parameter labels and associated parameter data are cleared.

Display screen title bar and display icons are retained.

Auto-scaling feature

Measurement units on the meter display and webpages automatically scale, depending on the value of PT Primary and CT Primary.

Voltage units are scaled based on the PT Primary value:

PT Primary value	Units or scaling
< 1000	V
1000–999,999	kV

Current units are scaled based on the CT Primary value:

CT Primary value	Units or scaling
< 1000	Α
1000–999,999	kA

Power units are scaled according to the value of (CT Primary x PT Primary x 3):

(CT Primary x PT Primary x 3) value	Units or scaling
< 1,000,000	kW, kVAR or kVA
1,000,000–999,999,999	MW, MVAR or MVA
≥ 1,000,000,000	GW, GVAR or GVA

Display screens

Display modes

Your meter has three display modes and provides access to your meter's setup screens:

- Normal Mode Screens (NORM) In Norm mode, your meter automatically scrolls through a
 series of customizable display screens. You can add or remove Norm mode display screens.
 If there are no Norm mode display screens, the meter displays a message stating that there
 are no available screens. To exit Norm mode, press the home button to access the display
 modes selection screen.
- Alt Display Mode (ALT) In Alt mode, you can navigate to view the different alternate screens. You cannot modify the default Alt mode display screens, but you can add custom screens. To exit Alt display mode, select Normal Display Mode to access the display modes selection screen.
- Test Mode (TEST) In Test mode, you can manually scroll through a series of default screens. To exit Test mode, press the home button and select Exit Test Mode.


NOTE: In Test mode, your meter's billing quantities stop accumulating and the data is sent to special test mode registers. These registers are cleared when you exit Test mode.

Access your meter's setup screens by pressing the home button in NORM, ALT or TEST mode. To exit the setup screens, press the home button.

Norm mode display menu

The Norm mode display screens show measured and calculated information about the power system being monitored.

NOTE: Your meter's menus may appear slightly different than shown depending on your display settings.



Alt mode display menu

The alt mode display menu allows you to view data screens and access the setup menu.

Alt mode data display screens

Your meter's default display screens show measured and calculated information about the power system being monitored.

NOTE: Minimum, maximum (peak), average and time of use (TOU) values are typically accessed by pressing More to open a list of additional screens.

Menu	Submenu	Content	
Summary	Summary	Power system summary	
Alarms	Active alarms,	Active alarms can be viewed and acknowledged.	
	Historical alarms	Historical alarms can be viewed and acknowledged.	
Basic readings	Voltage	Power system voltage (line-to-line or line-to-neutral),	
	Current	current and frequency values.	
	Frequency	 Average, minimum, and maximum values are also provided. 	
Power	Power summary	Per-phase and total kW, kVAR and kVA values, along with minimum and maximum values.	
	Demand	Delivered and received demand values including peak demand.	
	Power factor	Per-phase and total power factor along with minimum and maximum values.	

Menu	Submenu	Content	
Energy	Energy	Energy delivered-received, delivered and received.	
Events	Events	Meter event log entries listing and details.	
Power quality	EN50160	EN50160 values.	
	Harmonics	Voltage and current harmonics, with individual and total harmonic values.	
	Phasors	Phasor diagram with magnitude and angle values.	
Inputs/outputs	Digital inputs	Digital and analog I/O values and counts.	
	Digital outputs	_	
	Analog inputs	_	
	Analog outputs	_	
Nameplate	Nameplate	 Owner and tag information, meter model, and serial number. 	
		 Meter feature set, firmware version, and firmware CRC. 	
		 RMD serial number and firmware version. 	
		 Meter volts mode, meter nominals (voltage, current, and frequency), and PT/CT ratio. 	
		Demand configuration values.	
		Regulation tag.	
Custom screens	_	Custom screens	
Setup Menu	_	Access to the setup menu screens.	

Setup menu

Meter configuration can be performed through the display.

Configure your meter's security settings to allow front panel (display) programming to set up the meter using the display.

NOTE: Your display may appear differently than shown, depending on your meter's power system, configuration, and display settings.

NOTE: Some setup parameters cannot be configured when revenue security is enabled.

Menu	Submenu
Meter Setup	Volts Mode
	PT/CT Setup
	Voltage Polarity Setup
	Current Polarity Setup
	Nominal Values
Ethernet Port Enable Setup	Ethernet Port Enable Setup
Communications Setup	IPv4 Assignment Mode Setup
	Stored IPv4 Address Setup
	IPv6 Link Local Address
	IPv6 Assignment Mode Setup
	Stored IPv6 Global Address
	Ethernet Device Name
	DNS Setup
	COM1 Setup
	COM4 Setup
	NTP Address
	SMTP Address
Display Setup	Screen Setup
	Label & Symbol Setup
	Numeric Format Setup
Date/Time/Clock Setup	Date & Time Setup
	Clock Setup
Alarm Setup	Alarm Setup
Language Setup	Language Setup
Time of Use Setup	TOU Active Rates
	TOU Season
Resets	Resets

Meter setup using your display

Navigate to Setup screens and enter parameters to configure your meter.

Your meter's default display password is 0 (zero).

NOTE: Your meter locks you out of display configuration after you have exceeded the maximum number of attempts to enter a password.

The following example shows how to use the navigation icons to select parameters, enter numeric information or select parameter values from lists.

NOTE: Your display may appear differently than those shown, depending on your meter's power system and display and localization settings.

Example: Setting volts mode and PT/CT ratios


Use the display navigation icons to set your meter's volts mode and PT ratios.

NOTE: Potential transformers (PT) are also known as voltage transformers (VT).

1. Press to display the menu. Press until **Setup Menu** is highlighted. Press to display the Setup Menu. The Setup Menu lists the setup selections on your meter.



- 2. Press or to highlight the different setup menu selections. Highlight **Meter Setup** and press to select the meter setup screens. The **Volts Mode** setup screen is displayed.
- 3. Press to highlight **Volts Mode**. Press to edit the volts mode. The Enter Password screen is displayed.




4. Press to change the value of the highlighted digit (0 - 9). Press to go to the next digit.

Press to enter your password using the onscreen keyboard. The **Volts Mode** configuration screen is displayed.



5. Press or to highlight the desired volts mode from the list, in this case, 3W-WYE.

Press to select the highlighted volts mode. A confirmation screen is displayed, showing your meter's previous setting and newly selected setting.



6. Press


to confirm, and the new setting is applied to your meter. Press

to cancel and maintain your meter's original setting.



- 7. In the Volts Mode screen, press to go to the PT/CT Setup screen.
- 8. In the PT/CT Setup screen, press to highlight the potential transformer (PT) or current transformer (CT) value for editing. Press to edit the highlighted value.

NOTE: If you have exceeded the password timeout period, you are prompted to enter your meter's display password.



9. Press to change the value of the highlighted digit (0 - 9). Press to go to the next digit.

Press to enter the new value. When the confirmation screen is displayed, press to confirm the new value or to revert to the original value.

Display setup

You can configure basic display parameters using the display.

Screen setup

Parameter	Values	Description
Backlight Timeout	0–7200	Specifies how many seconds the display's backlight remains lit after the last button press

Label and symbol setup

Parameter	Values	Description
Phase Lbls	ABC, 123	Sets the voltage and current phase labels
Measurement Symbols	IEEE, IEC	Specifies whether IEEE or IEC measurement symbols are applied to displayed values
PF Convention	IEEE, IEC	Specifies whether IEEE or IEC power factor conventions are applied to displayed values

Numeric format setup

Parameter	Values	Description
Digit Grouping	1000.0, 1,000.0, 1 000,0	Specifies how digits are grouped for display
Volts Resolution	1., 1.X, 1.XX, 1.XXX, 1.XXXX	Specifies the number of decimal places displayed for voltages
Current Resolution	1., 1.X, 1.XX,1.XXX, 1.XXXX	Specifies the number of decimal places displayed for currents
Power Resolution	1., 1.X, 1.XX, 1.XXX, 1.XXXX	Specifies the number of decimal places displayed for power and energy measurements

Language setup

Set your meter display to one of the following languages:

- English (default)
- Spanish
- French
- Russian
- German
- Italian
- Portuguese
- Chinese (simplified)

Creating custom displays using ION Setup

Use ION Setup to create new custom displays.

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.

- 3. Click Displays > Front Panel.
- 4. Select Displays and click Edit.

ION Setup loads your meter's display information into the **Display Editor** screen.

- Select the display mode of the custom screens from the drop-down list box, and rename, delete, or change the order of custom displays.
 - a. Click **New** to add a new display screen in the selected display mode.
 - Click Edit to open the Display setup screen, where you can configure new or existing custom displays.
- 6. Configure your screen.
 - **Screen Type**: Specify the number of parameters displayed on the screen.
 - Screen Title: Enter the title to be shown at the top of your custom display.
- 7. Click **Edit** to select the displayed parameters.

The number of parameters displayed is determined in the **Screen Type** selection described above.

- 8. Select your digit display properties.
 - Resolution: Specifies the number of decimal places displayed.
 - Last Digit: Specifies if the last digit is rounded or truncated.
- 9. Click **Send** to save the changes in the meter.

Display units scaling

You can customize the units for metered values shown on the display and webpages.

You can configure the units for voltage, current, power and energy values shown on the display and webpages from their default units, and you can set the resolution for the display. To identify which values will have the modified units, refer to the display and web units information in your meter's Modbus map, available from www.se.com.

Configuring display units scaling using ION Setup

You can customize the units for metered values shown on the display and webpages using ION Setup.

Configuring display units scaling is an advanced procedure that requires in-depth knowledge of your meter, its underlying architecture, and the system in which it is installed.

To identify which values will have the modified units, refer to the display and web units information in your meter's Modbus map, available from www.se.com.

NOTE: Custom units and resolution settings are automatically adjusted for current and voltage values to help prevent the display from showing incorrect zero values.

- 1. Start ION Setup.
- 2. Connect to your meter in advanced mode.
- Navigate to the Display Options Modules folder and double-click on the module in the righthand pane.

The **Display Options** screen is displayed.

- 4. Select the **Setup Registers** tab.
- 5. Select the display units you want to configure: Voltage Units, Current Units, Power Units or Energy Units. Click **Edit**.

A unit selection screen is displayed.

- 6. Select the desired units from the drop-down list, and then click **OK**.
- 7. When you have finished configuring the display units, click **Send** to send your changes to the meter and close the Display Options screen.

For more information on the Display Options module and your meter's ION architecture, see *ION Reference*, available on www.se.com.

Remote display troubleshooting icons

The remote display shows troubleshooting icons in addition to the meter's status LED information.

Icon	Description
-W_	The display is connecting to your meter.
8	The display cannot communicate to your meter. Check the connection between your meter and the display. Check the meter's status LED to confirm that the meter is operating normally.
0	The display needs updated firmware for compatibility with your meter.
垦	The display is downloading a firmware upgrade. Do not disconnect the display from your meter.
\mathcal{Z}	The display is undergoing a firmware upgrade. Do not disconnect the display from your meter.

Alarms and alerts

Alarms

An alarm is the meter's means of notifying you when an alarm condition is detected, such as an error or an event that falls outside of normal operating conditions. Alarms are typically setpoint-driven and can be programmed to monitor certain behaviors, events, or unwanted conditions in your electrical system.

You can configure your meter to generate and display high, medium, and low priority alarms when predefined events are detected in the meter's measured values or operating states. Your meter also logs the alarm event information.

The meter ships with some alarms already enabled from the factory. Other alarms need to be configured before the meter can generate alarms.

Customize meter alarms as required, such as changing the priority. You can also create custom alarms using the advanced features of your meter.

Alarm types

Your meter has five types of alarms:

Alarm type	Description
Setpoint (standard)	Setpoint alarms compare the actual value of a parameter to a specified limit or range of values. These include measured voltage and current values and calculated power quality values.
	Some setpoint alarms use high-speed measurements for up to 1 millisecond resolution.
Digital	Digital alarms are triggered on a digital input's on/off state.
Disturbance (sag/swell)	Disturbance alarms are triggered on a measured sag or swell.
Transient	Transient alarms are triggered on a measured transient event.
Unary	Unary alarms are not configurable and generate an alarm based on the meter's state, for example, the meter powering up.

Alarms have two states:

Alarm state	Description
Active	The meter detects the alarm condition is met.
Historical	The alarm condition previously existed but the condition has since returned to a non-alarm state.

For more information on Setpoint, Relative Setpoint, Digital Input, Disturbance Analyzer, Transient, High-Speed Transient (ION9000T only), and Sag/Swell modules, see *ION Reference*, available on www.se.com.

Standard and high-speed alarms

Alarm speed is determined by the update rate of the framework for the particular alarm.

Standard alarm

Standard alarms have a detection rate of once every one second.

High-speed alarm

High-speed alarms have a detection rate of once every half-cycle.

3-phase alarms

Alarms on 3-phase systems are evaluated per phase and reported for each phase.

Some alarms, such as the sag/swell alarm, are evaluated per phase, but reported as a single alarm: Each of the three phases are evaluated for the setpoint condition individually, but there is only one alarm generated. The alarm pickup occurs when the first phase exceeds the alarm pickup magnitude for the pickup time delay. The alarm is active as long as any phase remains in an alarm state. The alarm dropout occurs when the last phase drops below the dropout magnitude for the dropout time delay.

Over and under setpoint (standard) alarm operation - Example


The meter supports over and under setpoint conditions on standard alarms.

A setpoint condition occurs when the magnitude of the signal being monitored crosses the limit specified by the pickup setpoint setting and stays within that limit for a minimum time period specified by the pickup time delay setting.

The setpoint condition ends when the magnitude of the signal being monitored crosses the limit specified by dropout setpoint setting and stays within that limit for a minimum time period specified by dropout time delay setting.

Over setpoint

When the value rises above the pickup setpoint setting and remains there long enough to satisfy the pickup time delay period (Δ T1), the alarm condition is set to ON. When the value falls below the dropout setpoint setting and remains there long enough to satisfy the dropout time delay period (Δ T2), the alarm condition is set to OFF.




Α	Pickup setpoint
В	Dropout setpoint
ΔΤ1	Pickup time delay period (in seconds)
EV1	Start of alarm condition
ΔΤ2	Dropout time delay (in seconds)
EV2	End of alarm condition
ΔΤ3	Alarm duration (in seconds)
Max1	Maximum value recorded during pickup period
Max2	Maximum value recorded during alarm period

The meter records the date and time when the alarm event starts (EV1) and when it ends (EV2). The meter also performs any task assigned to the event, such as operating a digital output. The meter also records maximum values (Max1, Max2) before, during or after the alarm period.

Under setpoint

When the value falls below the pickup setpoint setting and remains there long enough to satisfy the pickup time delay period (Δ T1), the alarm condition is set to ON. When the value rises above the dropout setpoint setting and remains there long enough to satisfy the dropout time delay period (Δ T2), the alarm condition is set to OFF.



Α	Pickup setpoint
В	Dropout setpoint
ΔΤ1	Pickup time delay period (in seconds)
EV1	Start of alarm condition
ΔΤ2	Dropout time delay (in seconds)
EV2	End of alarm condition
ΔΤ3	Alarm duration (in seconds)
Min1	Minimum value recorded during pickup period
Min2	Minimum value recorded during alarm period

The meter records the date and time when the alarm event starts (EV1) and when it ends (EV2). The meter also performs any task assigned to the event, such as operating a digital output. The meter also records minimum values (Min1, Min2) before, during or after the alarm period.

Relative setpoint

The meter's Relative Setpoint modules behave similarly to the Setpoint modules, except the pickup and dropout levels are set relative to the *Nominal* input source.

For more information on Relative Setpoint modules, see *ION Reference*, available on www.se.com.

Sag/swell alarms

Your meter monitors your power system's voltage and current for sags and swells.

When sag/swell limits are defined and alarming is enabled, the meter reports the disturbance's magnitude and duration, and logs data and waveform records associated with the disturbance.

You must configure nominal voltage and current for these alarms to function.

You can manually enter the limits (criteria) used by the meter to identify a sag or swell, or you can have your meter learn sag/swell limits by monitoring your power system.

For more information on the Sag/Swell and Disturbance Analyzer modules, see *ION Reference*, available on www.se.com.

Digital alarms

These alarms are triggered when the associated digital input changes state.

You can configure the alarm to be active when the digital input is on or off, depending on the alarm's purpose.

For example, if you used a digital input to monitor a breaker that is always supposed to be on, you would set the alarm to be active when the breaker has tripped.

NOTE: To stop a digital alarm from being displayed, set the alarm priority to **Info Only**. Disabling the digital alarm will disable all alarming functions of the associated digital input.

For more information on the Digital Input module, see ION Reference, available on www.se.com.

Transient alarms

Transient alarms are triggered by voltage transient activity (for example, ITI CBEMA Type 1 disturbances).

You must configure nominal voltage for these alarms to function.

The *Threshold* setup register in the Transient module defines what voltage disturbance magnitude should be considered as transient activity. Threshold is interpreted as a percentage of the nominal system voltage, plus 100. For example, if you want transients recorded when voltage deviates from nominal by 20%, enter 120 into the *Threshold* setup register.

For more information, see "Transients" on page 202.

For more information on the Transient module, see ION Reference, available on www.se.com.

Alarm event priorities

Your meter's alarm priorities correspond to event priority ranges.

Alarm priority	Event priority
High (red)	192–255
Medium (yellow)	128–191
Low (blue)	64–127
Info Only (no alarm)*	1–63
None (no alarm or event)*	0

^{*} Alarms with priority of **Info Only** or **None** are not indicated or displayed.

Info Only and None event priority

Alarms with a priority of **Info Only** or **None** are not shown on the meter's display, and do not function as alarms. If the alarm's priority is set to **Info Only**, and the event priority is greater than the event log cutoff value, the associated event is recorded in the meter's event log. If the alarm's

priority is set to **None**, the event priority is automatically set to zero, and no associated event is logged in the meter's event log.

For events that you want to log for future reference or troubleshooting, but don't want alarm functions, set the alarm priority to **Info Only**.

For nuisance events that frequently occur, and you have no desire to log for reference or troubleshooting, set the alarm priority to **None**.

Alarm indicators

Your meter's display has an alarm indicator to show you what alarm levels have been detected (active or historic) and whether they have been acknowledged.

For active high priority alarms, the display will also flash until the alarm is acknowledged. There is also an alarm LED to indicate the meter's alarm condition.

Alarm	Alarm icon	Alarm icon flash	Alarm LED	Display
Active high	Red solid bell	Flash if not acknowledged	Flash if not acknowledgedSteady if acknowledged	Flash if not acknowledged
Active medium	Yellow solid bell	Flash if not acknowledged	Flash if not acknowledgedSteady if acknowledged	No flash
Active low	Blue solid bell	Flash if not acknowledged	Flash if not acknowledgedSteady if acknowledged	No flash
Historic high	Red outline bell	Flash if not acknowledged	Flash if not acknowledgedSteady if acknowledged	No flash
Historic medium	Yellow outline bell	Flash if not acknowledged	Flash if not acknowledgedSteady if acknowledged	No flash
Historic low	Gray solid bell	No flash	Off	No flash
No active or unacknowledged alarms	Gray solid bell	No flash	Off	No flash

If there are multiple active alarms, the alarm condition associated with the highest priority is displayed. If there are multiple unacknowledged historic alarms, the meter displays the alarm condition associated with the highest priority unacknowledged historic alarm.

NOTE: To stop an alarm from being displayed without impacting other metering features, set the alarm priority to **Info Only**.

Default alarms

Your meter comes with default alarms. Some alarms are enabled by default.

NOTE: Some alarms require configuration to operate.

Name	Priority	Description	Default
Current Sag Ph1 - 3	High	Current sag alarms for phase 1, 2, 3	Disabled
Current Swell Ph1 - 3	High	Current swell alarms for phase 1, 2, 3	Disabled
Sag/Swell	High	Voltage sag/swell alarm	Disabled
Over I unbal	Medium	Over unbalanced current alarm	Disabled
Over V unbal	Medium	Over unbalanced voltage alarm	Disabled
Over THD V1 - 3	Medium	Over total harmonic distortion (THD) voltage alarms	Enabled
Over kW (P) sd	Medium	Over kW sliding demand alarm	Disabled
Over I a - c, (1 - 3) 4	Medium	Over current alarms	Disabled
V1 - V3 Setpoint	Medium	Voltage setpoint alarms	Disabled
Freq Setpoint	Medium	Frequency setpoint alarm	Enabled
4-30 Volt Intrp Ph1 - 3	Low	4-30 voltage interruption power quality alarms	Enabled
Transient/Waveshape	High	Transient alarm	Disabled
High-speed Transient (ION9000T only)	High	High-speed transient alarm	Disabled
		Digital input alarms	
Digital In	Info Only	Number of alarms determined by the total number of available digital inputs Note: Info Only alarms are not displayed.	Enabled

Alarm information

You can view information about an alarm from your meter's display.

Only alarms with a priority of low, medium, or high are displayed.

Parameter	Description
Alarm	The name of the alarm (for example, Over THD V1).
Priority	Low, medium, or high alarm priority.
Date	The date and time the alarm was triggered.
Duration	The duration of the alarm (only applies to inactive alarms).
Ack	The date and time when the alarm was acknowledged (only applies to acknowledged alarms).
Value	Active alarm: The minimum or maximum value detected when the alarm was triggered.
value	Historic alarm: The minimum or maximum value detected during the duration of the alarm.

Viewing and acknowledging alarms using the display

To view and acknowledge alarms using the display:

- 1. Press the **Home** button on the display.
- 2. Press Alarms > Active Alarms or Historical Alarms.
- 3. Press Select.
- 4. Press the up or down icons to navigate alarms. A gray bar appears behind the active selection.

NOTE: You can press **Info** to display alarm details.

5. To acknowledge alarms press Acknowledge All.

Alarm configuration

Topics in this section:

Alarm setup using the display

You can enable and disable alarms through the display.

WARNING

INACCURATE DATA RESULTS

- Do not use data displayed on the display or in software as a substitute for proper workplace practices or equipment maintenance.
- · Confirm your alarm is properly configured.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Default alarms available on the display

Parameter*	Description
Over I unbal	Over unbalanced current alarm
Over THD V1	V1 over total harmonic distortion (THD) voltage alarm
Over THD V2	V2 over total harmonic distortion (THD) voltage alarm
Over THD V3	V3 over total harmonic distortion (THD) voltage alarm
Over kW sd	Over kW sliding demand alarm
Over la	la over current alarm
Over Ib	lb over current alarm
Over Ic	Ic over current alarm
Over I4	I4 over current alarm
Over V unbal	Over unbalanced voltage alarm
V1 Setpoint	V1 setpoint alarm
V2 Setpoint	V2 setpoint alarm
V3 Setpoint	V3 setpoint alarm
Freq Setpoint	Frequency setpoint alarm
Sag/Swell 1	Voltage sag/swell alarm
Current Sag Ph1**	Current sag alarms for phase 1
Current Sag Ph2**	Current sag alarms for phase 2
Current Sag Ph3**	Current sag alarms for phase 3
4-30 Volt Intrp Ph1	4-30 voltage interruption power quality alarm for phase
4-30 Volt Intrp Ph2	4-30 voltage interruption power quality alarm for phase 2
4-30 Volt Intrp Ph3	4-30 voltage interruption power quality alarm for phase 3
Current Swell Ph1**	Current swell alarms for phase 1
Current Swell Ph2**	Current swell alarms for phase 2
Current Swell Ph3**	Current swell alarms for phase 3
HSTC 1 (ION9000T only)	High-speed transient alarm

^{*} Any Setpoint or Relative Setpoint module with an event priority greater than or equal to the Low alarm event priority is also displayed on this screen.

NOTE: Configuring alarms must be done using ION Setup.

^{**} Enabling or disabling one phase for each alarm type will enable or disable all phases for that type.

Alarms with a priority less than Low (Info Only or None) are not displayed.

You must configure all the parameters related to the alarm for alarm functions to operate. For example, for the Over Ia alarm to operate, you must enter the nominal value and the conditions that define an alarm state, even if the alarm is shown as Enabled on the Alarm Setup screen.

Disabling and enabling alarms using the display

Disable alarms using the display when you are performing maintenance tasks on your system and want to prevent nuisance alarms.

NOTE: To stop an alarm from being displayed without impacting other metering features, set the alarm priority to **Info Only**.

To disable alarms using the display:

- 1. Press the **Home** button on the display.
- 2. Press Setup Menu > Alarm Setup.
- 3. Press Select.
- 4. Press Edit. Enter your meter's password, if prompted.
- 5. Press the up or down icons to navigate alarms. A gray bar appears behind the active selection.
- 6. To select the item(s) press Select for Enable/Disable.
- 7. Press **Select** to accept the change.
- 8. Press Select to confirm.
- 9. Complete the system maintenance tasks.
- 10. Enable the alarms you disabled.

Configuring setpoint/standard alarms using ION Setup

To configure standard alarm settings using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Alarming > Standard.
- 4. Select a setpoint and click Edit.
- 5. Enter the password and click **OK**, if required.

The **Setpoint Setup** screen is displayed.

- 6. Configure the setpoint values as required.
- 7. Click **Save** to save the settings to your meter.

Parameter	Value/Range	Description
By Percentage	By Percentage/By Value	When available, specifies if the Pickup and Dropoff entries are by percentage or by value. If the option is not available, pickup and dropoff entries are by value.
		Forcing the alarm off disables all functions of the associated input.
Disabled/Enabled	Checked/Unchecked	To stop an alarm from being displayed without affecting other meter features, set the alarm priority to Info Only.
Label	String value	When available, lets you modify the default label so it more clearly identifies the alarm. Letters, numbers, and underscores are permitted.
Pickup	Numeric value	Use this setting to provide a value for when the alarm turns on.
Pickup Delay	Numeric value	This specifies the number of seconds the input must be over the alarm pickup value before the alarm turns on.
Dropout	Numeric value	Use this setting to provide a value for when the alarm turns off.
Dropout Delay	Numeric value	This specifies the number of seconds the input must be below the alarm dropoff value before the alarm turns off.
Alarm Priority	None, Info Only, Low, Medium or High	Specifies the priority level of the standard alarm. When priority is set to Info Only, the alarm does not appear on the display.
Custom Priority	0–255	Select custom priority to view and configure the event priority of the event associated with the alarm. The event log cutoff value is displayed for reference; priorities above the cutoff are stored in the meter's event log.

Sag/swell overview

Your meter monitors your power system's voltage and current for sags and swells (INCITS (CBEMA) Type 2 and Type 3 disturbances).

When sag/swell limits are defined and alarming is enabled, the meter reports the disturbance's magnitude and duration, and logs data and waveform records associated with the disturbance.

You can manually enter the limits (criteria) used by the meter to identify a sag or swell, or you can have your meter learn sag/swell limits by monitoring your power system.

Configuring sag/swell alarms using ION Setup

To configure sag/swell alarm settings using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Alarming > Sag/Swell.
- 4. Select the parameter you want to configure and click Edit.

The setup dialog box for that parameter appears.

5. Configure the parameters as required.

The values you need to set vary depending on the type of sag/swell alarm you are configuring.

Voltage sag/swell setup parameters

Parameter	Value/Range	Description
Enable/Disable	Enabled or Disabled	Specifies if sag/swell recording and alarming is enabled.
Nominal	1–999,999	The primary RMS voltage for the power system. Use the line-to-line voltage for a Delta configured device and line-to-neutral voltage for a Wye configured device.
		For more information on configuring Volts Mode, see "Configuring metering parameters" on page 71.
Swell Limit	Percentage of nominal	Specifies the swell limit expressed as a percentage of the nominal voltage.
Sag Limit	Percentage of nominal	Specifies the sag limit expressed as a percentage of the nominal voltage.
Hysteresis	Percentage – see description	Specifies the difference in magnitude between the sag or swell limit and the threshold for the power quality event to be considered over.
		For example, if the meter has the sag limit set to 90% of nominal and the hysteresis is set to 2%, this means that in a sag event, the voltage needs to return to 92% of nominal for the sag event to be considered over
Alarm priority	See description	Select the alarm priority you want to associate with Sag/Swell alarms.
Alarm priority		To stop an alarm from being displayed without affecting other meter features, set the alarm priority to Info Only.

Current sag/swell setup parameters

Parameter	Value/Range	Description
Enable/Disable	Enabled or Disabled	Specifies if sag/swell recording and alarming is enabled.
Nominal	1–999,999	Specifies the nominal current value used for current sag or current swell detection.

Parameter	Value/Range	Description
Pickup	Percentage of nominal	Specifies the percentage the current must deviate from the nominal current to be classified as a sag or a swell.
Dropout	Percentage of nominal	Specifies the percentage of nominal to which the current must recover to signal the end of the sag or the swell.
Hysteresis	N/A	Displays the difference in magnitude between the sag or swell Pickup and Dropout values.
		To change the hysteresis, change the Pickup or Dropout values.
Alarm priority	See description	Select the alarm priority you want to associate with Sag/Swell alarms.
		To stop an alarm from being displayed without affecting other meter features, set the alarm priority to Info Only .

Configuring transient alarms using ION Setup

To configure transient alarm settings using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Alarming > Transient.
- 4. Select **Transient/Waveshape** and click **Edit**.

The setup dialog box for that parameter appears.

5. Configure the parameters as required.

Transient setup parameters

Parameter	Value/Range	Description
Enabled/Disabled	Enabled or Disabled	Specifies if transient recording and alarming is enabled.
Nominal	1–999,999	Specifies the nominal voltage value used for transient detection.
Throshold	Percentage of nominal	Specifies the threshold expressed as a percentage of the nominal voltage, plus 100.
Threshold		For example, if you want transients recorded when voltage deviates from nominal by 20%, enter 120.
		Select the alarm priority you want to associate with Transient alarms.
Alarm priority	See description	To stop an alarm from being displayed without affecting other meter features, set the alarm priority to Info Only.

Configuring digital input alarms using ION Setup

To configure digital alarm settings using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Alarming > Digital Input.
- 4. Configure the digital input alarm settings by selecting an input and clicking **Edit**. Some settings are not configurable and are grayed out.
- 5. Click **Save** to save the changes to the meter.

Parameter	Value/Range	Description
		Specifies the input state/alarm behavior:
Input	Input On/Input Off	 Input On: the alarm is on when the digital input is on.
		 Input Off: the alarm is on when the digital input is off.
		Disable or enable the associated alarm.
Disable/Enable	Checked/Unchecked	To stop an alarm from being displayed without affecting digital input features, set the alarm priority to Info Only.
Label	String value	When available, lets you modify the default label so it more clearly identifies the alarm. Letters, numbers, and underscores are permitted.
Alarm Priority	None, Info Only, Low, Medium, or High	Specifies the priority level of the digital input alarm. To disable the alarm, set priority to Info Only.
Custom Priority	0–255	Select custom priority to view and configure the event priority of the event associated with the alarm. The event log cutoff value is displayed for reference; event priorities above the cutoff are stored in the meter's event log.

Alerts

An alert is an external notification from the meter to indicate changes, for example, a change of state for a digital input, or a power quality event such as a sag or swell.

When an alert condition occurs, a pulse or trigger is sent and generates the alert. You can configure alerts to send notification emails or messages to your energy management system through your meter's existing Ethernet communications connections. You can configure alert messages as a simple text string or you can also include device information. You can configure the alert's priority so that alerts are also recorded in the meter's event log.

You can configure multiple alerts on a single meter, each having different activation triggers, messages and/or transmission types. For instance, you can have two alerts, one generating an email, the other sending a message to your energy management system, but using the same

trigger conditions; or you can have two alerts with different conditions that send two unique emails to two different email addresses. You can also generate alerts based on triggers from devices connected to your meter.

Creating alerts is an advanced feature that requires familiarity with ION architecture and your power system and communications network. To create an alert, you must configure the Alert module using a configuration tool. You must also configure your device's communications as needed to send the alerts, such as configuring your meter's SMTP settings and connecting it via Ethernet to an SMTP mail server in order to send an alert by email.

For more information, see the ION Meter Alerts technical note, available on www.se.com.

Setpoint learning

Your meter can learn acceptable ranges or thresholds by monitoring normal operating values to determine what constitutes a voltage sag, swell or transient to help identify high and low setpoints.

NOTE: To help your meter learn the most accurate values possible, it is important that learning occur during a period of normal operation. Do not schedule learning during a period of unusual operations in your system. Do not modify your meter's configuration during the learning period as it may stop the learning process.

You can configure the meter so that learned values are applied automatically after the learning period is complete or require that they are reviewed and manually applied. If a learned value is invalid, the learned values are not automatically applied, but logged for review.

Setpoint learning can be used to identify the following values:

Feature	Values
	High limit
Satrainta (Alarma)	Low limit
Setpoints (Alarms)	Sustain until ON
	Sustain until OFF
Sag	Voltage sag limit
Swell	Voltage swell limit
Transient	Threshold

Learning installation mode and learning duration

You can configure learning for manual or automatic mode.


There are two learning installation modes:

- Manual: The meter learns the applicable values but does not begin using the learned values. The learned values are recorded for review, and you can decide to use the learned values or adjust them as required before manually implementing the learned values.
- 2. **Automatic:** The meter learns the applicable values and begins using those learned values automatically at the end of the learning period. If a learned value is invalid, the meter does not apply the value, but the value is recorded in the event log.

You can configure the maximum learning duration. The actual learning duration may vary, depending on the stability of the system. If the system is stable for a period equal to one quarter of the maximum learning duration, learning is complete; otherwise, the learning period will be the maximum learning duration.


Example: Setpoint learning duration in a stable system

In this example, the learning duration is 30 days. When the system is stable for 7.5 days (one quarter of 30 days) learning is complete.



Example: Setpoint learning duration in an unstable system

In this example, the learning duration is 30 days. Because the system is not stable for 7.5 days (one quarter of the 30 days) learning is complete at the end of the maximum learning duration.



For more information on Sag/Swell, Setpoint, and Relative Setpoint modules, see *ION Reference*, available on www.se.com.

Implementing standard alarm setpoint learning using ION Setup

You can use ION Setup to implement setpoint learning, which analyzes your power system and recommends settings.

NOTE: To learn valid setpoint values the meter's power system must be stable.

To implement setpoint alarm setpoint learning using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Alarming > Standard.

NOTE: You can manually configure setpoint values by selecting the setpoint and clicking **Edit**.

4. Select a setpoint and click Learn.

The Global Setpoint Learning screen is displayed.

- 5. Select the setpoint tabs to view existing configured or learned setpoint information.
- 6. Click Setup.

The Alarm Learning Setup screen is displayed.

Setpoint learning parameters

	01	
Parameter	Value/Range	Description
Install mode	Automatic, Manual	 Automatic: The learned values are automatically applied. Manual: The learned values are stored for you to review and enter.
Duration	1–365	Days for maximum learning duration.

- 7. Configure the learning parameters for each setpoint and click Save.
- 8. Click **Start All** to begin setpoint learning for all setpoints. Click **Yes** to confirm or **No** to cancel.
 - Learning status and time remaining are indicated in the Learning Status box.
 - Click **Abort** to stop learning for a specific setpoint. To stop all setpoint learning, repeat for each setpoint tab.
- 9. Apply the learned setpoint values:
 - Automatic: The setpoint values are automatically applied unless the learning process has issues or the learned values are invalid.
 - Manual: Navigate to Alarming > Setpoints, and then click Learn. On each setpoint
 tab, click Install to apply the learned values to that setpoint.

NOTE: If you click **Install** while learning is in progress (in either manual or automatic installation mode), it stops the learning process and prompts you for confirmation that you want to stop learning and install the learned values. Once you confirm, the learned values are automatically installed or prepared for manual installation.

Implementing sag and swell limit learning using ION Setup

You can use ION Setup to implement voltage sag/swell learning, which analyzes your power system and recommends settings.

NOTE: Your meter's power system must be stable to learn valid sag/swell limits.

NOTE: Learning is not supported for Current Swell and Current Sag.

To implement sag/swell limit learning using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Alarming > Sag/Swell.
- 4. Select Voltage and click Learn.

NOTE: You can manually configure the limit values by selecting the parameter and clicking **Edit**.

The Global Setpoint Learning screen is displayed.

5. Click Setup.

The Alarm Learning Setup screen is displayed.

Sag/swell limit learning parameters

eag. on on mine tour ming parameters		
Parameter	Value/Range	Description
Install mode	Automatic, Manual	 Automatic: the learned values are automatically applied. Manual: the learned values are stored for you to review and enter.
Duration	1–365	Days for maximum learning duration.

- 6. Configure the sag/swell limit learning parameters and click **Save**.
- 7. Click **Start** to begin sag/swell limit learning.
 - Learning status and time remaining are indicated in the Learning Status box.
 - Click Abort to stop sag/swell limit learning.
- 8. Apply the learned sag/swell limits.
 - Automatic: the limits are automatically applied unless there are issues with the learning process.
 - Manual: navigate to Alarming > Sag/Swell. Select Voltage and click Learn. Click Install to apply the learned limits.

NOTE: If you click **Install** while learning is in progress (in either manual or automatic installation mode), it stops the learning process and prompts you for confirmation that you want to stop learning and install the learned limits. Once you have confirmed, the learned limits are automatically installed or prepared for manual installation.

Implementing transient learning using ION Setup

You can use ION Setup to implement voltage transient learning, which analyzes your power system and recommends settings.

NOTE: Your meter's power system must be stable to learn valid transient thresholds.

To implement transient learning using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Alarming > Transient.
- 4. Select Transient/Waveshape and click Learn.

The Global Setpoint Learning screen is displayed.

5. Click Setup.

The Alarm Learning Setup screen is displayed.

- 6. Configure the transient threshold learning parameters and click Save.
- 7. Click **Start** to begin transient learning.
 - Learning status and time remaining are indicated in the Learning Status box.
 - Click Abort to stop transient learning.
- 8. Apply the learned values.
 - Automatic: the threshold is automatically applied unless there are issues with the learning process.
 - Manual: Click Alarming > Transient. Select Transient/Waveshape and click Learn.
 Click Install to apply the learned values.

NOTE: While learning is in progress (in either manual or automatic installation mode), it stops the learning process and prompts you for confirmation that you want to stop learning and install the learned limits. Once you have confirmed, the learned values are automatically installed or prepared for manual installation.

Transient learning parameters

Transfer four mig parameters		
Parameter	Value/Range	Description
Install mode	Automatic, Manual	Automatic: the learned values are automatically applied.Manual: the learned values are stored for you to
		review and enter.
Duration	1–365	Days for maximum learning duration.

Power quality

Your meter measures voltage and current harmonics, and calculates several harmonic distortion values, including K-factor and crest factor.

Configure your meter with the power system's nominal values for voltage, current, and frequency for the meter to perform power quality calculations.

Power quality configuration

Use ION Setup to configure sag/swell, transient and advanced power quality logging.

NOTE: For waveform recording to trigger automatically, enter your system's nominal (normal) voltage and current values and the amount of deviation from the nominal that is considered a sag or a swell using the **Metering > Basic** or **Alarming** screen

NOTE: Changing your meter's data logging (including burst data logging) and waveform recording configuration clears your meter's existing data logs, waveform records and COMTRADE waveform files.

Before setting up the Power Quality (PQ) parameters, make sure the meter is configured correctly:

- Metering parameters such as volts mode and PT/CT ratios
- Time sync settings, for integrating the meter in an energy management system such as EcoStruxure™ Power Monitoring Expert
- Nominal system parameters (nominal volts, nominal current and nominal frequency), for detecting power quality events
- Amount of deviation from the nominal that is considered a sag or swell

Make sure you understand:

- The structure of the meter's logging framework
- The meter's existing logging configuration
- Your data logging requirements

Changing the meter's data recorder and waveform recorder configuration clears existing data and waveforms in those recorders.

NOTICE

DATA LOSS

Ensure that all important data and waveforms have been recorded before configuring the data and waveform recorders.

Failure to follow these instructions can result in data loss.

Power quality logging

Sags and swells

Your meter monitors your power system's voltage and current for sags and swells (INCITS (CBEMA) Type 2 and Type 3 disturbances).

When sag/swell limits are defined and alarming is enabled, the meter reports the disturbance's magnitude and duration, and logs data and waveform records associated with the disturbance.

Configuring sag and swell logging

Use ION Setup to configure your meter to log data and waveform records related to sag/swell events, and to export the waveform data to COMTRADE files.

There are two data recorders for logging sag/swell related data:

- Sag/Swell Log (Data Rec 5) records data for plotting the ITIC (CBEMA) curve.
- Sg/Sw HS Log (Data Rec 6) records voltage and current data from the High-Speed Power Meter module.

To configure the Sag/Swell Log, Sg/Sw HS Log, Sag/Swell Waveform Log, and Sag/Swell COMTRADE files:

- 1. Start ION Setup.
- 2. Open the Setup Assistant for your meter.
- 3. Click Power Quality > Sag/Swell Logging.
- 4. Select the data log and click Edit.
- 5. Enter the meter password, if prompted.

The Sag/Swell Logging Wizard appears.

- 6. The **Device setting verification** screen shows results of the meter configuration check for possible errors related to sag/swell monitoring and reporting. Click **Fix** to view details or click **Next** to ignore the results and proceed to the next screen.
- 7. The **Disturbance Logging Setup** screen displays the **Log Depth** setting for the Sag/Swell Log (Data Rec 5). (Optional) Change the maximum number of records to store in this log.
- 8. Click Next.
- 9. The **High Speed Recording** screen displays the settings for the high-speed Sag/Swell data recorder (Sg/Sw HS Log Data Rec 6). Configure these settings for the meter to perform burst data logging.

Parameter	Description	Notes
Enable Burst Data	Select or clear this check box to	
Logging	turn burst data logging on or off.	-

Parameter	Description	Notes
Pre-trigger recording	Specifies, in seconds, how many pre-event records to capture. The actual number of records set in the high-speed Sag/Swell data recorder's <i>Pre-trigger Records</i> setup register = (2 x system frequency) x (number of seconds).	If system frequency is changed, the recording duration for Pretrigger recording and Post-trigger recording automatically adjusts to reflect the new frequency setting.
Post-trigger recording	Specifies, in seconds, how many post-event records to capture. The actual number of records set in the high-speed Sag/Swell data recorder's <i>Post-trigger Records</i> = (2 x system frequency) x (number of seconds).	If system frequency is changed, the recording duration for Pretrigger recording and Post-trigger recording automatically adjusts to reflect the new frequency setting.
Total # of recordings	Specifies how many burst data log sets to save in long-term memory (NVRAM). The actual number of records is configured in the high-speed Sag/Swell data recorder's <i>Depth</i> setup register = (Total # of recordings) x (<i>Pre-trigger Records</i> + <i>Post-trigger Records</i> + 1). For details on how a data log set is calculated, see "Data recorder burst data" on page 217.	When burst data logging is enabled, the equivalent number of records for 2 burst data log sets is allocated in short-term memory (RAM). The actual number of records set in the high-speed Sag/Swell data recorder's <i>Buffer Depth</i> setup register = 2 x (<i>Pre-trigger Records</i> + <i>Post-trigger Records</i> + 1).

10. Click Next.

11. Use the **Waveform Log Setup** screen to configure the waveform recorder for Standard or Delayed waveform capture.

NOTE: The **Sag/Swell Logging Wizard** does not support Extended waveform capture. For more information on Standard, Delayed, and Extended waveform capture, see "Waveform capture" on page 218.

Parameter	Description
Waveform Depth	Specifies the maximum number of waveform records stored on the meter.
Waveform Format	Specifies the number of samples per cycle and the number of cycles that are stored in a waveform record.

Parameter	Description
Trigger Position	Specifies the number of cycles to capture before the waveform versus after the waveform. Trigger position can be set using the pre-cycle arrows or the slider bar.

NOTE: The maximum number of cycles (pre-event + post-event) cannot exceed the total number of cycles in the waveform format.

12. Click Next.

- 13. Configure your meter's COMTRADE settings:
 - Select or clear the Generate COMTRADE files checkbox to enable or disable the creation of COMTRADE records.

NOTE: The waveform viewer on your meter's webpages uses the meter's COMTRADE files. If you want to view waveforms on the meter's webpages, select **Generate COMTRADE files**.

NOTE: The factory-default configuration for COMTRADE only supports Standard waveform capture.

b. Set the **Log depth** for the COMTRADE files to specify the maximum number of records stored on your meter's SFTP site.

14. Click Finish.

You are returned to the Sag/Swell Logging screen and the entry shows your new configuration.

If nothing happens after you click **Finish**, check the log depths and buffer depths for your other data logs to make sure that the meter has enough memory for these changes. Adjust the log depth and buffer depth of the data and waveform recorders, if needed.

Transients

Your meter monitors your power system's voltage and detects ITI (CBEMA) type disturbances related to transients.

When voltage transient limits are defined and alarming is enabled, the meter reports the disturbance's magnitude and duration, and logs data and waveform records associated with the disturbance.

Configuring transient logging using ION Setup

Use ION Setup to configure your meter to log data and waveform records related to voltage transient events, and to export the waveform data to COMTRADE files.

NOTE: Transient Log (Data Rec 15) records voltage transient related data.

To set up the Transient Log, Transient Waveform Log, and Transient COMTRADE files:

- 1. Start ION Setup.
- 2. Open the Setup Assistant for your meter.
- 3. Click Power Quality > Transient Logging.
- Select the data log and click Edit. Enter the meter password if prompted.

The Transient Logging Wizard appears.

- 5. The **Device setting verification** screen displays the results of meter configuration check for potential errors related to transient monitoring and reporting. Click **Fix** to view details or click **Next** to ignore the results and proceed to the next screen.
- The Transient Logging Setup screen displays Transient data recorder's Log Depth setting. You can change the maximum number of records to store in the Transient data log. Click Next to proceed to the next screen.
- 7. The **Waveform Log Setup** screen allows you to configure the waveform recorder for Standard or Delayed waveform capture.

NOTE: The Transient Logging Wizard does not support Extended waveform capture. See "Waveform capture" for details on Standard, Delayed and Extended waveform capture.

Parameter	Description
Waveform Depth	Specifies the maximum number of waveform records stored on the meter.
Waveform Format	Specifies the number of samples per cycle and the number of cycles that are stored in a waveform record.
Trigger Position	Specifies the number of cycles to capture before the waveform versus after the waveform. Trigger position can be set using the pre-cycle arrows or the slider bar.

NOTE: The maximum number of cycles (pre-event + post-event) cannot exceed the total number of cycles in the waveform format.

Click Next.

- 8. Configure your meter's COMTRADE settings:
 - Select or clear the Generate COMTRADE files check box to enable or disable the creation of COMTRADE records.

NOTE: The waveform viewer on your meter's webpages uses the meter's COMTRADE files. If you want to view waveforms on the meter's webpages, select **Generate COMTRADE files**.

NOTE: The factory-default configuration for COMTRADE only supports Standard waveform capture.

b. Set the **Log depth** for the COMTRADE files to specify the maximum number of records stored on your meter's internal SFTP site.

9. Click Finish.

You are returned to the Transient Logging screen and the entry shows your new configuration.

If nothing happens when you click **Finish**, check the log depths and buffer depths for all your other data logs to make sure that the meter has enough memory for these changes. Adjust the log depth and buffer depth of the data and waveform recorders if needed.

Configuring Advanced Power Quality

Use ION Setup to configure your meter's power quality monitoring and logging settings for IEC 61000-4-30, EN 50160, IEEE 519, and Rapid Voltage Change (RVC).

Prerequisites and notes

Ensure that Sag/Swell alarming is enabled and configured. For details on how to setup Sag/Swell alarming, see "Configuring sag/swell alarms using ION Setup" on page 190.

NOTE: IEC 61000-4-30 must be enabled before configuring EN 50160 or IEEE 519 logging.

NOTICE

DATA LOSS

- Enable Sag/Swell alarming before configuring power quality disturbance related features.
- Enable IEC 61000-4-30 before enabling other power quality monitoring and recording features.

Failure to follow these instructions can result in data loss.

To configure Advanced Power Quality:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Power Quality > Advanced PQ.
- 4. Configure IEC 61000-4-30.
- 5. (Optional) Configure EN 50160.
- 6. (Optional) Configure IEEE 519.
- 7. (Optional) Configure RVC.

Configuring IEC 61000-4-30

To configure IEC 61000-4-30:

- 1. Select 4-30 Enable.
- 2. Click **Edit** to configure your meter's IEC 61000-4-30 logging parameters.

3. Configure the settings as needed:

IEC 61000-4-30 Setup

Parameter	Description
	Select if you want to enable IEC 61000-4-30 monitoring.
Enabled	NOTE : This option must be enabled when monitoring EN 50160 or IEEE 519 parameters.
Threshold	Specifies the percentage of nominal voltage that defines a disturbance. For example, if you set this to 10% of 120 V nominal, the disturbance occurs when the voltage dips to 12 V and below.
Hysteresis	Specifies the percentage above the Threshold that defines the end of the disturbance. For example, if you set this to 2%, the end of the disturbance occurs when the voltage rises to (10% + 2%) of nominal, or 14.4 V and above.
Log 4-30 3s measurements	Select if you want to enable IEC 61000-4-30 3-second interval data logging.
Log 4-30 10s measurements	Select if you want to enable IEC 61000-4-30 10-second interval data logging.

4. Click **Send** to save your changes.

The **Advanced PQ** screen shows the new configuration.

Configuring EN 50160

To configure EN 50160:

1. Select EN50160 Enable.

If you want to delete all logged EN 50160 data, click Reset, and then click Yes to confirm.

2. Click **Edit** to configure your meter's EN 50160 logging parameters.

NOTE: You must enable IEC 61000-4-30 before the meter can start monitoring EN 50160 parameters.

3. Configure the settings as needed:

EN 50160 Setup

Parameter	Description
Enabled	Select if you want to enable EN 50160 monitoring.
Nominal Voltage	Specifies the nominal voltage value used for EN 50160.
Nominal Frequency	Specifies the nominal frequency used for EN 50160.
Log EN50160	Select if you want to log EN 50160 parameters.
measurements	NOTE : You need to enable EN 50160 monitoring to log the parameters.

4. Click Send to save your changes.

The Advanced PQ screen shows the new configuration.

Configuring IEEE 519

To configure IEEE 519:

- 1. Select 519 Enable.
- 2. Click **Edit** to configure your meter's IEEE 519 logging parameters.

NOTE: You must enable IEC 61000-4-30 before the meter can start monitoring IEEE 519 parameters.

- 3. From the **Harmonics Limits** drop-down list, select the IEEE 519 edition you want the meter to use when analyzing harmonic data.
- 4. Click Next.
- 5. Configure the voltage settings as needed:

IEEE 519 Setup

Parameter	Description
Nominal Voltage	Displays the nominal voltage value used for IEEE 519.
	NOTE : If you change the Nominal Voltage, you must return to this setup screen and update the IEEE 519 configuration.
<bus options="" voltage=""></bus>	Select the bus voltage at the point of common coupling.
	Select Disabled if you do not want to log IEEE 519 related data.

6. After specifying the bus voltage, click **Next** to configure the IEEE 519 current parameters.

IEEE 519 Setup

Parameter	Description
Maximum short circuit current	Enter the maximum short-circuit current at the point of common coupling.
Maximum demand load current	Enter the maximum demand load current at the point of common coupling.
Ratio	This displays the maximum short-circuit to maximum demand load ratio. This is used to determine the voltage and current distortion limits.

7. Click **Next** to view the screen that displays the voltage and current distortion limits for the harmonic content.

Harmonics 2 to 50 and THD/TDD are displayed, with the corresponding set limits for Voltage Distortion % and Current Distortion %.

8. Click **Finish** to save your changes.

The Advanced PQ screen shows the new configuration.

Configuring RVC

To configure RVC:

- 1. Select RVC Enable.
- 2. Click **Edit** to configure your meter's RVC feature.

NOTE: You must enable the Sag/Swell module before the meter can start monitoring and detecting RVC.

3. Configure the settings as needed:

Rapid Voltage Change Setup

Parameter	Description
Enabled	 Disabled: ION Setup has detected that the Sag/Swell module is disabled. Go to Alarming > Sag/Swell and enable Sag/Swell first for the meter to detect RVC. Yes: RVC monitoring is on. No: RVC monitoring is off.
Threshold	Specifies, as a percentage, the RMS voltage limit that must be exceeded for an RVC event to occur.
Hysteresis	Specifies, as a percentage, the difference in magnitude between the start and end thresholds for an RVC event.

Click Send to save your changes.

The Advanced PQ screen shows the new configuration.

Rapid Voltage Change

Rapid Voltage Change (RVC) is a quick transition in RMS voltage between two steady-state conditions, during which the voltage does not exceed the sag/swell thresholds.

You can configure the Sag/Swell module to detect and measure RVC and record the event in the meter's Event Log.

For more information on the Sag/Swell module, see ION Reference, available on www.se.com.

Harmonics

Harmonics are integer multiples of the fundamental frequency of the power system.

Harmonics information is valuable for power quality analysis, determining properly rated transformers, maintenance, and troubleshooting. Evaluation of harmonics is required for compliance with system power quality standards such as EN 50160 and meter power quality standards such as IEC 61000-4-30.

Harmonics measurements include per-phase magnitudes and angles (relative to the fundamental frequency of the phase A voltage) for the fundamental and higher order harmonics relative to the fundamental frequency. The meter's power system setting defines which phases are present and determines how line-to-line or line-to-neutral voltage harmonics and current harmonics are calculated.

Harmonics are used to identify whether the supplied system power meets required power quality standards, or if non-linear loads are affecting your power system. Power system harmonics can cause current flow on the neutral conductor, and damage to equipment such as increased heating in electric motors. Power conditioners or harmonic filters can be used to minimize unwanted harmonics.

Viewing harmonics information using the display

To view detailed harmonics data through the display:

- 1. Press the Home button on the display.
- 2. Press **Power Quality > Harmonics**. The total harmonic distortion (THD) screens are displayed.
- 3. Press **More**, then use the up or down icons to select the desired harmonics. The per-phase harmonics are graphically displayed.
- 4. Press the left and right icons to move to individual harmonics. The harmonic number, magnitude and phase angle are displayed.

Voltage crest factor

Crest factor is the ratio of peak to RMS voltage values.

For a pure sinusoidal waveform, crest factor is equal to 1.414. The meter uses the following equation to calculate crest factor:

$$C = \frac{V_{peak}}{V_{peak}}$$

$$C = Crest factor$$

$$V_{peak} = Voltage peak$$

$$V_{RMS} = Voltage RMS$$

Current crest factor

Crest factor is the ratio of peak to RMS current values.

For a pure sinusoidal waveform, crest factor is equal to 1.414. The meter uses the following equation to calculate crest factor:

$$C = \frac{I_{peak}}{I_{RMS}}$$

$$I_{peak} = Current peak$$

$$I_{RMS} = Current RMS$$

K-factor

K-factor relates the heating effect of a distorted current in a transformer to a sinusoidal current with the same RMS magnitude — it describes a transformer's ability to serve non-linear loads without exceeding rated temperature rise limits.

The K-factor is equal to the sum of the squares of the harmonic currents multiplied by the squares of the harmonic order. The meter uses the following equation to calculate K-factor:

$$K = \frac{\sum_{n=1}^{h} (lh^{2} \times h^{2})}{\sum_{n=1}^{h} lh^{2}}$$

Where ${\tt K}$ is the K-factor, ${\tt h}$ is the harmonic order and ${\tt Ih}$ is the true RMS current of harmonic order ${\tt h}$.

Harmonic content calculations

Harmonic content (H_c) is equal to the RMS value of all the non-fundamental harmonic components in one phase of the power system.

The meter uses the following equation to calculate H_c:

$$HC = \sqrt{(H_2)^2 + (H_3)^2 + (H_4)^2} ...$$

THD% calculations

THD% is a quick measure of the total distortion present in a waveform and is the ratio of harmonic content (H_C) to the fundamental harmonic (H_1).

By default, the meter uses the following equation to calculate THD%:

$$THD = \frac{H_C}{H_1} \times 100\%$$

thd and TDD

Your meter can be configured to provide thd (total harmonic distortion using the total RMS value for the content rather than the fundamental content) and TDD (total demand distortion, the harmonic current distortion against the maximum demand of the electrical system).

thd =
$$H_C / RMS *100\%$$

$$TDD = H_C / Demand_{Max} *100\%$$

For more information on the Harmonics Measurement module, see *ION Reference*, available on www.se.com.

Phasors

Phasors are used to represent the voltage and current magnitude and angles.

The length of the lines in the phasor diagram represent the relative magnitude of the voltages with respect to the other phase voltages, and the currents with respect to the other phase currents. All angles are measured with respect to the Va/V1 phase. The Va/V1 phasor is fixed to the right-hand horizontal axis (positive x-axis). Positive angles are measured counterclockwise.

Measured values are provided for the magnitude and relative angle for each voltage and current phase.

Delta vector diagrams can be configured to display two different ways:

- Instrument (voltage vectors appear 60 degrees apart showing the actual voltage and current values that the meter is measuring).
- System (voltage vectors appear 120 degrees apart showing true system operation including any calculated values).

Phasor information can be used to troubleshoot incorrect connections on the meter's voltage and current inputs (for example, switched phase wiring or polarity errors), if you know how the phasors should be oriented for your power system.

Phasor information can be viewed using ION Setup, meter webpages, or the display.

Power quality standards compliance

Meter compliance

Your meter is compliant with the following power quality standards.

IEC 62586-1 and IEC 62586-2

Your meter is compliant with IEC 62586-1 and IEC 62586-2. The meter classification is PQI-A-FI1, defined as follows:

Product Code	Description
PQI	Power quality instrument
Α	Functions class A according to IEC 61000-4-30
F	Fixed installed equipment
I	Indoor application
1	Indoor environment with uncontrolled temperature variations

NOTE: Your meter has Power station electromagnetic immunity compliance in accordance with IEC 61000-6-5.

IEC 61000-4-30

IEC 61000-4-30 power quality standard compliance is provided by ION modules including: Power Quality Aggregator, Harmonics Measurement, Disturbance Analyzer, Symmetrical Components, Mains Signaling Evaluation, and Sag/Swell.

For more information, see the <u>IEC 61000-4-30 compliance and ION meters</u> technical note, available on www.se.com.

Power quality standards compliance reporting

Your meter can measure and record compliance data for the following power quality standards.

EN 50160

The EN 50160 framework includes ION modules such as Flicker, Mains Signaling Evaluation, Harmonics Evaluation, and Voltage Harmonics.

NOTICE

DATA LOSS

Use an Uninterruptible Power Supply (UPS) to help maintain EN 50160 framework operation during a power outage.

Failure to follow these instructions can result in data loss.

For more information about EN 50160, see the <u>Power Quality: ION Meters and EN50160:2010</u> technical note, available on www.se.com.

IEEE 519

The IEEE 519 framework includes ION modules, such as: Harmonics Evaluation, Harmonics Measurement, and Counter.


Disturbance direction detection

Your meter has disturbance direction detection capabilities to help you determine the location of a power system disturbance.

When a disturbance occurs, the meter analyzes the disturbance information to determine the direction of the disturbance relative to the meter. This analysis includes a confidence level indicating the level of certainty that the disturbance is in the determined direction and is stored in your meter's event log.

Disturbance direction detection is enabled on your meter by default and does not require any additional configuration beyond setting the nominal voltage and nominal frequency.

Disturbance direction detection can help locate the source of a disturbance when used in a system of disturbance direction detection devices. In the diagram below, meters (B), (C) and (D) are installed on the power consumer side, while meter (E) is installed on the utility side.



Α	Disturbance location
В	Meter (B) reports downstream disturbance
С	Meter (C) reports upstream disturbance
D	Meters (D) report upstream disturbance
Е	Meter (E) reports downstream disturbance

The arrows show the direction the meters have determined for the disturbance. With this information, you can determine that the disturbance occurred between meter (B) and meter (C) and can focus on that section of your system to find the cause of the disturbance.

Disturbance direction detection events

The results of the disturbance direction detection algorithm appear in the meter's event log.

The image below shows an example of how a Disturbance Direction Detection event appears in your meter's event log when viewed using ION Setup.



You can view your meter's event log through ION Setup or display.

For details on how to view the event log, see "Viewing and downloading an event log" on page 54.

For more information on the Disturbance Direction Detection module, see *ION Reference*, available on www.se.com.

COMTRADE

The meter provides waveforms in **COM**mon format for **TRA**nsient **D**ata **E**xchange (COMTRADE) format. IEC 60255-24 defines the COMTRADE format. COMTRADE files simplify the retrieval, analysis, and exchange of power quality event (disturbance) data between many sources and vendors.

COMTRADE records are generated from the existing Waveform Recorder modules that are connected to the COMTRADE module.

Your meter can generate COMTRADE files and store them on the meter's internal SFTP site.

COMTRADE can be used in conjunction with IEC 61850.

For more information, see the <u>COMTRADE</u> and <u>ION</u> technology technical note, available on www.se.com.

COMTRADE implementation

COMTRADE is configured as part of the default waveform recording framework.

COMTRADE records are created for sag/swell events. Configure your meter's nominal voltages to enable waveform recording. COMTRADE records are stored as read-only files on the meter's internal SFTP site. A master reset, firmware upgrade, or waveform recorder change will delete the records.

NOTE: Sag/Swell alarms must be enabled when using COMTRADE. For details on how to set up Sag/Swell alarming, see "Configuring sag/swell alarms using ION Setup" on page 190.

By default:

 The meter is configured so COMTRADE records are created for the default waveform recorders.

TIP: If you create a waveform recorder, the recorder will not create COMTRADE files by default. Configure a new COMTRADE module if you want COMTRADE files created by new recorders. You can configure up to three COMTRADE modules using ION Setup in Advanced mode. For more information on how to switch ION Setup to Advanced mode, see "Meter configuration" on page 23.

 The oldest COMTRADE record is overwritten by the newest record when the COMTRADE depth is exceeded.

NOTE: COMTRADE files can only be downloaded using an Ethernet connection. They cannot be downloaded using serial, modem, or Ethernet gateway connections.


For more information, see the COMTRADE and ION technology technical note, available on www.se.com.

Waveforms on the meter webpages

You can use the waveform viewer on the meter's webpages to view waveforms generated as a result of power quality events.

Set up the meter to view waveforms on the webpages

Before you can view waveforms on the meter's webpages, you need to perform some basic configuration to enable waveform capture and store the waveforms in COMTRADE format.



1. Enable waveform capture on your meter

Set the meter's nominal voltage using ION Setup or meter webpages.

a power quality event occurs

A COMTRADE record is generated and saved to your meter's internal SFTP site.


2. A waveform is captured when 3. View the waveform on the meter's webpages

> Go to the waveform viewer (Monitoring > Waveforms) to explore the waveform data.

The waveform viewer uses the meter's COMTRADE files to display the waveforms. If the events you want to capture are not included in the default framework, you can customize the meter's waveform recording framework.

Webpage waveform viewer

After COMTRADE files are generated by your meter, you can view them using the waveform viewer.



A Select the COMTRADE module to view (COMTRADE_1 is set up by default; you can also set up COMTRADE_2 or COMTRADE_3)

B Select the particular COMTRADE waveform to view

C Show/hide parameters

D View details

E Zoom in/out

Viewing waveforms on meter webpages

Use the waveform viewer on your meter's webpages to view the meter's COMTRADE waveform files.

Prerequisites:

Ensure the meter is configured to record waveforms by setting the nominal voltage.

To view waveforms on meter webpages:

- 1. Open a browser and go to the IP address for your meter, entering valid login credentials when requested.
- 2. Navigate to **Monitoring > Waveforms**.

A screen displays with accordion menus for three COMTRADE modules (regardless of whether or not that COMTRADE module is being created by the meter). The waveform viewer for COMTRADE 1 is expanded.

By default, COMTRADE_1 displays the sag/swell waveform records. COMTRADE_2 and COMTRADE_3 are used if you have configured additional waveform recorders and connected them to COMTRADE modules.

Select the accordion menu for the COMTRADE records you want to view, for example COMTRADE_2.

The waveform viewer for those COMTRADE records is displayed.

4. Select the file you want to view from the record drop-down list box.

The numbering starts at 0 (zero), which means you select cmt0_00004 to view the fifth file for COMTRADE 1.

- 5. Click or tap an individual voltage or current channel in the legend to show or hide it in the waveform viewer.
 - Visible
 - Hidden
- 6. Use the bar at the bottom to zoom in/zoom out on a particular section of the waveform, or to scan through the waveform with the selected zoom level.



- Draw a window over a particular area to zoom in on that section of the waveform.
- Drag the selected area to move the zoom across the waveform.
- Drag the start and end points to expand or narrow the zoom.
- 7. Hover over or tap a spot on the waveform to view the values associated with that particular moment in time.



Burst data logging

Burst data logging is a recording method that captures a snapshot of data that occurred immediately before and immediately after a triggered recording.

Burst data logging is analogous to continuous shooting mode or "burst mode" in photography. An understanding of pre and post event data assists in the analysis of undesired power quality events such as sags or swells.

Burst logging is typically used for high-speed RMS (half-cycle) data capture, but the data recorder supports standard speed (1-second) recording as well, depending on the ION modules connected to the inputs of the Data Recorder module.

NOTE: To maximize the performance of your power management system, it is recommended that devices be connected directly to an Ethernet network.

Data recorder burst data


The meter's Data Recorder modules support burst data logging.

The Data Recorder module's *Pre-trigger Records* setup register specifies how many pre-event records are saved with each triggered recording. The *Post-trigger Records* setup register specifies how many post-event records are saved with each triggered recording.

Both *Pre-trigger Records* and *Post-trigger Records* are set to zero by default. To configure the data recorder for burst data logging, either or both of these setup registers must be set to a non-zero positive integer value.

The data log set for each triggered recording is equal to the sum of *Pre-trigger Records + Post-trigger Records + 1* (where 1 is the actual record when the Data Recorder module's *Record* input was triggered).

For example, if *Pre-trigger Records* is set to 10 and *Post-trigger Records* is set to 5, the number of records for each data log set is 16:



Burst data log set = [pre-trigger records] + [post-trigger records] + [actual trigger record] = 10 + 5 + 1 = 16.

When burst data logging is enabled, both *Buffer Depth* and *Depth* setup registers must be set to a positive integer multiple of the data log set.

Use the system frequency to calculate the number of records needed to capture 1 second of data:

- For 60 Hz, total number of records per second = 60 cycles/second x 2 half-cycles = 120
- For 50 Hz, total number of records per second = 50 cycles/second x 2 half-cycles = 100

You can use the **Power Quality** setup assistant in ION Setup to specify how many seconds of pre-trigger and post-trigger data you want to capture. ION Setup automatically calculates the required number of records based on your input.

Waveform capture

Use the meter's Waveform Recorder modules to capture waveform data.

The Waveform Recorder module captures one waveform record every time its *Record* input is triggered.


A waveform record is defined by the module's *Format* setup register, expressed as (number of samples per cycle) x (number of cycles per waveform record). For example, if *Format* is set to 128x7, that means one waveform record is made up of 7 cycles of waveform data at 128 samples per cycle.

The meter supports 3 waveform capture types: standard, delayed, and extended.

Standard waveform capture

The meter's Waveform Recorder modules support standard waveform capture.

A standard waveform capture saves one buffered waveform record at the *Record* trigger time. Only pre-trigger waveform data is captured in this mode. No post-trigger waveform cycles are recorded.




- A Waveform recording triggered
- B Waveform record captured at trigger

Delayed waveform capture

The meter's Waveform Recorder modules support delayed waveform capture.

The Waveform Recorder module's *Record Delay Cycles* setup register specifies how many cycles to delay the waveform capture after the *Record* input is triggered. This is for capturing post-trigger waveform data.




- A Waveform recording triggered
- B Waveform record if Record Delay Cycles was set to zero
- C Delay period (number of cycles specified in Record Delay Cycles setup register)
- D Delayed waveform capture recorded in waveform log

Extended waveform capture

The meter's Waveform Recorder modules support extended waveform capture.


The Waveform Recorder module's *Pre-trigger Records* setup register specifies how many preevent records are saved with each triggered recording. The *Post-trigger Records* setup register specifies how many post-event records are saved with each triggered recording. Both *Pre-trigger Records* and *Post-trigger Records* are set to zero by default. To configure the waveform recorder for extended waveform capture, either or both of these setup registers must be set to a non-zero positive integer value. If you do this, you must also set the *Record Delay Cycles* setup register to zero in order to properly configure the extended waveform capture.



- A Waveform recording triggered
- B Waveform record captured at trigger
- C Pre-trigger waveform records captured
- D Post-trigger waveform records captured

The waveform log set for each triggered recording is equal to the sum of *Pre-trigger Records* + *Post-trigger Records* + 1 (where 1 is the actual record when the Waveform Recorder module's *Record* input was triggered).

For example, if *Pre-trigger Records* is set to 2 and *Post-trigger Records* is set to 6, the number of records for each waveform log set is 9:



The waveform log set for the extended waveform capture = [pre-trigger records] + [actual trigger record] + [post-trigger records]. The total waveform records captured in this example is 2 + 1 + 6 = 9.

When extended waveform capture is enabled, both *Buffer Depth* and *Depth* setup registers must be set to a positive integer multiple of the waveform log set.

NOTE: The COMTRADE module does not support extended waveform capture. The COMTRADE files saved are only for the trigger waveform record.

High-Speed Transient Capture (HSTC)

High-Speed Transient Capture overview

The ION9000T continuously monitors incoming voltage signals. In addition to standard transient monitoring, the ION9000T detects sub-microsecond high-voltage transients up to a peak voltage of 10 kV.

NOTE: The high-speed transient capture (HSTC) feature is available on the ION9000T (METSEION95030 and METSEION95040).

The ION9000T meter is equipped with firmware and frameworks that enable the HSTC feature.

The default HSTC related settings suit most applications. Use the default settings or make changes based on your system needs.

Use the HSTC feature to:

- Expand power quality event detection capabilities when combined with standard transient capture.
- Record pre-event data to see the characteristics of the incoming voltage signal before the disturbance.
- Receive alarm notifications when a transient has been detected.
- Chart waveforms to better understand the transient event. For example, peak magnitude, duration and initial polarity of the transient.
- Record statistics, such as voltage stress, to provide an indication of cumulative impact to loads within the electrical system.
- Sort voltage transients by peak magnitude and duration.
- Quantify transients on a per phase basis.
- Detect and characterize transients to create mitigation strategies.

For more information on the HSTC, HSTC waveform recorder, and Data set recorder modules, see *ION Reference*, available on www.se.com.

Go to www.se.com and search for "An Overview of Transients in Power Systems" for information on transients and their effects in electrical power systems.

HSTC prerequisites

To use the HSTC feature, you need the following:

- ION9000T meter.
- ION9000T frameworks files (v2.2.x or later).
- ION Setup (v3.2.x or later).

The HSTC feature is not supported on other ION9000 series meters.

Verify the correct meter framework

The HSTC option is displayed as the HSTC feature set.

View the meter's feature set using ION Setup, meter webpages, or the display.

Viewing feature set using ION Setup

- 1. Open ION Setup and select the **Setup Assistant** for your meter.
- 2. Click Template > Save to PC > FAC1 Feature Set.

Viewing feature set using the meter webpages

- Open a web browser and enter the IP address for your meter. Enter your login credentials when prompted.
- 2. Click Diagnostics > Statistics > Meter Basic > Feature Set.

Viewing feature set using the display

Select Alt Display Mode > Nameplate > Feature Set.

See "Display modes" on page 171 for information about display modes.

Verify the correct ION Setup version

To verify the ION Setup version:

- 1. Open ION Setup.
- 2. Click **Help > About ION Setup**. An ION Setup dialog box opens and displays the ION Setup version.

If your version is earlier than v3.2.x., download the latest version of ION Setup

Downloading the latest ION Setup version

- 1. Browse to https://www.se.com/en/download/document/ION_Setup_Latest_Release for the latest version of ION Setup.
- 2. Download the installation file, then run it to upgrade ION Setup.

Commission HSTC

This section supplements the meter installation guides and provides guidance on commissioning your meter to enable HSTC.

See your device installation guide for information related to installation.

System voltage

Potential transformer (PT) scaling is not applied in high-speed transient capture.

High-speed transient measurements are performed on voltage levels present at the meter's voltage terminals.

Voltage reference

Set the voltage reference, Ve or Vn, according to your system configuration.

High-speed transient voltage measurements are calculated between V1–V4 and neutral (Vn), or between V1–V4 and earth (Ve) depending on this setting.

Communications

Ethernet communication is recommended. HSTC waveform viewing is not supported over serial connections.

Set up HSTC

HSTC alarms are disabled by default. The HSTC feature is enabled when HSTC alarms are enabled.

HSTC related settings, such as magnitude and duration thresholds, are pre-configured at the factory. Use the default settings or make changes based on your system needs.

Review and configure the settings for the following functions before enabling the HSTC feature:

- HSTC alarms
- HSTC logging.

HSTC alarms

Use HSTC alarms to notify you when a specific condition is met, such as a voltage transient that exceeds a defined magnitude threshold.

HSTC alarms are included in the ION9000 series alarm system and are shown in the meter's **Historical Alarm** screen(s).

Default HSTC alarm settings

Setup Register	Value/Range	Default
HSTC Alarm status	Disabled, Enabled	Disabled
Voltage Reference	Ve, Vn	Ve
Magnitude Threshold (V _{RMS})	120–7100	1000
Duration Threshold (μs)	0–250.0	0
Alarm Priority	None, Info Only, Low, Medium, High	High
Custom Priority	0–255	192

To use HSTC alarms, perform the following:

- Enable HSTC alarms.
- Configure HSTC alarms.
 - Set the voltage reference.
 - Set the peak magnitude threshold and duration threshold.
 - Assign alarm priority.
 - Set a custom alarm priority.
- View and acknowledge alarms.

See "Alarms and alerts" on page 180 for additional information about the ION9000 series alarms.

Enable and configure HSTC alarms

Enable HSTC alarms using ION Setup or the display.

Configure HSTC alarms using ION Setup.

Changing your meter's HSTC alarm configuration deletes all existing Data set and HSTC waveform logs.

NOTICE

DATA LOSS

Ensure that all important data has been recorded before configuring HSTC alarms.

Failure to follow these instructions can result in data loss.

Enabling and configuring HSTC alarms using ION Setup

To enable and configure HSTC alarms using ION Setup:

- 1. Open ION Setup and select the **Setup Assistant** for your meter.
- 2. Click Alarming > Transient.
- 3. Select High Speed Transient, and then click Edit.
- 4. In **High Speed Transient Setup**, enable or configure the setup registers:

Setup Register	Value/Range	Description
Enabled/Disabled	Enabled, Disabled	Specifies if HS Transient capture is enabled.
Voltage Reference	Ve, Vn	Determines the voltage reference. Set the voltage reference to match your system configuration.
Magnitude Threshold (V _{RMS})	120–7100	Specifies the absolute voltage threshold that must be exceeded to trigger a HS transient capture. Note: This value is entered in RMS volts.
Duration Threshold (μs)	0–250.0	Specifies the length of time that the magnitude threshold must be exceeded to trigger a HS transient capture. If this register is set to zero, any voltage that exceeds the magnitude threshold will trigger a HS transient capture.
Alarm Priority	None, Info Only, Low, Medium, High	Select the alarm priority you want to associate with the HS transient alarms. To stop an alarm from being displayed without affecting other meter features, set the alarm priority to Info Only.

Setup Register	Value/Range	Description
Custom Priority	0–255	Select custom priority to view and configure the priority associated with the alarm. The event log cutoff value is displayed for reference. Event priorities above the cutoff are stored in the meter's event log.

5. Click **Save**. ION Setup performs a configuration check and displays a message if the Magnitude Threshold setting is below the configured nominal voltage.

Enabling HSTC alarms using the display

To enable and disable HSTC alarms using the display:

- 1. Review your meter's nominal voltage settings.
- 2. Set the HSTC magnitude threshold to a value higher than the nominal voltage.

See "Disabling and enabling alarms using the display" on page 189 for instructions.

Log HSTC

Topics in this section:

HSTC logging

The HSTC logging function is enabled with HSTC alarms. When defined transient thresholds are exceeded the meter performs the following:

- HSTC data set logging.
- HSTC waveform logging.

The meter performs a set of calculations and stores separate records for each voltage phase. Records are captured for V1–V4 regardless of which phase the transient occurred on.

HSTC logging default settings

Data Set Logging	HSTC Waveform Storage
100 records	40 records, 20.0 ms

See "Configuring HSTC logging using ION Setup" on page 228 for information about these settings.

HSTC Data set logging

Use data set logging to record transient event information such as peak voltage magnitude and duration.

This feature also provides summary information such as volts-seconds stress accumulations for each phase and total unique transient events.

Each time the HSTC trigger criteria are met, the meter performs a set of calculations for each voltage phase:

HSTC Data set	Event based analytics
	Peak voltage amplitude
	Rise time
	Duration
	 Voltage stress (volt-seconds)
	Average voltage
	Timestamps

HSTC Summary	Event accumulations and statistics	
	Total number of transient events on voltage phases V1–V4	
	Total number of unique events	
	Date and time of the last transient event counter reset	
	 Accumulated voltage stress (volt-seconds) for voltage phases V1–V4 	
	Date and time of the last voltage stress accumulations reset	
	 Total number of transient events grouped by peak magnitude and duration. There are a total of nine bins: 	
	 Magnitude 1/Duration 1 	
	 Magnitude 1/Duration 2 	
	 Magnitude 1/Duration 3 	
	 Magnitude 2/Duration 1 	
	 Magnitude 2/Duration 2 	
	 Magnitude 2/Duration 3 	
	 Magnitude 3/Duration 1 	
	 Magnitude 3/Duration 2 	
	 Magnitude 3/Duration 3 	

HSTC waveform logging

Use HSTC waveform logging to capture voltage transient waveform data.

A transient detected on any voltage phase triggers a waveform capture for all connected voltage phases. The HSTC waveform recording feature detects long duration and repetitive disturbances and automatically extends high-speed transient capture if conditions persist.

Each transient waveform recording includes pre-event data to analyze the characteristics of the incoming voltage signal prior to the event that triggered the high-speed transient capture.

Use ION Setup or EcoStruxure™ Power Monitoring Expert to chart and view waveforms.

Enable and configure HSTC logging

HSTC logging is enabled when HSTC alarms are enabled. Use the default settings or make changes based on your system needs.

Changing your meter's HSTC logging configuration deletes all existing data log and waveform records.

NOTICE

DATA LOSS

Ensure that all important data and waveforms have been recorded before configuring the data and waveform recorders.

Failure to follow these instructions can result in data loss.

Enabling HSTC logging

The HSTC logging function is enabled with HSTC alarms.

See <u>"Enable and configure HSTC alarms"</u> for instructions on how to enable or disable the HSTC alarms.

Configuring HSTC logging using ION Setup

Configure data set and waveform logging using ION Setup.

To set different conditions:

- 1. Open ION Setup and select the **Setup Assistant** for your meter.
- 2. Click Power Quality > HSTC logging.
- 3. Select the data log and click **Edit**.

The **HSTC Logging Wizard** displays

- 4. Set the **Data Set Depth** to the number of records to keep
- 5. Click Next.
 - ION Setup prompts you if the number of records exceeds file size limits. Enter a lower number, then click **Next** to proceed.
- Set the waveform storage Log Depth to the number of waveforms to keep. The total duration of log storage in milliseconds (ms) is displayed consistent with the Log Depth setting.
 - ION Setup prompts you if the **Log Depth** setting exceeds the recommended memory allocation.
- 7. Click **Finish** to return to the **HSTC Logging** tab.

View HSTC

The ION9000T continuously monitors incoming voltage signals. When HSTC is enabled and defined transient thresholds are met the meter performs the following functions:

- HSTC alarms
- HSTC logging
 - Data set logging
 - HSTC waveform logging

View and acknowledge alarms

HSTC alarms are classified as historical alarms. Use the display to view and acknowledge HSTC alarms.

See "Viewing and acknowledging alarms using the display" on page 187 for instructions.

View HSTC logs

The following logs are generated when a high-speed transient has been detected:

- HSTC data set logs
- HSTC summary logs
- · HSTC waveform recorder logs

View HSTC logs using ION Setup, the meter webpages or the display.

Viewing HSTC data sets using ION Setup

- 1. Open ION Setup and select your meter.
- 2. Click View > Data Screens.
- Go to the High Speed Transient Capture folder, then select the HSTC Data Set log.
 The HSTC Data Set Recorder log displays.

Viewing HSTC summary using ION Setup

- 1. Open ION Setup and select your meter.
- 2. Click View > Data Screens.
- Go to the High Speed Transient Capture folder, then select the HSTC Summary log.
 The HSTC Summary log displays.

Viewing HSTC summary using meter webpages

- 1. Open a web browser and enter your meter's IP address in the address box.
 - The webpage login displays.
- 2. Enter your login credentials.
- 3. Select Monitoring > Power Quality Summary > HSTC.

The **High-Speed Transient Summary** screen displays.

View HSTC waveforms


Use ION Setup or EcoStruxure[™] Power Monitoring Expert to view HSTC waveforms.

Viewing HSTC waveforms using ION Setup

Use the ION Setup waveform viewer to plot captured waveform logs.

- 1. Open ION Setup and select your meter.
- 2. Click View > Data Screens.
- Go to the High Speed Transient Capture folder, then select the HSTC Waveform log. The
 HSTC Waveform log displays. A progress bar at the bottom of the screen indicates when all
 waveform logs have been retrieved from the meter.

NOTE: Records are sorted by **Start Date/Time**, with the newest entries appearing at the top.



- 4. Select the data to plot:
 - a. Select the record you want to view.
 - b. Hold the SHIFT key while selecting the first and last entries to plot multiple records in the same view.
- 5. Click the chart icon to plot the selected records.
 - A Chart Properties box opens.
- 6. Click OK.

The **HSTC Waveform Plot** displays.

HSTC waveform viewer navigation

The HSTC waveform viewer provides user interface elements to help understand transient event information such as the peak magnitude, duration and initial polarity of the transient.



Element	Name	Description
А	Active window	This window displays a portion of the overall captured disturbance.
В	HSTC V1–V4 phase selector	Click to select a single voltage phase V1 through V4.
С	Slider control (top and bottom)	Click and drag to focus on an event in the Active window. The values shown in the information panel at the bottom of the screen will update to reflect the new slider positions.
D	Scale	Auto generated value based on the magnitude of the detected transient. Note: The color of the text matches the voltage phase selected. For example, blue text indicates HSTC V3 phase has been selected.
E	Trigger point	The time when the transient thresholds are exceeded. Note: The color of the trigger point indicator arrow matches the voltage phase selected. For example, a red arrow indicates HSTC V1 phase has been selected.
F	Histogram	The histogram shows the complete captured disturbance. Waveform samples are grouped into bins based on the peak magnitude of the sample.

Element	Name	Description
G	Active histogram window	This window functions as a coarse zoom. Select and drag the window to any point in the histogram to focus on a specific set of waveform samples. The waveform samples contained within this histogram window are displayed in the active window above. Note: The waveform samples in the active window reflect the selected HSTC phase.
		The peak magnitude of captured high-speed transients is sorted into three bin thresholds to aid in the classification and analysis of the captured event.
		Mag ≤ 1500 V
	Magnitude	1500 V < Mag < 4000 V
H thresholds	4000 V ≤ Mag < 10 000 V Right click in the histogram to set the number of active bins and their corresponding thresholds. Note: The updated threshold settings are used for informational purposes only. They do not change the conditions set to detect transients, nor are they retained when the HSTC waveform viewer is closed.	
I	Trigger timestamp	Timestamp representing the point in time that the transient condition was detected.
J	Active window zoom	This window functions as a fine zoom. Click, hold and drag your cursor across any waveform portion in the active window. Note: The waveform samples in the active window zoom reflect the selected HSTC phase.
К	Spectral analysis	Right click within the histogram window to view the spectral analysis of the selected samples. Note: The spectral analysis window reflects the selected HSTC phase.

HSTC events

HSTC events are logged the same as other meter events:

- External events such as the detection of a high-speed transient
- Configuration changes such as editing the HSTC magnitude threshold
- · Other meter events

See the "Event log" on page 245 for more information about logging meter events.

Viewing HSTC events

View the event log using ION Setup or the display.

HSTC resets

There are two HSTC reset methods, depending on what information you want to clear:

Use the meter's Master reset to clear HSTC Data set and Waveform logs.

Use the meter's HSTC reset to clear HSTC event accumulations and statistics.

NOTICE

DATA LOSS

Ensure all important data from the device has been recorded before performing a reset.

Failure to follow these instructions can result in data loss.

Master reset

Perform a Master reset using ION Setup.

Alternatively, you can use the meter webpages or meter display.

See "Resets" on page 274 for more information about meter resets.

Resetting HSTC using ION Setup

- 1. Open ION Setup and select your meter.
- 2. Click View > Data Screens.
- Go to the High Speed Transient Capture folder, then select the HSTC Summary log.
 The HSTC Summary log displays
- 4. Click the HSTC Reset icon.
- 5. Click Yes to confirm HSTC reset.

Logging

Logging overview

The meter's logging frameworks include factory-configured data recorders, waveform recorders, and event logs.

The logging frameworks store data related to:

- Power quality and compliance
- Energy and demand
- · Revenue metering
- Trending and forecasting
- Meter events

When your system's nominal parameters are programmed into the meter, power quality events such as sags, swells and transients are automatically detected, and associated voltage and current data and waveforms are logged. Meter data is stored in non-volatile memory, so data is retained even if the meter loses power. If your system nominal values fluctuate, you can configure the meter's setpoint learning feature to learn your power system's normal operating values, then use that information to help identify voltage sags and swells.

The meter's logging framework also supports burst data logging for sag/swell events. When burst data logging is enabled, additional data records immediately before and immediately after the sag/swell event are captured. Energy management systems can then retrieve this information for use in applications, such as power event analysis.

TIP: Connect devices directly to an Ethernet network to help maximize the performance of your power management system.

You can also configure the meter to email data from the logging frameworks. For more information, see the PowerLogic MeterM@il Internal Email Client Feature technical note, available on www.se.com.

Meter events are recorded in the meter's onboard event log. You can also configure the meter to record events to an external syslog server.

For details on how to set up syslog, see "Configuring Syslog network settings using ION Setup" on page 247.

Default data logging configuration

The meter's default template includes factory-configured data logs (Data Recorder modules).

These data logs and their configuration are used by other components of your power monitoring system.

NOTE: Do not change the default configuration of any of the logs unless you understand the impact of the change on these power monitoring system components, the data they use, and your meter's memory.

The meter can support up to 100 data recorders, which can each record up to 16 different parameters.

Revenue Log

The Revenue Log (Data Rec 1) is configured for use with UTS MV-90 billing software.

Factory settings for this data recorder:

- Log depth = 3360 records (35 days)
- Interval = 900 seconds (15 minutes)

By default, it logs the following values:

Parameter	Description
kWh del int	Interval kWh delivered
kWh rec int	Interval kWh received
kVARh del int	Interval kVARh delivered
kVARh rec int	Interval kVARh received

Historic data logs

Three historic data logs are used to record standard power system quantities, such as phase current, phase voltage, and power factor. These logs are labeled Hist Mean Log, Hist High Log, and Hist Low Log.

Factory settings for these data recorders:

- Log depth = 3360 records (35 days)
- Interval = 900 seconds (15 minutes)

By default, they log the following values:

Hist Mean Log (Data Rec 2)				
VII ab mean	V unbal mean	I avg mean	kVA tot mean	
VII bc mean	la mean	I 4 mean	PF lag mean	
VII ca mean	lb mean	kW tot mean	PF lead mean	
VII avg mean	lc mean	kVAR tot mean	Freq mean	

Hist High Log (Data Rec 3)				
VII ab high	V unbal high	I avg high	kVA tot high	
VII bc high	la high	I 4 high	PF lag high	
VII ca high	lb high	kW tot high	PF lead high	
VII avg high	lc high	kVAR tot high	Freq high	

Hist Low Log (Data Rec 4)				
VII ab low	V unbal low	I avg low	kVA tot low	
VII bc low	la low	I 4 low	PF lag low	
VII ca low	lb low	kW tot low	PF lead low	
VII avg low	Ic low	kVAR tot low	Freq low	

Loss Log

The Loss Log (Data Rec 9) is configured to record loss values.

Factory settings for this data recorder:

- Log depth = 3360 records (35 days)
- Interval = 900 seconds (15 minutes)

By default, it logs the following values:

Parameter	Description
MU la^2h int	Phase A interval current squared hours
MU lb^2h int	Phase B interval current squared hours
MU lc^2h int	Phase C interval current squared hours
MU Vllab^2h int	Phase A interval voltage Line-to-Line squared hours
MU VIIbc^2h int	Phase B interval voltage Line-to-Line squared hours
MU VIIca^2h int	Phase C interval voltage Line-to-Line squared hours
MU VIn a^2h int	Phase A interval voltage Line-to-Neutral squared hours
MU VIn b^2h int	Phase B interval voltage Line-to-Neutral squared hours
MU VIn c^2h int	Phase C interval voltage Line-to-Neutral squared hours

Harmonics logs

Two harmonics logs record various harmonics data, including K-factor and Total Harmonic Distortion (THD). These recorders are labeled Harm Mean Log and Harm High Log.

Factory settings for these data recorders:

- Log depth = 840 records (35 days)
- Interval = 3600 seconds (1 hour)

By default, they log the following values:

	Harm Mean Log (Data Rec 7)		
V1 THD mean	I1 THD mean	I1 K Fac mean	
V2 THD mean	I2 THD mean	I2 K Fac mean	
V3 THD mean	I3 THD mean	I3 K Fac mean	

	Harm High Log (Data Rec 8)		
V1 THD high	I1 THD high	I1 K Fac high	
V2 THD high	I2 THD high	I2 K Fac high	
V3 THD high	I3 THD high	I3 K Fac high	

Energy and Demand Log

The EgyDmd Log (Data Rec 10) records energy and demand data used by energy management software to generate reports.

Factory settings for this data recorder:

- Log depth = 3360 records (35 days)
- Interval = 900 seconds (15 minutes)

By default, it logs the following values:

Parameter	Description	
kWh del	Active energy delivered	
kWh rec	Active energy received	
kWh del-rec	Active energy delivered minus received	
kVARh del	Reactive energy delivered	
kVARh rec	Reactive energy received	
kVARh del-rec	Reactive energy delivered minus received	
kVAh del+rec	Apparent energy delivered plus received	
kW sd del-rec	Active power demand delivered minus received	
kVAR sd del-rec	Reactive power demand delivered minus received	
kVA sd del+rec	Apparent power demand delivered plus received	

Daily Nominal Log

The DailyNom Log (Data Rec 39) provides information about the meter's nominal settings.

Factory settings for this data recorder:

- Log depth = 450 records
- Interval = Triggered on demand

By default, it logs the following values from the Factory module's setup registers:

Parameter	Description
FAC1 Vnominal	Nominal voltage setting
FAC1 NomFreqNum	Expected frequency of operation

Rapid Voltage Change Log

The RVC Log (Data Rec 23) provides details of rapid voltage changes related to sag/swells (power quality events). This data recorder is disabled by default.

Factory settings for this data recorder:

- Log depth = 100 records
- Interval = Triggered on demand

If enabled, it logs the following by default:

SS1 Delta Umax	SS1 Delta Uss	SS1 RVC Duration	

For more information on how to enable the Rapid Voltage Change Log, see "Configuring Advanced Power Quality" on page 204.

Sag/swell Log

The Sag/swell Log (Data Rec 5) provides details of power quality events.

Factory settings for this data recorder:

- Log depth = 100 records
- Interval = Triggered on demand

By default, it logs the following values:

SS1 DistDur	SS1 DistV1Min	SS1 DistV1Max	SS1 DistV1Avg
SS1 DistV1Engy	SS1 DistV2Min	SS1 DistV2Max	SS1 DistV2Avg
SS1 DistV2Engy	SS1 DistV3Min	SS1 DistV3Max	SS1 DistV3Avg
SS1 DistV3Engy	SS1 DistNominal	SS1 Swell Lim	SS1 Sag Lim

For more information on how to configure sag/swell logging, see "Configuring sag and swell logging" on page 200.

Sg/Sw HS Log

The Sg/Sw HS Log (Data Rec 6) captures high-speed (half-cycle) voltage and current data that includes pre-event and post-event records related to the sag/swell event. This data recorder is disabled by default.

If enabled, it logs the following by default:

HS VIn a	HS VII ab	HSTa	HS Freq
HS VIn b	HS VII bc	HSIb	PQA1 Vavg Sliding Ref Voltage
HS VIn c	HS VII ca	HSIc	

For more information on how to enable the Sg/Sw HS Log, see "Configuring sag and swell logging" on page 200.

Transient Log

The Transient Log (Data Rec 15) provides details of power quality events. Factory settings for this data recorder:

Factory settings for this data recorder:

- Log depth = 100 records
- Interval = Triggered on demand

By default, it logs the following values:

TR1 TranV1Dur	TR1 TranV3Dur	PM1 PT Prim
TR1 TranV1Max	TR1 TranV3Max	PM1 PT Sec
TR1 TranV2Dur	TR1 TranNominal	PM1 CT Prim
TR1 TranV2Max	TR1 Threshold	PM1 CT Sec

EN 50160 compliance logs

The EN 50160 compliance logs are used to record EN 50160 compliance counters:

Data recorder	Description
EN50160 Flicker (Data Rec 18)	Flicker
EN50160 Frq/Mg (Data Rec 17)	Power frequency and supply magnitude
EN50160 Hrm VIt (Data Rec 29)	Voltage harmonics
EN50160 Ihm VIt (Data Rec 30)	Voltage interharmonics
EN50160 Intrp (Data Rec 24)	Short/long interruptions
EN50160 MSignal (Data Rec 31)	Evaluation of mains voltage signals
EN50160 Prm-f/V (Data Rec 32)	Frequency and supply voltage statistics
EN50160 Prm-Flk (Data Rec 33)	Flicker statistics (Pst and Plt)
EN50160 PrmHrm1 (Data Rec 12)	Harmonics statistics
EN50160 PrmHrm2 (Data Rec 11)	Harmonics statistics overflow
EN50160 Swell (Data Rec 25)	Voltage swells
EN50160 VIt Dp1 (Data Rec 19)	Supply voltage dips
EN50160 VIt Dp2 (Data Rec 20)	Supply voltage dips
EN50160 Vunbal (Data Rec 28)	Voltage unbalance

The meter logs EN 50160 counter data for present and previous observation periods as well as EN 50160 events.

For more information about EN 50160, see the <u>Power Quality: ION Meters and EN50160:2010</u> technical note, available on www.se.com.

IEC 61000-4-30 logs

The IEC 61000-4-30 logs are used to log parameters related to the International Electrotechnical Commission's IEC 61000-4-30 standard and to create reports:

4-30 3s RMS Log (Data Rec 38)			
PqFlag 2s ivd	I1 3s	V1 OverDev 3s	V3 OverDev 3s
V1 3s	12 3s	V2 UnderDev 3s	
V2 3s	l3 3s	V2 OverDev 3s	
V3 3s	V1 UnderDev 3s	V3 UnderDev 3s	

4-30 10mRMS Log (Data Rec 16)			
PqFlag 10m	PQA1 I1 10m	V1 OverDev 10m	V3 OverDev 10m
V1 10m	PQA1 I2 10m	V2 UnderDev 10m	Power Freq 10m
V2 10m	PQA1 I3 10m	V2 OverDev 10m	
V3 10m	V1 UnderDev 10m	V3 UnderDev 10m	

4-30 2hrRMS Log (Data Rec 37)			
PqFlag 2hr	I1 2hr	V1 OverDev 2hr	V3 OverDev 2hr
V1 2hr	l2 2hr	V2 UnderDev 2hr	Power Freq 2hr
V2 2hr	13 2hr	V2 OverDev 2hr	
V3 2hr	V1 UnderDev 2hr	V3 UnderDev 2hr	

4-30 3s THD Log (Data Rec 26)			
PqFlag 3s THD	V3 THD 3s	I3 THD 3s	IUnbal u2 3s
V1 THD 3s	I1 THD 3s	Vunbal u2 3s	IUnbal u0 3s
V2 THD 3s	I2 THD 3s	Vunbal u0 3s	

4-30 10mTHD Log (Data Rec 27)			
PqFlag 10m	V3 THD 10m	PQ I3 THD 10m	IUnbal u2 10m
V1 THD 10m	PQ I1 THD 10m	Vunbal u2 10m	IUnbal u0 10m
V2 THD 10m	PQ I2 THD 10m	Vunbal u0 10m	

4-30 2hrTHD Log (Data Rec 34)			
PqFlag 2hr	V3 THD 2hr	I3 THD 2hr	IUnbal u2 2hr
V1 THD 2hr	I1 THD 2hr	Vunbal u2 2hr	IUnbal u0 2hr
V2 THD 2hr	I2 THD 2hr	Vunbal u0 2hr	

4-30 10s Freq (Data Rec 21)	
Power Frequency	PqFlag 10s

4-30 Intrp Log (Data Rec 22)

V Intrp DrtnAll (voltage interruption duration - all voltages)

For more information, see the <u>IEC 61000-4-30 compliance and ION meters</u> technical note, available on www.se.com.

IEEE 519 compliance logs

The IEEE 519 compliance logs are used to record IEEE 519 compliance parameters:

Data recorder	Description
519 Hrm I-X (Data Rec 35)	Current harmonics statistics and counters: Weekly 95th percentile 10 min intervals
519 Hrm I-Y (Data Rec 36)	Current harmonics statistics and counters: Weekly 99th percentile 10 min intervals
519 Hrm I-Z (Data Rec 14)	Current harmonics statistics and counters: Daily 99th percentile 3 s intervals
519 Hrm V-X (Data Rec 42)	Voltage harmonics statistics and counters: Weekly 95th percentile 10 min intervals
519 Hrm V-Z (Data Rec 13)	Voltage harmonics statistics and counters: Daily 99th percentile 3 s intervals
I1 Hrm 1-16 (Data Rec 44)	I1 current harmonics - 10 min
I1 Hrm 17-32 (Data Rec 50)	I1 current harmonics - 10 min
I1 Hrm 33-48 (Data Rec 56)	I1 current harmonics - 10 min
I2 Hrm 1-16 (Data Rec 45)	I2 current harmonics - 10 min
I2 Hrm 17-32 (Data Rec 51)	I2 current harmonics - 10 min
I2 Hrm 33-48 (Data Rec 57)	I2 current harmonics - 10 min
I3 Hrm 1-16 (Data Rec 46)	I3 current harmonics - 10 min
I3 Hrm 17-32 (Data Rec 52)	I3 current harmonics - 10 min
I3 Hrm 33-48 (Data Rec 58)	I3 current harmonics - 10 min
V/I Hrm 49-50 (Data Rec 59)	V1, V2, V3, I1, I2, I3 harmonics - 10 min
V1 Hrm 1-16 (Data Rec 40)	V1 voltage harmonics - 10 min
V1 Hrm 17-32 (Data Rec 47)	V1 voltage harmonics - 10 min
V1 Hrm 33-48 (Data Rec 53)	V1 voltage harmonics - 10 min
V2 Hrm 1-16 (Data Rec 41)	V2 voltage harmonics - 10 min
V2 Hrm 17-32 (Data Rec 48)	V2 voltage harmonics - 10 min

Data recorder	Description
V2 Hrm 33-48 (Data Rec 54)	V2 voltage harmonics - 10 min
V3 Hrm 1-16 (Data Rec 43)	V3 voltage harmonics - 10 min
V3 Hrm 17-32 (Data Rec 49)	V3 voltage harmonics - 10 min
V3 Hrm 33-48 (Data Rec 55)	V3 voltage harmonics - 10 min

Configuring data logging using ION Setup

Use ION Setup to configure the meter's data recorders.

Changing the meter's data recorder configuration clears existing data in that data recorder.

NOTICE

DATA LOSS

Ensure that all important data is recorded before configuring data recording.

Failure to follow these instructions can result in data loss.

To configure data logging using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click **Logging > Memory**.
- 4. In the **Status** tab, select the data log and click **Edit**.

The **Log Depth Setup** window appears.

5. Configure the settings as applicable:

Parameter	Description
Log Interval	How frequently records are logged
Log Depth	Maximum number of records stored in the log
Log Memory	Information only. This is automatically calculated, and displays how much memory the log uses based on the Log Interval and Log Depth
Log Storage	Information only. This is automatically calculated, and displays how much total memory is left after subtracting the Log Memory usage

Waveform recording

The meter's factory-configured waveform recorders store waveform data related to power quality events.

Waveform information is used to help identify power system disturbances, which are an increasing concern for industrial plants, hospitals, data centers and other facilities where the equipment is sensitive to voltage or current sags, swells, transients, and momentary interruptions. Waveform information is also used to help ensure compliance with power quality standards.

In addition to measuring and recording numerical values for voltage and current, your meter can also capture the sinusoidal waveform data. The current and voltage waveform data provides additional information for analysis of the system's power quality or a power quality event.

When your system's nominal parameters are programmed into the meter, power quality events such as sags, swells and transients are automatically detected and voltage and current waveform data is logged. The default factory settings for sag/swell and transient detection are sufficient for most applications, but you can also modify the amount of deviation from the nominal required to trigger waveform recording.

Waveform data storage format

Your meter's waveform data storage format is defined by:

- Cycles: the number of cycles included in the waveform (its duration).
- Samples: samples per cycle, which is the number of waveform data points collected in each cycle.

This gives you the option to record a lot of information for a very short duration or less information over a longer duration. You can also configure the waveform recording to record pre-event and post-event data.

Types of waveform data

You can use your meter to detect ITI (CBEMA) - type disturbances, and determine information regarding the magnitude and duration of each disturbance. This information can be used by your energy management system to plot the disturbance on an ITI (CBEMA) curve.

COMTRADE waveform data is available from your meter.

NOTE: If you are generating COMTRADE waveform information, the associated waveform recorders cannot be modified unless COMTRADE is disabled. If the waveform recorders are not configured identically, COMTRADE waveform information will not be generated.

Key terms

Term	Definition
COMTRADE	COMmon format for TRAnsient Data Exchange (COMTRADE) is a common format for waveform data.
ITI (CBEMA)	A curve that graphically describes an AC input voltage envelope which can be typically tolerated by information technology equipment. Meter waveform information is plotted on this curve to help evaluate power quality.
Nominal	The normal or usual parameter value. For example, the nominal voltage for many power systems is 120 V.

Term	Definition
Sag	A power event where the voltage or current drops below the nominal value.
Swell	A power event where the voltage or current rises above the nominal value.
Transient	A power event where a short duration surge of electrical energy is detected.

For more information on the Waveform Recorder module, see *ION Reference*, available on www.se.com.

Default waveform recording configuration

The meter's default framework includes factory-configured waveform logs (waveform recorders).

These waveform logs and their configuration are used by other components of your power monitoring system. Do not change the default configuration of any of the logs unless you understand the impact of the change on these power monitoring system components, the data they use and your meter's memory.

Waveform Recorder modules

The factory-default Waveform Recorder modules are preconfigured to capture sag/swell and transient power quality events.

Waveform recorder	Description
Wfm Rc V1-Sg/Sw (Wform Rec 1)	V1 voltage waveforms recorded during a defined sag or swell event.
Wfm Rc V2-Sg/Sw (Wform Rec 2)	V2 voltage waveforms recorded during a defined sag or swell event.
Wfm Rc V3-Sg/Sw (Wform Rec 3)	V3 voltage waveforms recorded during a defined sag or swell event.
Wfm Rc I1-Sg/Sw (Wform Rec 5)	I1 current waveforms recorded during a defined sag or swell event.
Wfm Rc I2-Sg/Sw (Wform Rec 6)	I2 current waveforms recorded during a defined sag or swell event.
Wfm Rc I3-Sg/Sw (Wform Rec 7)	I3 current waveforms recorded during a defined sag or swell event.
Vfm Rc V1-Trnst (Wform Rec 9)	V1 voltage waveforms recorded during a defined transient event.
Vfm Rc V2-Trnst (Wform Rec 10)	V2 voltage waveforms recorded during a defined transient event.

Waveform recorder	Description
Vfm Rc V3-Trnst (Wform Rec 11)	V3 voltage waveforms recorded during a defined transient event.
Vfm Rc I1-Trnst (Wform Rec 13)	I1 current waveforms recorded during a defined transient event.
Vfm Rc I2-Trnst (Wform Rec 14)	I2 current waveforms recorded during a defined transient event.
Vfm Rc I3-Trnst (Wform Rec 15)	I3 current waveforms recorded during a defined transient event.

COMTRADE modules

The factory-default COMTRADE modules are preconfigured with their inputs linked to the *Trigger* outputs of the waveform recorders for sag/swell and transient monitoring.

COMTRADE 1 inputs (sag/swell)	Linked Waveform Recorder (<i>Trigger</i> output)
Waveform Trigger 1	Wfm Rc V1-Sg/Sw (Wform Rec 1)
Waveform Trigger 2	Wfm Rc V2-Sg/Sw (Wform Rec 2)
Waveform Trigger 3	Wfm Rc V3-Sg/Sw (Wform Rec 3)
Waveform Trigger 4	Wfm Rc I1-Sg/Sw (Wform Rec 5)
Waveform Trigger 5	Wfm Rc I2-Sg/Sw (Wform Rec 6)
Waveform Trigger 6	Wfm Rc I3-Sg/Sw (Wform Rec 7)

COMTRADE 2 inputs (transient)	Linked Waveform Recorder (<i>Trigger</i> output)
Waveform Trigger 1	Vfm Rc V1-Trnst (Wform Rec 9)
Waveform Trigger 2	Vfm Rc V2-Trnst (Wform Rec 10)
Waveform Trigger 3	Vfm Rc V3-Trnst (Wform Rec 11)
Waveform Trigger 4	Vfm Rc I1-Trnst (Wform Rec 13)
Waveform Trigger 5	Vfm Rc I2-Trnst (Wform Rec 14)
Waveform Trigger 6	Vfm Rc I3-Trnst (Wform Rec 15)

Event log

Your meter records events produced by the meter's ION modules or external meter events.

Meter events, such as meter configuration or changes to I/O state, have priority values associated with them, so you can control what events are logged. Each event has a priority based on its type and severity, and for most events you can configure the priority. The event log records the date and time of the event, along with relevant details about the event.

Your meter's event log can be viewed through ION Setup and the display.

For more information on how to view the event log, see "Viewing and downloading an event log" on page 54.

Default event log configuration

Your meter logs all configuration changes, meter access events, and power system events.

You can configure certain features, such as the digital inputs, so an event is logged when the feature changes state (for example, the digital input changes from off to on).

Your meter's event log might be used by other components of your power monitoring system. Do not change the default event log configuration unless you understand the impact of the change on the power monitoring system components and the data they use and on your meter's memory.

Changing the default event log configuration should only be undertaken by those with an advanced understanding of ION architecture and their meter's template.

The event log is controlled by the Event Log Controller module, which allows you to set a priority cutoff for event logging. Events with a priority number greater than the cutoff value are logged, and events with lower priorities are discarded. By default, this value is set so that all relevant events are recorded in the meter's event log. Event priority values range from 0 to 255 with a typical cutoff value of 5.

NOTE: Alarms are generated by events from certain ION modules. The alarm level is determined by the priority of the associated event. To disable the alarm but still record the associated event, set the alarm priority to **Info Only**. To disable the alarm and the event, set the alarm priority to **None**.

For more information on the Event Log Controller module and event priorities for specific ION modules, see *ION Reference*, available on www.se.com.

User triggered event log entries

The Event Log includes an association between security-related events and the username that was logged in to the meter during the event.

When a user produces an event, such as a reset, successful or unsuccessful login attempts, user lockout or setup change, it is written to the event log. Events created in advanced security through ION Setup or the display are associated with the username that was logged into the meter (USER1 - USER50).

Unread events in event log

View unread events in the event log. Log into ION Setup as the designated reader and switch ION Setup into Advanced mode to view unread events. A customized framework is required to setup notifications for unread events.

Assigning a designated reader for event log notification

A user can be assigned the role of designated reader for the event log.

When the *Designated Reader* is configured, an entry in the event log is considered unread until it is reviewed or backed up to external storage by the designated reader. When the designated reader is informed that the event log is nearly full, an event log review or backup strategy can be

implemented before older entries are overwritten. This feature can assist in ensuring that event log entries are not overwritten before they can be reviewed. Use ION Setup to select a user to be the designated reader.

- 1. Open ION Setup.
- 2. Ctrl + click on the meter to select it. This switches ION Setup to Advanced mode.
- 3. Open the EventLogCtl Modules folder and double click EventLogCtl.
- 4. Enter login credentials as necessary.
- 5. Click the **Setup Registers** tab.
- 6. Select Designated Reader and click Edit.
- Set Designated Reader to the user that reviews the event log (USER0 USER50) and click OK.

Syslog

Syslog uses the User Datagram Protocol (UDP) to transport event log information from the meter directly to a centralized syslog server.

The syslog server can receive logs from multiple devices, including meters, then store and filter the log information as needed. You can use ION Setup to modify the syslog network settings for your device. Syslog is a useful feature to help maintain meter log information for extended periods of time.

NOTE: Ethernet is required to use the syslog feature.

Syslog is an open standard allowing you to use any one of a number of syslog server applications currently available. The decision regarding which syslog server solution to use can be based on budget and your technical requirements. See the individual syslog server's documentation for more information.

Configuring Syslog network settings using ION Setup

To configure Syslog network settings using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Communications > Advanced Ethernet > SysLog.
- 4. Select Enable Syslog and click Edit.
- 5. Select **Yes** to enable the syslog server feature or select **No** to disable it.
- 6. Click OK.
- 7. Select Syslog Server and click Edit.
- 8. Enter the IPv4 address or an IPv6 address for the syslog server.

NOTE: You must enter the IP address for the syslog server, not the server's fully-qualified domain name.

- 9. Click OK.
- 10. Verify that the Syslog server is receiving log information from the meter.

NOTE: If the *Enable Syslog* register is enabled but the *Syslog Server* register does not contain an IP address, an event is generated in the event log to indicate that syslog is enabled with no server IP.

Syslog severity to event log priority mapping

Syslog severities map to ION event priorities (0–255).

Only four of the syslog severities are used in the mapping.

Syslog severity	ION event priority name	ION event priority range
2 - Critical condition	High	192–255
4 - Warning condition	Medium	128–191
5 - Normal but significant condition	Low	64–127
6 - Informational	None	0–63

Advanced log setup and memory optimization

You can configure your meter's logs to help ensure the integrity of critical data and to optimize the meter's memory usage.

Before you configure your meter's logs, it is important to understand how logging functions and how the settings work together.

NOTE: Configuring your meter's logs requires an in-depth understanding of the meter's memory, how the logs function and the data you are capturing.

Viewing log configuration and memory usage information

You can use ION Setup to view log settings and memory usage information for your meter's default logs.

This information can help you understand your log usage and how to optimize your logging configuration for your situation.

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.

3. Click Logging > Memory screen.

The Status tab:

- Lists the default logs, their interval (**Duration**) and depth (**Records**), if applicable, and the percentage of available memory used by the log.
- Provides information on how much of the meter's memory is used for system tasks in the System Resources list item.
- Displays the total meter memory and the percentage of memory in use versus memory available.

Log depth configuration

You can change the number of records (depth) stored in the log.

Use ION Setup to change the maximum number of records (depth) stored in the log in the meter's long-term memory.

Data logs and circular-format waveform recorders have a minimum depth of 1 record. The maximum depth is dependent on your meter's memory and the configuration of your other logs.

Log interval configuration

You can configure the logging interval, which is how frequently records are logged.

You can change the logging intervals for most logs using the ION Setup Assistant **Logging > Memory** screen.

Changing the interval for other logs (for example, logs that are related to standards or triggered by disturbances) is an advanced procedure that involves using the Advanced mode of ION Setup to modify settings in the module that is linked to the log's *Record* input. See the ION Setup help and the *ION Reference* for more information.

Programming your meter to write to any data recorder at continuous intervals shorter than 60 seconds (heavy logging configuration) can cause loss of data in the event of a power failure.

NOTICE

DATA LOSS


Use an uninterruptible power supply (UPS) if you program your meter for heavy logging.

Failure to follow these instructions can result in data loss.

Log mode configuration

You can configure the log record mode, or how the log behaves when full.

Changing how the log records information (circular or stop-when-full) is an advanced procedure that requires changing the *RecordMode* setup register in the Data Recorder and Waveform Recorder modules.



- A Circular (FIFO) logging mode: when the log is full, a new record overwrites the oldest record
- Stop-when-full logging mode: when the log is full, any new records are not logged

Log buffer configuration

The log buffer depth is the maximum number of records that can be stored in the meter's short-term memory (RAM) for a particular log.

After records are captured in the log buffer in the meter's short-term memory, they are replicated to the long-term memory. Because of inherent differences between short-term (volatile) and long-term (non-volatile) memory, records can be added more quickly to the short-term memory than they can be copied to long-term memory.

The logs in the default logging framework have their log buffer depths pre-configured to a value suitable for most applications. But you can configure the log buffer depth for your applications, if required (for example, to help ensure the continuity of critical data in high-speed logging scenarios or to optimize usage of your meter's memory for your particular logging configuration).

If you are logging data at high speeds, it is important to review your logging needs, and find the right balance between data retention and memory optimization for your particular situation.

NOTE: If you get a message that you do not have sufficient memory when you try to create a new log or change the configuration of an existing log, you may need to reduce the log buffer depths of other logs in order to make memory available for the new log.

Fully buffered logs

A fully buffered log (e.g., a Data Recorder or Waveform Recorder module) is one where the value of the Buffer Depth setup register is the same as the Depth setup register. This means the buffer (short-term memory) is set up to use all the available long-term memory allocated for that log. This ensures the buffer does not run out of space before all the records are replicated to the long-term memory, regardless of the recording speed (i.e., the rate of record captures).

You may want to use this configuration if you are logging critical data (for example, revenue logs) or logging data at frequent intervals (for example, intervals less than 60 seconds). However, it is important to note that this configuration uses the most short-term memory, or RAM (the meter has a maximum 10 MB of RAM available for the log buffer depth).

Partially buffered logs

A partially buffered log (e.g., for a Data Recorder or Waveform Recorder module) is one where the value of the Buffer Depth setup register is less than the Depth setup register. This means the buffer (short-term memory) is set up to use only a portion of the available long-term memory allocated for that log. This configuration allows for a larger log size (i.e., number of records). However this does not ensure that the buffer does not run out before all the records are replicated to the long-term memory (e.g., in the case of high-speed recording).


You may want to use this configuration for logs with intervals greater than 60 seconds or with less critical data. Because the records are partially replicated, this configuration uses less of the meter's short-term memory, or RAM, in a log that is otherwise configured the same. This allows you to make more RAM available for other logs with a higher logging frequency or more critical data.

However, depending on your configuration, there may be instances where the log buffer fills up faster than it can replicate records to long-term memory. In this case, you may lose records and see gaps in your data.

NOTE: The *Insert Outage Records* functionality does not work if the data recorder is configured as partially buffered. In order to use this functionality, you must configure the data recorder to be fully buffered. See *ION Reference*, available from www.se.com, for more information about configuring the Data Recorder module.

Example: Fully buffered log records replicated from short-term to long-term memory


In the following example, the log buffer equals the log depth and all the records are replicated in both the short-term memory and the long-term memory.



Α	Log buffer
В	Long-term memory
С	Total available space in the log buffer (for example, 20 records)


Example: Partially buffered log records replicated from short-term memory to long-term memory

In the following example, the buffer depth equals 20. The first record has already replicated to the long-term memory, making room in the log buffer for the new records (including the newest record, in gray).



Example: Resulting gaps in data when a partially buffered log is full

In the graphic on the left, the log buffer (A) is full, and the oldest record has not replicated to the long-term memory yet. This means that the new record (C) is not logged, and is permanently lost. In the graphic on the right, the oldest record (D) was replicated to long-term memory, making space in the buffer. The new record at the next interval (E) is logged but there is a gap in the data for the lost record (C).



- A Log buffer

 B Long-term memory

 C Record that cannot be logged because log buffer is full (this record is lost)

 D Record moving from short-term memory to long-term memory
- E New record at next interval

Changing log interval and depth settings using ION Setup

You can configure log intervals, log depths and buffer depths to optimize your memory usage. Before you begin, make sure you understand:

- the structure of the meter's logging framework
- the meter's existing logging configuration
- · your data logging requirements

Changing your meter's log configuration deletes all existing records from that log.

NOTICE

DATA LOSS

Ensure that all important data is recorded before configuring a log.

Failure to follow these instructions can result in data loss.

The default log settings are designed to meet the needs of most users.

This procedure provides the steps for configuring settings for a subset of data logs using the ION Setup Assistant. Configuring these settings for custom logs, and logs not listed in the **Logging > Memory** screen, is an advanced procedure; see the ION Setup help for more information.

- 1. Start ION Setup.
- 2. Open the Setup Assistant for your meter.
- 3. Click Logging > Memory.
- 4. Select the log you want to edit and click **Edit.**
- 5. Set the log depth and log interval as required for your logging needs.
 - Log Interval: you can change the interval units to seconds, minutes, hours or days.
 - Log Depth: You can set the depth in time (seconds, hours, days, etc.) or the number of records.

NOTE: For some log types, you only set the log depth (for example, waveform recorders).

Log Memory shows the estimated impact of the changes on the total size of the log and **Log Storage** displays the estimated available log memory on the meter.

NOTE: If you receive a message stating that there is not enough memory when you change a log's configuration, check the configuration of your meter's other logs. You may not have enough RAM, or short-term memory, to allow for the new configuration. You may need to use Advanced mode to check the detailed configuration of your logs.

6. Click Finish.

NOTE: You may see a **Next** button instead of **Finish**. In this case, the next screen allows you to configure the buffer depth for the log. The screen displays the overall log depth and a field for setting the log buffer depth. It also shows the impact of the **Buffer Depth** setting to your meter's short-term memory (RAM).

Time and timekeeping

Time and timekeeping overview

Your meter's internal clock is used for keeping time, timestamping data, and determining intervals for time-based measurements.

Local meter time is displayed based on the meter's time sync source and the settings used for time zone and daylight savings time. You can configure and view your meter's date and time information using ION Setup, or the display.

Your meter monitors time using the frequency of an internal oscillator or the frequency of the line power being measured. Your meter's battery powers the internal clock so that time is maintained when the meter is unpowered.

Your meter supports different time types and time synchronization methods to adjust its internal clock. To improve your meter clock's accuracy, you can use an external time reference such as a Global Positioning System (GPS) signal, Network Time Protocol (SNTP/NTP) server or Precision Time Protocol (PTP) leader.

For more information, see the <u>Time Synchronization and Timekeeping</u> technical note, available on www.se.com.

For more information on the Clock module, see ION Reference, available on www.se.com.

Internal clock temperature compensation

The time accuracy of the meter has been improved by compensating for clock drift if the meter's operating temperature falls outside the optimum temperature range.

Your meter's internal clock is adjusted based on the internal clock temperature compensation parameters.

Time synchronization

Your meter's clock controls the timing of metering parameters, such as demand intervals or power quality measurement aggregation over time intervals.

Adjustments to the clock are made by synchronizing the meter's time with another time source, determined by the *Time Sync Source*. Time synchronization messages can be automatically generated and sent to your meter from your energy management system software or other time sources such as an SNTP/NTP server, PTP leader, or GPS receiver. You can also manually trigger a time synchronization message from your energy management system or configuration software.

NOTE: To help maintain data integrity, some energy management systems impose a blackout rule where time synchronization messages near energy interval boundaries are ignored.

Supported time synchronization sources

Several time synchronization sources are available to your meter.

Time sync source	Description
Meter configuration software (ION Setup)	Configuration software can manually synchronize the time of your meter based on the clock of the computer running the configuration software. Configuration software synchronization is usually performed when the meter is initially commissioned.
Energy management system	Energy management systems can synchronize the time of your meter to be consistent with other meters on the network.
GPS receiver (IRIG-B) ¹	A GPS receiver using IRIG-B can synchronize the time of a meter up to \pm 1 ms of Coordinated Universal Time (UTC). A dedicated serial network is required to implement a GPS scheme. For IRIG-B, one of your meter's digital inputs must be connected to the IRIG-B network, and the digital input must be configured for IRIG-B time synchronization in addition to configuring your meter's clock.
GPS over serial	A GPS receiver can synchronize the time of a meter up to \pm 1 ms of Coordinated Universal Time (UTC). For GPS over serial, your meter's serial port must be connected to a GPS receiver, and the serial port communications must be configured with the correct protocol setting.
Simple Network Time Protocol (SNTP)	SNTP can synchronize the time of your meter up to \pm 1 second of other meters on an Ethernet network. For SNTP time synchronization, your meter must be connected to an Ethernet network that has an active SNTP server and be configured with the server's information.
Network Time Protocol (NTP)	NTP can typically synchronize the time of a meter to ± 10 to 100 ms, depending on network configuration. To implement NTP time synchronization, your meter must be connected to an Ethernet network that has an active NTP server and be configured with the server's information.
Precision Time Protocol (PTP) ²	PTP can synchronize the meter time to \pm 1 ms of other devices connected to a local area network. To implement PTP time synchronization, your meter must have PTP selected as the time sync source and be connected to an Ethernet network that has a valid PTP grandmaster.

¹ Use the digital inputs located on the meter base for IRIG-B time synchronization and other high-accuracy applications.

Clock source

The *Clock Source* setup register defines the meter's representation of a one second period, and can be set to:

² This clock precision assumes your meter is installed in a Star network topology only.

Setting option	Description	
Line Frequency	The meter monitors the ISO Grid Operation line frequency, and adjusts the one second period based on the measured line frequency. All devices connected to the grid network are synchronized to maintain a consistent time base. If a power outage occurs, the clock automatically synchronizes with the meter's internal crystal until power is restored. Once power is restored, the clock resynchronizes with the line frequency. NOTE: Do not use line frequency when your meter is synchronized to an external time sync source.	
Internal	The meter clock is synchronized to the meter's internal crystal.	
	The meter clock is synchronized to an external time sync source. Use this for the <i>Clock Source</i> if:	
Comm	 The Time Sync Source setup register is set to a serial communications port to receive GPS time synchronization signals. 	
	The <i>Time Sync Source</i> setup register is set to ETHERNET-PTP and your meter is installed in a trusted PTP network.	
	The Time Sync Source setup register is set to IRIG-B.	

Clock source time quality flag

The meter's clock source time quality flag is primarily used to report time quality information for digital input events, such as status alarms, in Sequence-of-Events Recording (SER) applications.

The meter keeps track of the time difference between the meter's internal clock and the time sync source.

When the meter's Clock module's *Use Clock Source Qual Flag* is set to use flag, the Diagnostics module's *Receiver Status* output register is set to:

- LOCKED if the time difference between the GPS time sync source or PTP leader and meter clock is within ±1 ms of each other
- UNLOCKED if the time difference between the GPS time sync source or PTP leader and meter clock is greater than ±1 ms of each other

PTP system setting recommendations


By default, your meter is configured to be compatible in typical PTP supported systems.

In a PTP system, the grandmaster clock determines the reference time for the entire system. To ensure correct implementation and operation of the protocol, it is recommended to set the following parameters in your system grandmaster clock:

Parameter	Setting	Description
PTP device type	End to End transparent clock	A transparent clock that supports the use of the end-to- end delay measurement mechanism between slave clocks and the leader clock.
Peer delay mechanism	2 step	A clock that provides time information using the combination of an event message and a subsequent general message.
Clock domain	0–3	A logical grouping of clocks that synchronize to each other using the protocol, but that are not necessarily synchronized to clocks in another domain
Ethernet switches	PTP V2 compatible	All switches and other devices in the network must support IEEE 1588 PTP V2 to achieve the stated time precision and accuracy

Star network topology

In addition to PTP system related settings, the accuracy of your meter clock also depends on your physical network configuration. A star network topology is required to achieve the level of clock precision specified.



A Ethernet switch or hub

B Ethernet connected meters

C PTP leader clock

Configuring time information using ION Setup

You can set the time, date, and time synchronization settings using ION Setup.

NOTE: You must manually adjust the date and time information if the device is installed in a different time zone location from the computer running ION Setup.

To configure time information using ION Setup:

- 1. Start ION Setup.
- 2. Open the Setup Assistant for your device.
- 3. Click Clock > Timezone.
- 4. Select any parameter, and then click **TimeSync** to synchronize your device's date and time with the computer that is running ION Setup.

NOTE: **Time Sync Source** must match the device connection type to ION Setup for **TimeSync** to work.

- 5. Click **DST Settings** to modify your meter's daylight savings time (DST) start and end dates, if required.
- 6. Select the parameter that you want to configure, and then click **Edit**. Enter the password if prompted.

Parameter	Value	Description
TimeZone –	_	Sets the time zone based on the time zones available from the computer's operating system.
		TIP : You can synchronize the computer's DST settings with the meter while editing this parameter.
	UTC or LOCAL	Specifies the time format of the time sync message.
Timo Syno		UTC (Coordinated Universal time) is equivalent to Greenwich Mean Time (GMT).
Time Sync Type		LOCAL is the local time with DST and time zone information applied.
		 For SNTP/NTP and PTP time synchronization, set the Time Sync Type to UTC.

Parameter	Value	Description
		Sets which device port accepts time synchronization messages.
Time Sync Source	COM1, COM4, ETHERNET, ETHERNET - ION, ETHERNET - DNP, ETHERNET - PTP, IRIG-B	 Time synchronization messages on other ports are ignored. For GPS time synchronization, set the Time Sync Source to COM1 (or COM4). For SNTP/NTP time synchronization, set the Time Sync Source to ETHERNET. For ION time synchronization, set the Time Sync Source to ETHERNET - ION. For DNP time synchronization, set the Time Sync Source to ETHERNET - DNP. For PTP time synchronization, set the Time Sync Source to ETHERNET - PTP. For IRIG-B time synchronization, set the Time Sync Source to IRIG-B.
Clock Source	Internal, COMM, Line Freq	 Sets the source for the clock: Internal: the meter's internal clock. COMM: the meter's communication port (used by the IRIG-B, GPS or ETHERNET - PTP time sync source). Line Freq: uses the measured line frequency of the power system as the clock source.
DST Offset	Numeric Bounded Format/Elapsed Interval Format	Specifies the amount of time the displayed local time is moved forward when entering Daylight Savings. A value of zero disables this feature and local time is not adjusted for DST.
Start of the Week	Monday–Sunday	Specifies the start day of the week used for Trending and Forecasting. NOTE: Changing the start day of the week clears all trending and forecasting data.

7. (Optional) If using SNTP/NTP time synchronization, enter the following information under **Communications > Advanced Ethernet > NTP**:

Parameter	Value	Description
	NTP, SNTP, No	NTP: specifies NTP time synchronization.
Enable NTP		SNTP: specifies SNTP time synchronization.
Time Sync		No: neither NTP nor SNTP time synchronization are used.
NTP Time Sync	Numeric value or elapsed	Specifies how often the meter synchronizes over SNTP
Interval	interval value	NOTE: This parameter is not used for NTP.
Event Logging	0.000001 to	Specifies the minimum time difference (in seconds) for a time synchronization to be logged as an event.
Threshold (NTP and PTP only)	1.000000	This parameter can be configured to help prevent the meter's event log from being flooded with time synchronization events.
NTP Server	Server IP address or domain name	Specifies the IP address (or fully qualified domain name if DNS is active) of the SNTP or NTP server.

8. (Optional) If using serial GPS time synchronization, enter the following information under **Communications** > **Serial** settings:

Parameter	Description
Protocol	Select the GPS setting that matches your GPS receiver.
Baud rate	The recommended baud rate for GPS time synchronization is 19200 bps.
Serial port	The recommended stop bits/parity for GPS time synchronization is 8N1.

Configuring time information using the display

Use the meter's display to configure time parameters.

NOTE: If your device is installed in a region where DST is observed, it is recommended to use ION Setup to configure the time zone for your locale.

- 1. Press Setup Menu > Date/Time/Clock Setup > Date & Time Setup.
- 2. Configure your time and date formats, time zone offset, and daylight savings time offset. Press the down button to access the **Clock Setup** screen.
- 3. Configure the clock and time synchronization source, and the time synchronization time format.

Date and time setup

Parameter	Values	Description
Time Format	12 H, 24 H	Specifies how the time is displayed.
Date Format	MM/DD/YYYY, DD/MM/YYYY, YYYY/MM/DD	Specifies how the date is displayed.
TZ Offset	-12:00:00 to 13:00:00	Sets the time zone of the meter's location, relative to UTC.
DST Offset	-3:00:00 to 3:00:00	Sets the daylight savings time offset of the meter's location.

Clock setup

Parameter	Values	Description
Clock Source	Internal, Line Freq, COMM	Specifies the time synchronization source.
Time Sync Source	COM1, COM4, ETHERNET, ETHERNET - ION, ETHERNET - DNP, ETHERNET - PTP, IRIG-B	Specifies the port to receive time synchronization signals.
Time Sync Type	UTC, Local	Specifies whether time synchronization signals are received in local time or UTC.

Measurements

Energy

Your meter provides bi-directional, 4-quadrant, revenue accurate energy metering:

- kWh, kVARh, kVAh delivered and received
- · kWh, kVARh, kVAh net (delivered minus received)
- kWh, kVARh, kVAh total (delivered plus received)
- · Volt-squared-hours and amp-squared-hours
- Integration of any instantaneous measurement

Energy parameters can be logged automatically on a programmed schedule.

All energy values represent the total for all three phases.

Demand

Your meter supports several demand calculation methods, including block, rolling block, synchronized and predicted demand.

It can measure demand on any instantaneous value and record peak (maximum) demand with time and date information.

- kW, kVAR, kVA demand
- kW, kVAR, kVA peak demand
- · Amps, Volts demand

Instantaneous measurements

Your meter provides one second and half-cycle true RMS readings.

Instantaneous readings include:

- 3-phase voltages (line-to-line, line-to-neutral): per phase and average
- Line-to-earth voltages per phase and V4, neutral-to-earth voltage
- 3-phase currents: per phase and average
- · I4 and I5 currents, measured
- Residual current, calculated (I calc res)
- Active (kW), reactive (kVAR) and apparent (kVA) power: per phase and total
- Power factor per phase and total
- System frequency
- Voltage and current unbalance
- · Phase reversal

Harmonics

Your meter provides harmonic distortion metering, recording, and real-time values for all voltage and current inputs.

Your meter can measure and record:

- Individual harmonics, including magnitude and phase angle
- Interharmonics
- Total even harmonic distortion (TEHD)
- Total odd harmonic distortion (TOHD)
- Total harmonic distortion (THD)
- Total demand distortion (TDD)
- K-factor
- Crest factor

Min/max recording

Your meter records new minimum and maximum data every recording interval for a variety of values.

- · Voltage and current
- kW, kVAR and kVA
- Power factor
- Frequency
- Voltage unbalance

Power quality measurements

Your meter monitors the voltage channels to detect and record power quality events.

Disturbance event recording

The meter measures and records:

- Sag/swells: ITIC/CBEMA and SEMI curves
- Transients: 20 µs or longer on any voltage channel

Power quality standards logging

The meter logs power quality standards data according to:

- EN 50160, including Flicker
- IEC 61000-4-30 Class A
- IEEE 519

Advanced power quality features

The meter supports advanced power quality features:

 Disturbance Direction Detection: The meter can capture sag/swell and transient disturbances, analyze the information, and determine the direction of the disturbance relative to the meter. Determining the source of a disturbance more quickly and accurately helps prevent repeat occurrences and also helps to minimize facility downtime.

- COMTRADE: The meter can save waveform data in COMmon format for TRAnsient Data Exchange (COMTRADE) format. COMTRADE data is available for download using an SFTP client application.
- Setpoint learning: You can configure your meter to learn certain disturbance-related values.
 For example, what constitutes a sag, swell, transient, or high or low setpoint.

Power and power factor

The sampled measurements taken at the meter's voltage and current inputs provide data for calculating power and power factor.

In a balanced 3-phase alternating current (AC) power system source, the AC voltage waveforms on the current-carrying conductors are equal but offset by one-third of a period (a phase angle shift of 120 degrees between the three voltage waveforms).

Power factor (PF)

Power factor (PF) is the ratio of real power (P) to apparent power (S).

$$PF = \frac{P}{S}$$

PF is provided as a number between -1 and 1 or as a percentage from -100% to 100%, where the sign is determined by the convention.

A purely resistive load has no reactive components, so its power factor is 1 (PF = 1, or unity power factor). Inductive or capacitive loads introduce a reactive power (Q) component to the circuit which causes the PF to become closer to zero.

True PF and displacement PF

The meter supports true power factor and displacement power factor values:


- True power factor includes harmonic content.
- Displacement power factor only considers the fundamental frequency.

NOTE: Unless specified, the power factor displayed by the meter is true power factor.

Apparent, active, and reactive power (PQS)

Apparent power (S) is the capacity of your measured power system to provide active (real power, P) and reactive power (Q).

A typical AC electrical system load has both resistive and reactive (inductive or capacitive) components. Resistive loads consume real power (P). Reactive power (Q) is either consumed (inductive loads) or generated (capacitive loads).



The units for power are watts (W or kW) for real power P, vars (VAR or kVAR) for reactive power Q, and volt-amps (VA or kVA) for apparent power S.

Positive real power P(+) flows from source to load, and negative real power P(-) flows from the load to the power source.


Current phase shift from voltage

Electrical current can lag, lead, or be in phase with the AC voltage waveform, and is typically associated with the type of load — inductive, capacitive or resistive.


For purely resistive loads, the current waveform is in phase with the voltage waveform. For capacitive loads, current leads voltage. For inductive loads, current lags voltage.

The following diagrams show how voltage and current waveforms shift based on load type under ideal (laboratory) conditions.


Current and voltage in phase (resistive)



Current leads voltage (capacitive)



Current lags voltage (inductive)



Power demand

Power demand is a measure of average power consumption over a fixed time interval.

NOTE: If not specified, references to demand are assumed to mean power demand.

The meter measures instantaneous consumption and can calculate demand using various methods.

Peak demand

Peak (or maximum) demand is the highest demand level recorded over the billing period.

Power utilities generally bill commercial customers based on their peak usage levels, called peak demand (in kW) and energy consumption (in kWh). Peak (or maximum) demand is the highest demand level recorded over the billing period. You can view peak demand values on your meter's display.

Your meter calculates the average current demand and kW, kVAR and kVA demand using sliding window demand methods. It supports coincident demand values when a peak demand is detected.

Your meter's default configuration is suitable for most applications, or you can customize it for your specific application. You can configure the minimum time between consecutive demand resets.

NOTE: If not specified, references to demand are assumed to mean power demand.

Peak demand reset lockout

The demand reset lockout time sets the minimum time allowed between consecutive demand resets; the meter ignores any attempts to reset demand that occur within the lockout period.

The peak demand reset lockout period is user-configurable (typical default value is 25 days).

See the ION Setup online help for instructions on how to configure demand peak and the demand reset lockout period on your meter.

For more information on how Sliding Window Demand modules measure and calculate demand values, see *ION Reference*, available on www.se.com.

Sliding window demand

To calculate demand values, your meter uses the sliding window averaging (or rolling interval) method which divides the demand interval into a set number of subintervals of specified duration.


The demand is measured based on the average load level over the most recent set of subintervals. Sliding window demand also provides predicted demand values.

Examples of sliding window demand


This example shows two different ways of configuring a 15-minute demand interval:

- Single interval (also called block or timed block): the 15-minute demand interval is defined as
 a single subinterval with a duration of 15 minutes.
- Sliding window (also called rolling block): the 15-minute demand interval is defined as three subintervals with a duration of 5 minutes each. This method offers better response time than a single interval.

Single interval (block)



Sliding window (rolling block)



Incremental energy

Incremental energy allows you to define a start time, end time, and the time interval (increments) for incremental energy accumulation.

At the end of each interval, the energy accumulated during that period is stored. By default, the meter only records the previous interval's incremental energy and the instantaneous energy accumulations in the active interval.

The first interval of incremental energy accumulation begins at the specified start time. Incremental energy ends at the specified end time, which may result in a truncated interval if the interval duration does not divide evenly into the overall incremental energy duration. For example, an interval duration of three hours with an overall duration of five hours truncates the last interval duration to two hours. The latest value for the specified end time is midnight (24:00).

Your start time must be before the end time and after midnight, and the period over which incremental energy is accumulated cannot include midnight. This is because your meter's start and end times are defined relative to midnight.

Start: 6AM, End: 12AM, interval: 3 hrs	Incremental energy accumulates from 6AM to midnight in intervals of 3 hours.
Start: 6AM, End: 2AM, interval: 3 hrs	Incremental energy will not function. End time must be after start time and before or equal to midnight.

Incremental energy helps provide information for analyzing energy and power usage against present or future utility rates, and is useful for measuring energy consumption by shift or for a specific process.


When configuring incremental energy, shorter incremental energy periods provide more granular data which can make the data easier to use for comparison purposes.

Example: Incremental energy

Start time: 8AM or 08:00

End time: 12AM or 24:00

Interval: 420 minutes (7 hours)



- A First interval (08:00 to 15:00)
- B Second interval (15:00 to 22:00)
- C Third interval (22:00 to 24:00)

The first incremental energy interval is from 8AM (start time) to 3PM, and is 7 hours long. The second incremental energy interval is from 3PM to 10PM, and is also 7 hours long. The third interval is from 10PM to 12AM, and is only 2 hours long because 12AM is the specified end time. These intervals repeat every 24 hours until the configuration is changed or incremental energy feature is disabled.

Configuring incremental energy using ION Setup

You can configure incremental energy using ION Setup.

- 1. Start ION Setup.
- 2. Open the Setup Assistant for your meter.
- 3. Click Energy Applications > Incremental Energy.

- 4. Select Status and click Edit. The Incremental Energy Setup screen is displayed.
- 5. Select **Enable** to display parameters for configuration.
- 6. Select the parameter to configure.

NOTE: Configuring any parameter resets the incremental energy values recorded by your meter.

Parameter	Range	Description
Start time	12:00 am to 11:59 pm	The incremental energy first interval's start time. The start time must be prior to the end time for energy accumulation.
End time	12:01 am to 12:00 am	The end time for incremental energy. The end time must be after the start time and be less than or equal to 12AM (midnight).
Interval duration	Configurable	The increment period for the incremental energy duration.

7. Click **OK** to save your changes.

Conditional energy

Conditional energy allows you to define an accumulation period for real and reactive energy using one of your meter's digital inputs.

You can use conditional energy to track four-quadrant accumulated energy during a specific period. For example, you can track accumulated energy values during a particular process that is controlled by a programmable logic controller (PLC).

Conditional energy is accumulated until it is reset. The conditional energy reset date and time information is stored in the meter's event log.

Configuring conditional energy using ION Setup

You can enable and configure conditional energy settings using ION Setup.

When configuring your meter, the configuration interface may show all of the possible ports, regardless of what is physically available on your meter.

One of your device's digital inputs must be connected and configured to define when conditional energy is accumulated.

- 1. Start ION Setup.
- 2. Open the Setup Assistant for your meter.
- 3. Click **Energy Applications > Digital Input Based**. Review the digital inputs assigned to applications to help ensure there are no conflicting usages.
- 4. Select **Conditional Energy** and click **Edit**. The Conditional Energy Setup screen is displayed.
- 5. Click **Enabled** to enable the conditional energy feature.

6. Click **Select** to define the digital input. The input's state determines whether conditional energy is accumulated. When this digital input is on, conditional energy is accumulated.

NOTE: It is recommended to set **Assigned Input** to No Connection to disable the conditional energy feature by removing any port associations.

7. Click **OK** to save your configuration.

Trending and forecasting overview

Trending and forecasting is a feature on your device that predicts the next set of measured or calculated data by plotting and analyzing trends in historical data.

Trending and forecasting data is a useful tool to help analyze changes in load and power quality and forecasting values such as demand. For your meter's trending and forecasting feature to work, you only need to give the meter time to accumulate data.

For more information on the Trending and Forecasting module, see *ION Reference*, available on www.se.com.

Trending and forecasting implementation

Data used for trending and forecasting is logged for specific intervals:

- · Every hour for the last 24 hours
- · Every day for the last month
- · Every week for the last 8 weeks
- Every month for the last 12 months

The following parameters are configured for trending and forecasting using ION Setup:

kW sd del-rec (demand)	Freq (frequency)
VII ab	l a mean
VII bc	l b mean
VII ca	I c mean
VII avg	l avg mean

You can configure the start day of the week for trending and forecasting using the **Clock** setup assistant in ION Setup.

Viewing trending and forecasting data on your meter's webpages

You can select data for forecasting and trending and view the resulting information using your meter's webpages.

For trending and forecasting to operate, your meter must have accumulated data for at least two of the specified intervals. For example, if you want to view a daily graph, your meter must have accumulated data for at least two previous days before the present day.

To view trending and forecasting data on your meter's webpages:

- 1. Log in to your meter's webpages.
- 2. Click Monitoring > Trending & Forecasting.
- 3. Select the Target and Interval. The graph for the selected data is displayed.

Resets

Resets overview

Resets allow you to clear accumulated parameters stored on your meter, reinitialize the meter or reinitialize meter accessories.

Meter resets clear your meter's onboard data logs and other related information. Resets are typically performed after you make changes to the meter's basic setup parameters to clear invalid or obsolete data to prepare the meter for active service.

NOTE: Revenue-locked meters must be unlocked to perform resets that impact revenue data. For more information, see "Revenue locking your meter" on page 295.

Option modules reset

Perform an option module reset if your option modules are not communicating with your meter.

During an option module reset, the option module may not operate normally, and digital and analog outputs may change state.

WARNING

UNINTENDED OPERATION

Do not use this device for critical control or protection of persons, animals, property, or equipment.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

You can reset your meter's option module bus using ION Setup or the display. This power cycles all the modules attached to your meter. If you have queued firmware updates for option modules on your meter's internal SFTP site, the firmware updates are performed.

By default, your meter is configured to automatically perform an option module bus reset to help keep the option modules operating normally. Contact Technical Support for instructions on changing this default configuration.

Available resets

You can perform meter resets using ION Setup, the meter webpages or the display.

Reset	Description	
	 Clears all cumulative and derived quantities from the meter, including: demand, peak demand, energy, revenue, and test mode parameters. 	
Master Reset	Clears meter event and waveform logs.	
	 Clears COMTRADE waveform records stored in the meter's internal SFTP site. 	
	Clears meter data logs.	
Peak Demand Reset	Clears meter peak demand values. NOTE: The peak demand reset has a lockout period that sets the minimum time allowed between consecutive resets.	
Min/Max Reset	Clears maximum and minimum values stored in the meter.	
Digital Input Count Reset	Clears the digital input status change counters.	
Harmonics Min/Max Reset	Clears maximum and minimum harmonics values stored in the meter.	
Disturbance Count Reset	Clears the sag/swell event counter. The sag/swell event counter counts the number of sag/swells that have occurred since the last reset or meter power-up.	
EN50160 Reset	Clears all EN 50160 parameters and statistics accumulated in the meter.	
Option Modules Reset	Resets communications to expansion modules connected to the meter.	
Conditional (Cnd) Energy Reset	Clears the conditional energy values stored in the meter.	
Input Metering Reset	Clears the input metering values stored in the meter.	

Performing resets using ION Setup

You can reset the meter using ION Setup.

Revenue-locked meters must be unlocked to perform resets that impact revenue data.

Meter resets clear the meter's onboard data logs and other related information.

NOTICE

DATA LOSS

Ensure all important data from the device is saved before performing a reset.

Failure to follow these instructions can result in data loss.

To reset the meter using ION Setup:

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Verification.
- 4. Select Normal Mode and click Display.
- 5. Select the desired tab in the **Normal Mode** dialog box. Depending on the tab selected, different resets are available.

Tab	Reset available
Energy	Master Reset
Rolling Demand	Peak Reset
	Master Reset
Volts, Amps and Power	Master Reset
Conditional Energy	Cnd Reset
	Master Reset
Input Metering IM(n) Reset NOTE: n is the input metering number, for example IM1.	

6. Click the appropriate button to perform the reset. For some resets, the meter indicates that the reset is in progress.

NOTE: Do not configure or power down your meter until it indicates that the reset is complete or some parameters may not be completely reset.

Performing resets using the meter webpages

You can reset the meter using the meter webpages.

Meter resets clear the meter's onboard data logs and related information.

NOTICE

DATA LOSS

Ensure all important data from the device has been retrieved before performing a reset.

Failure to follow these instructions can result in data loss.

To reset the meter using the meter webpages:

- 1. Connect to your meter's webpages.
- 2. Browse to Control > Resets.

3. Click Reset for the values you want to clear.

Parameter	Description		
	 Clears all cumulative and derived quantities from the meter, including: demand, peak demand, energy, revenue, and test mode parameters. 		
Master Reset	Clears meter event and waveform logs.		
	 Clears COMTRADE waveform records stored in the meter's internal SFTP site. 		
	Clears meter data logs.		
Peak Demand Reset	Clears meter peak demand values. NOTE: The peak demand reset has a lockout period that sets the minimum time allowed between consecutive resets.		
Min/Max Reset	Clears all accumulated maximum and minimum values stored in the meter.		
Digital Input Count Reset	Clears the digital input status change counters.		
Harmonics Min/Max Reset	Clears all accumulated maximum and minimum harmonics values stored in the meter.		
Disturbance Count Reset	Clears the sag/swell event counter. The sag/swell event counter counts the number of sag/swells that have occurred since power-up or the last reset to provide power quality information to energy management systems.		
EN50160 Reset	Clears all EN50160 parameters and statistics accumulated in the meter.		

Performing resets using the display

You can reset the meter using the display.

Revenue-locked meters must be unlocked to perform resets that impact revenue data.

Your meter's digital and analog outputs may change state or may not function during resets.

UNINTENDED OPERATION Do not use this device for critical control or protection of persons, animals, property, or equipment. Failure to follow these instructions can result in death, serious injury, or equipment damage.

Meter resets clear the meter's onboard data logs and related information.

NOTICE

DATA LOSS

Ensure all important data from the device has been retrieved before performing a reset.

Failure to follow these instructions can result in data loss.

To reset the meter using the display:

- 1. Press the **Home** button on the display.
- 2. Press Setup Menu > Resets.
- 3. Press the Edit button. Enter your meter's username and password.
- 4. Press the up or down icons to navigate available resets. A gray bar appears behind the active selection.

Reset	Description		
Master Reset	 Clears all cumulative and derived quantities from the meter, including: demand, peak demand, energy, revenue, and test mode parameters. 		
	 Clears meter event and waveform logs. 		
	 Clears COMTRADE waveform records stored in the meter's internal SFTP site. 		
	 Clears meter data logs. 		
Peak Demand Reset	Clears meter peak demand values.		
	NOTE: The peak demand reset has a lockout period that sets the minimum time allowed between consecutive resets.		
Min/Max Reset	Clears all accumulated maximum and minimum values stored in the meter.		
Digital Input Count Reset	Clears the digital input status change counters.		
Harmonics Min/Max Reset	Clears all accumulated maximum and minimum harmonics values stored in the meter.		
Disturbance Count Reset	Clears the sag/swell event counter. The sag/swell event counter counts the number of sag/swells that have occurred since power-up or the last reset to provide power quality information to energy management systems.		
EN50160 Reset	Clears all EN 50160 parameters and statistics accumulated in the meter.		
Option Modules Reset	Resets communications to expansion modules connected to the meter.		

- 5. Press the Check Box icon.
- 6. Press the Select icon to accept the change.

When you select Master Reset, the message all recorded data will be lost. Reset selected parameters? is displayed.

7. Press Select icon to confirm.

Firmware upgrades

Firmware upgrades overview

It is recommended to upgrade PowerLogic™ ION9000 advanced power quality meters to the latest firmware version.

Firmware version pre-v2.1.0

Before upgrading to the latest firmware version, firmware version 2.1.0 must have been previously installed. Go to www.se.com, and then search for *Upgrading Meter Firmware to v2.1.0* for information on that upgrade.

TIP: Firmware version can be identified using ION Setup, meter webpages, or the display.

Meter firmware includes a digital signature which helps ensure authenticity.

Obtaining meter upgrades

To find a recent firmware package, search for your meter type and Firmware and Associated Files.

Download the firmware upgrade package (ZIP) from www.se.com.

Upgrade information

Meter firmware

A meter upgraded to firmware version 4.5.0 or later cannot be downgraded to an earlier firmware version.

NOTICE

LOSS OF DOWNGRADE CAPABILITY

Do not upgrade to firmware version 4.5.0 or later if you need to downgrade the meter in the future.

Failure to follow these instructions can result in loss of firmware downgrade functionality.

Upgrade agent

When upgrading to firmware to version 2.1.0 or later, use upgrade agent version 2.1.0 or later.

Restart requirement

Meter restart is required.

Legacy security support

Legacy security support is an interim solution for users that use Standard security mode and is the default setting for new meters. It provides backwards compatibility with older software communicating with the meter using ION protocol.

If Standard security was used before upgrading meter firmware to v3.0.0, Legacy security support is enabled.

If Advanced security was used before upgrading meter firmware to v3.0.0, Advanced security is enabled.

RECOMMENDATION: Use Advanced security mode.

Legacy security support username	Legacy security support password	Legacy security support password range	Legacy security support password limit
User1	 Same password used before upgrade to firmware version 3.0.0., or 	0–99999999	8 characters
	0 (zero) for new meters.		

Switch ION Setup into Advanced mode to setup multiple user accounts for meters using Legacy security support: Open ION Setup > Ctrl + click on the meter to select it.

Meter firmware upgrade prerequisites

Perform back ups of all meter data, download latest ION Setup, and check the connection requirements before upgrading.

Ensure that the firmware version you are upgrading to is compatible with your meter and the version number is greater than your existing firmware.

Back up custom meter webpages

Back up webpage files if they were customized.

The upgrade process overwrites all existing meter webpages.

NOTICE

LOSS OF CUSTOM WEBPAGES

Back up custom webpages before upgrading the meter firmware.

Failure to follow these instructions can result in loss of custom webpage functionality.

To back up meter webpages, copy the **web** folder to a local folder on the computer using an SFTP client application.

Back up custom meter frameworks

Back up the meter template if the meter uses a customized meter template or frameworks.

The upgrade process overwrites all existing meter frameworks.

NOTICE

LOSS OF CUSTOM FRAMEWORKS

Back up custom frameworks before upgrading the meter firmware. The upgrade process overwrites existing meter frameworks.

Failure to follow these instructions can result in loss of custom framework functionality.

Back up accumulated energy values

Record the accumulated energy values on the meter before upgrading. Re-enter these values after the upgrade. See "Editing accumulated energy values using ION Setup" on page 288.

Download latest ION Setup

To upgrade meter firmware, the most recent version of ION Setup is required.

- 1. Start ION Setup.
- 2. Click Help > Check for Updates.
- 3. Open a web browser and go to https://www.se.com/en/download/document/ION_Setup_Latest_Release/ to download the latest version of ION Setup.
- 4. If you do not have the most recently released version, download the installation file, then run it to upgrade ION Setup.

Connection requirements

- Use a direct Ethernet TCP connection to prevent delays and upgrade failure risks associated with slower communications connection methods. You cannot perform certain firmware updates over serial or Ethernet gateway.
- The display, webpages and option module firmware updates require an SFTP over Ethernet connection.
- Use a computer connected to the same Ethernet network as the meter (physically or through a remote desktop connection).
- To upgrade option module firmware, the option modules must be connected to the meter.

Meter firmware upgrades

Use individual files such as UPX, BIN and S19 file formats to upgrade or use the firmware upgrade ZIP file with ION Setup (recommended).

Do not interrupt the upgrade process until all updates are complete.

NOTICE

UPGRADE FAILURE

Do not interrupt the upgrade process or disconnect the meter or any connected components while ION Setup is performing the firmware upgrades.

Failure to follow these instructions can result in loss of meter functionality.

Option 1 (recommended) – Upgrading using ZIP file

This is the recommended method of upgrading your meter. This method can also be used for sequential device upgrades.

Any digital and analog outputs associated with your device may change state during a firmware upgrade.

WARNING

UNINTENDED OPERATION

Do not use this device for critical control or protection of persons, animals, property, or equipment.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Loading firmware or template onto your meter clears the meter's recorded data.

NOTICE

DATA LOSS


Ensure that all important data has been recorded before uploading firmware or a template to your device.

Failure to follow these instructions can result in data loss.


- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Template > Upgrade.
- 4. Click **Upgrade** and navigate to the saved upgrade ZIP file.
- Select the upgrade ZIP file and click Open. The Compressed Device Upgrade Package window displays the updates to be installed in the order listed.

NOTE: Click the **View What's New PDF** link to read about new and updated features related to the firm upgrade.

6. Select the components you want to upgrade. For example:



- ION9000 firmware V3.0.0 package to be applied in the order listed:
 - UpgradeAgent V002.001.000.upx (not required if already applied)
 - V003.000.000.upx
- Factory V2.2.0.0.0 template is the meter template that is programmed to the meter after the firmware upgrade is complete.
- Factory V3.0.0 web pages are the files to be uploaded to the meter's web SFTP folder, to update the meter webpages with firmware-related changes.
- 7. Select the desired settings and readings to be retained, if you selected a template component:



- 8. Click OK.
- 9. Click **Proceed** to start the upgrade process.

10. Confirm upgrade status is complete and upload webpages to the meter. See "Status" on page 285 for details.

Option 2 - Upgrading using individual upgrade files

Refer to the "Firmware and templates" section in the meter's user manual for detailed instructions on how to upgrade the meter, display and option module firmware.

- 1. Follow tasks in the order listed:
 - a. UpgradeAgent V002.001.000.upx
 - b. V003.000.000.upx

To retain your meter settings, select a meter template file (DCF) to paste into the meter when performing a and b firmware upgrades. Use the **Template Paste Options** box to specify the settings to retain after the upgrade.

NOTICE

LOST SETTINGS

Always select a template file when upgrading the meter firmware.

Failure to follow these instructions can result in loss of meter settings.

2. Confirm upgrade status is complete and upload webpages to the meter. See "Status" on page 285 for details.

Status

After all required meter firmware updates are complete, ION Setup continues to perform the remaining updates.

- If you selected to upgrade the template, ION Setup will paste the template into the meter.
- If you selected to upgrade PM89RD96 remote display firmware, ION Setup will perform the display upgrade through the connected DIN rail-mounted meter.

Upgrading display firmware

For more information, see the <u>Upgrade PM89RD96 display firmware to v4.0.15</u> technical note, available on www.se.com.

Upgrading option module firmware

You can upgrade option module using ION Setup or directly through the meter's internal SFTP site.

- 1. Go to www.se.com and search for the METSEPM89M0024 or METSEPM89M2600 firmware file.
- 2. Download the firmware file.

Loading option module firmware using ION Setup

Upload firmware to option modules using ION Setup over an Ethernet connection. Each option module must be upgraded individually.

Prerequisites:

- Option module firmware upgrade (.S19) file(s). Go to www.se.com to download upgrade files.
- Option module is connected to the meter.
- · Access to meter's internal SFTP site.

Digital and analog outputs may change state during a firmware upgrade. Option modules are offline during an option module firmware upgrade; they will not communicate to the meter and the outputs may change state during the upgrade process.

A WARNING

UNINTENDED OPERATION

Do not use this device for critical control or protection of persons, animals, property, or equipment.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

If your meter's option module loses power during firmware upload, the option module will revert to its original firmware and you will have to reload the firmware file.

To load firmware option module firmware using ION Setup:

- 1. Obtain the Option Module firmware files (.S19) that you want to load onto your option module(s). Save the files where they can be accessed by the computer running ION Setup.
- 2. Start ION Setup.
- 3. Open the **Setup Assistant** for your meter.
- 4. Select the **Template** screen.
- Click the Upgrade tab, then click Upgrade. Enter your meter's password if prompted and click OK.
- 6. Navigate to where you have stored the option module firmware. Select the Option Module firmware file (*.S19) as the file type.
- 7. Select the option module firmware file and click **Open**.
 - An ION Setup window will open. Click Yes to confirm the firmware upgrade.
- 8. The Option Card Upgrade window opens. Select the Slot that corresponds to the Option Module type. You can select multiple slots for the same option module type.
- 9. Click Start.

A dialog box describes the firmware upgrade progress, verifies the firmware, and finishes with an overview stating whether the firmware was successfully uploaded.

Loading option module firmware using SFTP

Upload firmware to your meter's option modules by loading the firmware upgrade file onto your meter's internal SFTP site. Each option module must be upgraded individually.

Prerequisites:

- Option module firmware upgrade (.S19) file(s). Go to www.se.com to download upgrade files.
- Option module is connected to the meter.
- · Access to meter's internal SFTP site.

The meter's digital and analog outputs may change state during a firmware upgrade. Option modules are offline during an option module firmware upgrade. They will not communicate to the meter and the outputs may change state during the upgrade process.

WARNING

UNINTENDED OPERATION

Do not use this device for critical control or protection of persons, animals, property, or equipment.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

NOTE: If your meter's option module loses power during firmware upload, the option module will revert to its original firmware and you will have to reload the firmware file.

To load firmware option module firmware using SFTP:

- 1. Connect to your meter's internal SFTP site.
- 2. Open the (optionModuleUpg) folder.
- 3. Open the option module folder that applies to the module to be upgraded.
- 4. Drag the option module firmware file into the option module upgrade folder.
 - The file is immediately transferred to the option module, and is not stored on the meter.
- 5. Review the option module firmware upgrade details stored in the meter's event log to confirm that the upload was successful. The upgrade folder must match the position of the option module (A through D).

Maintenance

Maintenance overview

The meter does not contain any user-serviceable parts. If the meter requires service, contact your local Schneider Electric Technical Support representative.

NOTICE

METER DAMAGE

- Do not open the meter case.
- Do not attempt to repair any components of the meter.

Failure to follow these instructions can result in equipment damage.

Do not open the meter. Opening the meter voids the warranty.

Editing accumulated energy values using ION Setup

You can edit energy values such kWh and kVARh using ION Setup.

NOTE: Ensure you have recorded accumulated energy values before upgrading your meter's firmware. You can then re-enter these values after the upgrade.

NOTE: Revenue-locked meters must be unlocked before accumulated energy values can be edited. See "Revenue locking your meter" on page 295 for more information

- 1. Start ION Setup.
- 2. Open the **Setup Assistant** for your meter.
- 3. Click Template.
- 4. Click the **Register Edit** tab, click **Energy** then click **Display**. Enter your meter's password (if prompted) and click **OK**.

The Register Editor screen displays.

- 5. Click **Edit** to enable editing.
- 6. Enter values for kWh, kVAh and kVARh as required. Click **Send** to finish.

NOTE: Only values that have the check box selected will be sent to the meter.

7. Click Close to close the Register Editor screen.

Test mode

Test mode is typically used for verifying meter functions.

The meter is usually reading data from a test power supply while function verification is performed.

The values shown in the test mode display screens represent different accumulators than those shown in norm or alt mode (although they perform some of the same basic measurements). The test mode display values are for accuracy checking purposes; they only accumulate while the meter is in test mode.

You can create custom test mode screens and modify the existing test mode screens.

NOTE: You cannot place revenue-locked meters into test mode.

Several things to note about test mode:

- All of the billing quantities that are recorded when the meter is in Normal mode stop
 accumulating when the meter is switched to test mode the data is sent to special test mode
 registers instead.
- The values accumulated in these test registers are displayed on the test mode displays and in ION Setup.
- The regular normal mode billing registers are unaffected while the meter is in test mode; accumulation of this data continues as soon as you exit test mode.
- All test registers are reset to zero when you exit test mode.

Test mode default screens

Your meter has default test mode display screens.

NOTE: You can modify the test mode display screens or add custom screens using ION Setup.

Screen	Description
Demand test	This screen shows test mode kW delivered and received values. Both quantities are produced from a sliding window (rolling block) demand calculation.
Reactive energy test	This screen shows test mode kVARh delivered and received values.
Active energy test	This screen shows test mode kWh delivered and received values.

Putting your meter in test mode using ION Setup

NOTE: You cannot place a revenue-locked meter into test mode.

To put your meter into test mode using ION Setup:

- 1. Start ION Setup.
- 2. Open the Setup Assistant for your meter.
- 3. Navigate to **Verification** and select the **Verification** tab.

4. Select Test Mode and click Display.

Your meter is now in test mode, and the Test Mode screen is displayed.

- 5. Select the different tabs to view your meter's test mode values and modify test mode parameters.
- 6. Click **Close** to take your meter out of test mode.

Putting your meter in test mode using the display

You can put your meter into test mode using the display.

NOTE: You cannot place a revenue-locked meter into test mode.

- 1. Press the Home button.
- 2. Press **Up** or **Down** to navigate to **Normal Display Mode**.
- 3. Press Select.
- 4. Press **Down** to navigate to **Test Mode**.
- 5. Press **Select** to enter the **Test Mode Screens**. Enter the meter password if prompted and press **Select**.

The **Test Mode** menu displays briefly before switching to the first **Test Mode** screen.

- 6. View the test mode screens by pressing **Up** or **Down**.
- 7. Press the Home button to return to **Test Mode Screens**. Press **Down** to highlight **Exit Test Mode**, then press **Select**.

Cleaning instructions

Your meter is rated for Pollution Degree 2: Normally, only non-conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation may be expected.

You should periodically inspect and clean your meter. Non-conductive pollution could negatively impact the meter by impeding air flow and cooling. Abrasive contaminants can reduce the meter lifespan.

NOTE: The meter is rated as IP30 (not protected from liquids.) The front of the meter display is rated as IP54 (dust and water resistant) or IP65 (dust and water proof.) To review your meter's display specifications, see "Display" on page 314.

Prerequisites:

· Turn off all power supplying the device before cleaning it.

A DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Apply appropriate Personal Protective Equipment (PPE) and follow safe electrical work practices. See NFPA 70E, CSA Z462 or other local standards.
- Turn off all power supplying this device and the equipment in which it is installed before working on or in the equipment.
- Always use a properly rated voltage sensing device to confirm that all power is off.
- Do not use the data from the meter to confirm power is off.
- Do not short secondary terminals of Voltage Transformer (VT).
- Do not open secondary terminals of Current Transformer (CT).
- Secure CT or Low Power Current Transformers (LPCT) secondary conductors to ensure they
 do not contact live circuits.
- Assume communications and I/O wiring are hazardous live until determined otherwise.
- Replace all devices, doors and covers before turning on power to this equipment.

Failure to follow these instructions will result in death or serious injury.

To clean the meter and accessories:

- Use compressed air (up to 30 PSI or ~200 kPa) to remove non-conductive pollution from inside and around the meter or any of its accessories.
- Clean meter surfaces using a cloth dampened with water. *

NOTE: Do not allow liquids to enter the device through ventilation slots, connectors, or other openings.

If you are not certain about how to remove abrasive contaminants from the meter or its
accessories, contact Support or your Schneider Electric representative. Improperly removing
contaminants and pollution may void the warranty.

To clean the display:

- Wipe the display using a cloth dampened with water. *
- * You can use 70% isopropyl alcohol instead of water if absolutely necessary. Cleaning the device too frequently with isopropyl alcohol could damage the printing on labels and buttons. If you are concerned about the risk of infection from touching surfaces, wear gloves or use hand sanitizer afterward.

Device-specific information

Manufacturing-related information about the meter is available from the Factory module or through Modbus commands.

The meter's Factory module stores meter details such as device type, serial number, and vendor name. You can use ION Setup in advanced mode to view the contents of the Factory module's setup registers. Similarly, you can use Modbus commands to read the Modbus registers mapped to the corresponding Factory module's registers.

NOTE: Not all ION device setup registers are mapped to Modbus registers by default.

Other device-specific details, such as Product Code, are not stored in the Factory module. Product Code (also known as Modbus Product ID) is a number that the manufacturer assigned to a product to uniquely identify it, for use by systems that specifically require this information. You can use the device's Modbus map and Modbus commands to read the Modbus Product ID.

For more information on the Factory module, see ION Reference, available on www.se.com.

Revenue

A revenue meter provides, over a defined range of operating conditions, measurements that are within international and national defined standards and industry-accepted accuracy limits.

It also provides protection against unauthorized alteration of these measured quantities. National and utility-based standards regulate protection against unauthorized alteration of measured quantities.

Revenue metering components

To meet government regulations and utility security requirements, the meter incorporates three types of security systems:

- Traditional anti-tamper mechanical seals on the meter. See your device installation guide.
- Passcode entry to reset meter values, for example, Master reset.
- Hardware locking mechanism that prevents modification of revenue quantities after they are locked.

Revenue firmware security features

Your revenue meter has additional firmware security features:

- Your firmware upgrades are recorded in your meter's upgrade log. Contact Technical Support for information on upgrade log retrieval.
- When revenue-locked, you cannot perform resets, configure some revenue-specific parameters, or upgrade your meter.

Protected features and settings

Your revenue meter has features and settings that cannot be changed while revenue-locked.

In order to prevent changes to revenue-related features, settings and meter data, you can apply revenue-locking after all revenue-metering setup is complete. See the *ION Device Template Reference*, available from www.se.com, for a complete listing of revenue-locked features and settings.

Revenue locking

Revenue locking may be required to help meet government regulations and utility security requirements.

Revenue locking your meter helps:

- Prevent changes to revenue-related features, settings and meter data.
- Prevent tampering with your meter's voltage and current connections.
- Ensure the validity of revenue data.

See the *ION Device Template Reference*, available from www.se.com, for a complete listing of revenue-locked features, settings and meter data.

See the meter's catalog pages, available from www.se.com, or consult your local Schneider Electric representative for information about your device, its options and accessories.

Revenue-locking summary

You must configure and revenue lock your meter before installing it.

- · Unlock your revenue meter if it is locked.
- Configure the required revenue settings specific for installation.


NOTE: If you are using ION Setup to configure your meter, allow for any communication delays before removing power to your meter.

- Verify the revenue settings have been implemented.
- Clear all accumulated meter data.
- · Revenue lock your meter.
- · Verify the meter is revenue-locked.
- Install the meter and install the terminal covers according to your meter's installation guide.

Revenue lock switch

The revenue lock switch located on the meter base is used to revenue lock your meter.

This switch is accessed through a sealable cover.



A Revenue lock switch cover
 B Sealing point
 C Toggle switch
 D Revenue lock LED

Revenue lock LED behavior

The revenue lock LED indicates the lock status of the meter.

LED behavior	Revenue lock status
Off	The meter is not revenue locked.
On	The meter is revenue locked.
Flashing	New revenue lock state is pending; power cycle your meter to set the revenue lock to on or off.

Revenue locking your meter

You can lock and unlock your meter using the revenue lock switch located on the meter base.

A DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Apply appropriate Personal Protective Equipment (PPE) and follow safe electrical work practices. See NFPA 70E, CSA Z462 or other local standards.
- Turn off all power supplying this device and the equipment in which it is installed before
 working on or in the equipment.
- Always use a properly rated voltage sensing device to confirm that all power is off.

Failure to follow these instructions will result in death or serious injury.

- 1. Open the revenue lock switch cover.
- 2. Locate the revenue lock switch.
- 3. Toggle revenue lock switch on or off.
- 4. Close the revenue lock switch cover and make sure it is firmly in place.
- 5. Seal the revenue lock switch cover if required.

Anti-tamper sealing

The meter has several anti-tamper sealing points which can be sealed by a wire seal or lock.

In certain countries, the meter is no longer revenue certified if the anti-tamper seals are broken.

See your meter's installation guide for sealing point locations.


NOTICE

LOSS OF COMPLIANCE

Re-certify your meter with the appropriate revenue metering authorities if you remove the anti-tamper seals.

Failure to follow these instructions may render your device non-compliant for billing purposes.

Revenue lock switch seal



PT/CT correction

Potential transformer/current transformer correction (PT/CT correction), also called instrument transformer correction, can help reduce the need to replace transformers in installations where high accuracy is required.

The primary application for PT/CT correction is to apply correction factors for ratio errors and phase angle errors to instrument transformers. PT/CT correction is done for each current and voltage input to the meter and only affects 1-second power meter data and values derived from it, such as energy or demand. No high-speed, harmonics or waveform values are affected by the correction.

NOTE: For those familiar with ION architecture, the relevant 1-second Power Meter module outputs are compensated using the Instr Xformer (ITC) Correction module. All other modules that use the 1-second Power Meter module's data are also compensated.

See the ION Setup online help, available from www.se.com, for instructions on how to configure PT/CT correction on your device.

For more information about the Instr Xformer Correction (ITC) module and how it applies PT/CT correction to your device, see *ION Reference*, available on www.se.com.

Transformer loss compensation

Transformer Loss Compensation (TLC) is the method for compensating for the measurable losses that occur when there is a physical separation between the meter and the actual billing point.

TLC is used when a meter's actual location is different from the electrical location where change of ownership occurs, for example, if meters are connected on the low-voltage side of power transformers but the ownership change occurs on the high-side of the transformer. Meters are usually installed on the low-voltage side of a transformer because it is more cost-effective

NOTE: Due to the variation in installations, advanced knowledge of power systems and connection methods is required before transformer loss compensation can be properly implemented. Data parameters should only be programmed by qualified personnel that have appropriate training and experience with Transformer Loss Compensation calculations.

There are cases where the change of ownership occurs halfway along a transmission line, where it is impractical to install a meter. In this case, power metering must be compensated using line loss calculations.

For more information, see the <u>PowerLogic Transformer Line Loss Calculations</u> technical note, available on www.se.com.

Time of use

Time of Use (TOU) is often used when a utility has set up schedules with different rates based on time of day, type of day and date when energy is consumed.

You can view the TOU active rates and seasons using the display.

For more information on how to configure TOU on your meter, see the ION Setup online help, available from www.se.com.

For more information on the Time of use module and its settings, see *ION Reference*, available on www.se.com.

Energy pulsing LED behavior

The visible and infrared LEDs are configured by default to pulse based on energy measured by the meter.

You can configure the pulse weight (pulses per kWh) and the energy source.

Energy pulsing is used to help verify the energy measurement accuracy of your meter for revenue purposes.

Verifying accuracy

Verifying accuracy overview

All meters are tested and verified at the factory in accordance with International Electrotechnical Commission (IEC) and American National Standards Institute (ANSI) standards.

Your digital power meter typically does not require re-calibration. However, in some installations a final accuracy verification of the meters is required, especially if the meters will be used for revenue or billing applications.

For a list of accuracy standards that your meter complies to, contact your local Schneider Electric representative or download the meter brochure from www.se.com.

Accuracy test requirements

The most common method for testing meter accuracy is to apply test voltages and currents from a stable power source and compare the meter's readings with readings from a reference device or energy standard.

Signal and power source

The meter maintains its accuracy during voltage and current signal source variations but its energy pulsing output needs a stable test signal to help produce accurate test pulses. The meter's energy pulsing mechanism needs approximately 10 seconds to stabilize after every source adjustment.

The meter must be connected to control power in order to conduct accuracy verification testing. Refer to your meter's installation documentation for power supply specifications.

DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Verify the device's power source meets the specifications for your device's power supply.

Failure to follow these instructions will result in death or serious injury.

Control equipment

Control equipment is required for counting and timing the energy pulse outputs from a visible LED, infrared LED or onboard digital output.

- Most standard test benches have an arm equipped with optical sensors to detect LED pulses (the photodiode circuitry converts detected light into a voltage signal).
- The reference device or energy standard typically has digital inputs that can detect and count
 pulses coming from an external source (i.e., the meter's onboard digital output).

NOTE: The optical sensors on the test bench can be disrupted by strong sources of ambient light (such as camera flashes, florescent tubes, sunlight reflections, floodlights, etc.). This can cause test errors. Use a hood, if necessary, to block out ambient light.

Environment

The meter should be tested at the same temperature as the testing equipment. The ideal temperature is about 23 °C (73 °F). Make sure the meter is warmed up sufficiently before testing.

A warm-up time of 30 minutes is recommended before beginning energy accuracy verification testing. At the factory, the meters are warmed up to their typical operating temperature before calibration to help ensure that the meters will reach their optimal accuracy at operating temperature.

Most high precision electronic equipment requires a warm up time before it reaches its specified performance levels. Energy meter standards allow the manufacturers to specify meter accuracy derating due to ambient temperature changes and self-heating.

Your meter complies with and meets the requirements of these energy metering standards.

For a list of accuracy standards that your meter complies with, contact your local Schneider Electric representative or download the meter brochure from www.se.com.

Reference device or energy standard

To help ensure the accuracy of the test, it is recommended that you use a reference device or reference energy standard with a specified accuracy that is 6 to 10 times more accurate than the meter under test. Before you start testing, the reference device or energy standard should be warmed up as recommended by its manufacturer.

NOTE: Reference equipment with a traceable calibration certificate is recommended when performing accuracy testing.

Energy pulsing

Energy pulsing LEDs and digital outputs can be used for energy pulsing.

Your meter is equipped with two types of energy pulsing LEDs: visible light and infrared. These LEDs emit pulses that are then used to determine the accuracy of the meter's energy measurements. The pulses of light indicate accumulated energy; the meter's accumulations are compared with the reference/standard's accumulated energy in order to help determine the meter's accuracy.

The meter's digital output can also be used for energy pulsing. A closing (low impedance) and then opening (high impedance) of the digital output represents a pulse. If the accuracy testing equipment has a voltage requirement, a current-limited wetting supply voltage must be provided.

NOTE: Digital outputs on option modules should not be used for meter accuracy testing.

Verifying accuracy test meter settings

Your meter's power system and other parameters must be configured for accuracy testing.

Meter parameter	Value
Volts mode	4W-Wye (4 wire Wye)
PT/CT correction	Disabled
	Active
Test mode	NOTE: In test mode, your meter's billing quantities stop accumulating, and the data is sent to special test mode registers. These registers are cleared when you exit test mode.

Verifying accuracy test

The following tests are guidelines for accuracy testing your meter; your meter shop may have specific testing methods.


A DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Apply appropriate Personal Protective Equipment (PPE) and follow safe electrical work practices. See NFPA 70E, CSA Z462 or other local standards.
- Turn off all power supplying this device and the equipment in which it is installed before working on or in the equipment.
- · Always use a properly rated voltage sensing device to confirm that all power is off.
- Do not exceed the maximum ratings of this device.
- Verify the device's power source meets the specifications for your device's power supply.

Failure to follow these instructions will result in death or serious injury.

Connect the test voltage and current source to the reference device or energy standard.
 Ensure all voltage inputs to the meter under test are connected in parallel and all current inputs are connected in series.



Α	Reference device or energy standard
В	Test voltage and current source
С	Meter under test

2. Connect the control equipment used for counting the standard output pulses using one of these methods:

Option	Description
Energy pulsing LED	Align the red light sensor on the standard test bench armature over the energy pulsing LED.
Onboard Digital output	Connect the meter's onboard digital output to the standard test bench pulse counting connections.

NOTE: When selecting which method to use, be aware that energy pulsing LEDs and digital outputs have different pulse rate limits.

- 3. Before performing the verification test, let the test equipment power up the meter and apply voltage for at least 30 seconds. This helps stabilize the internal circuitry of the meter.
- 4. Configure your meter power settings (such as voltage, current and frequency) to align with the reference device.
- 5. Depending on the method selected for counting the energy pulses, configure the meter's energy pulsing LED or one of the digital outputs to perform energy pulsing. Set the meter's energy pulse constant so it is in sync with the reference test equipment.
- Perform accuracy verification on the test points. Run each test point for at least 30 seconds to allow the test bench equipment to read an adequate number of pulses. Allow 10 seconds of dwell time between test points.

Calculate the number of required pulses

The reference test equipment typically requires you to specify the number of pulses required for a test duration of "t" seconds.

Normally, the number of pulses required is at least 25 pulses, and the test duration is greater than 30 seconds.

Use the following formula to calculate the required number of pulses:

Number of pulses =	Ne * V * I * PF * t	
CAPACE STANDARDS PERSON STANDARDS STANDARDS	3600 * Kt	
Ne Number of metering elements used		
V	Test point voltage in line-to-neutral volts (V) per phase	
I	Test point current in amps (A) per phase	
t	Test duration in seconds (s) which must be longer than 30 seconds	
PF	Power factor	
Kt	Pulse constant programmed in the meter under test in Wh/pulse	

Round up the result of the calculation to the nearest integer number of pulses.

Calculation for number of required pulses

This example calculates the number of pulses required for an inductive load 3-phase test point with a test duration of 60s; the source is configured to use V = 120V, I = 5A, PF = -0.5; the pulse constant of the meter under test is Kt = 1.8 Wh/pulse.

Round the number up to the nearest integer: Number of pulses = 9

Percentage error calculation for accuracy verification testing

Accuracy verification testing requires you to calculate the percentage error between the meter being tested and the reference/standard.

Calculate the percentage error for every test point using the following formula:

Energy error = (EM - ES) / ES x 100%

Where:

- EM = energy measured by the meter under test
- ES = energy measured by the reference device or energy standard.

NOTE: If accuracy verification reveals inaccuracies in your meter, they may be caused by typical sources of test errors. If there are no sources of test errors present, please contact your local Schneider Electric representative.

Typical sources of test errors

If you see excessive errors during accuracy testing, examine your test setup and test procedures to eliminate typical sources of measurement errors.

Typical sources of accuracy verification testing errors include:

- Loose connections of voltage or current circuits, often caused by worn-out contacts or terminals. Inspect terminals of test equipment, cables, test harness and the meter under test.
- Meter ambient temperature is significantly different than 23 °C (73 °F).
- Floating (ungrounded) neutral voltage terminal in any configuration with unbalanced phase voltages.
- Inadequate meter control power, resulting in the meter resetting during the test procedure.
- Ambient light interference or sensitivity issues with the optical sensor.
- Unstable power source causing energy pulsing fluctuations.
- Incorrect test setup: not all phases connected to the reference device or the energy standard.
 All phases connected to the meter under test should also be connected to the reference meter/standard.
- Moisture (condensing humidity), debris or pollution present in the meter under test.

Accuracy verification test points

The meter should be tested at full and light loads and at lagging (inductive) power factors to help ensure testing over the entire range of the meter.

The test amperage and voltage input rating are labeled on the meter. Refer to the installation guide or data sheet for your meter's nominal current, voltage and frequency specifications.

Watt-hour test point	Sample accuracy verification test point
Full load	100% to 200% of the nominal current, 100% of the nominal voltage and nominal frequency at unity power factor or one (1).
Light load	10% of the nominal current, 100% of the nominal voltage and nominal frequency at unity power factor or one (1).
Inductive load (lagging power factor)	100% of the nominal current, 100% of the nominal voltage and nominal frequency at 0.50 lagging power factor (current lagging voltage by 60° phase angle).

VAR-hour test point	Sample accuracy verification test point	
Full load	100% to 200% of the nominal current, 100% of the nominal voltage and nominal frequency at zero power factor (current lagging voltage by 90° phase angle).	

VAR-hour test point	Sample accuracy verification test point
Light load	10% of the nominal current, 100% of the nominal voltage and nominal frequency at zero power factor (current lagging voltage by 90° phase angle).
Inductive load (lagging power factor)	100% of the nominal current, 100% of the nominal voltage and nominal frequency at 0.87 lagging power factor (current lagging voltage by 30° phase angle).

Troubleshooting

Review the topics in this section to get more information on how to troubleshoot your meter and where to obtain technical assistance.

Setting up Advanced security troubleshooting

Some users could experience software access issues after enabling Advanced Security mode. Resolve software access issues using these troubleshooting steps:

Meter state	Example behavior	Solution – follow tasks in the order listed
New meter Login credentials are unknown	Login gradentials are unknown	 Verify that you are using the newest version of ION Setup.
	Login credentials are unknown.	 Enter Username: User1 and Password: 0 [zero].

Meter state	Example behavior	Solution – follow tasks in the order listed
	Using EcoStruxure [™] Power Monitoring Expert software and after password is entered, access is not granted.	 Verify that you are using the newest version of ION Setup.
		 Verify you are using meter firmware v3.0.0.
		 Configure software meter security settings.
		 Enter meter username: User1 and Password: [password used before upgrade to firmware v3.0.0].
	Using Vista software and after password is entered, access is not granted.	Go to www.se.com and search for support to get assistance with troubleshooting.
Meter recently upgraded to firmware v3.0.0	Using EcoStruxure™ Power Operation software.	Go to www.se.com and search for support to get assistance with troubleshooting.
	Incorrect credentials are entered multiple times and a lockout occurs.	Wait until lockout duration is over and account is not locked out. If a user account is locked out, that user can still access the device by entering the correct credentials over a different protocol and communications method.
	Login credentials are unknown.	 Verify that you are using the newest version of ION Setup.
		 Enter meter username: User1 and Password: [password used before upgrade to firmware v3.0.0].

Option module troubleshooting

Events related to option module initialization and operation are stored in your meter's onboard event log. Perform an option bus reset to restart the option bus and re-initialize the option modules attached to your meter. Reviewing the events in the event log within the first minute of option bus reset will provide the most specific details of the detected problem with your option module.

When troubleshooting option modules, attach each option module directly to the meter and verify its operation. If each option module operates when directly connected, use combinations of modules or known good modules to help identify the issue.

Information about your option module's type, serial number, firmware version and present status is available in the Factory and Diagnostics modules.

See *ION Reference*, available from www.se.com, for more information about the Factory and Diagnostics modules.

Technical assistance

Go to www.se.com and search for support to get assistance with troubleshooting.

Have the meter model, serial number and firmware version information ready. See "Device-specific information" on page 291 for details about obtaining this information.

You may be asked by a customer care agent to enable factory access to the device for troubleshooting. Factory access is gained after a unique diagnostic access code is used to login to the device over a secure protocol.

Factory access:

- Is disabled by default.
- Is temporarily enabled for a duration defined in the Factory Access minutes register.
- Requires adequate user privileges to enable.
- · Provides read and write permissions.

ION9000 specifications

This section provides additional specifications for your meter and accessories.

NOTE: The information contained in this section is subject to change without notice. You can download updated documentation from www.se.com or contact your local Schneider Electric representative for the latest updates.

Mechanical characteristics

ION9000 series meter

Mounting entions	DIN rail: IEC 60715 (DIN EN 60715), TH 35–7.5 or TH 35–15
Mounting options	Panel mount: with 9B2BMA
Orientation	Vertical, retaining clips located on bottom of meter
IP degree of protection	IP30 (except connectors)
Maximum number of option modules	4 (based on maximum operating temperature)

Mechanical compliance

Vibration	IEC 60068-2-6
	IEC 60068-2-57
Shock	IEC 60068-2-27
	IEC 60068-2-31, Test Ec Free fall procedure 1

Electrical characteristics

Measurement accuracy

Active energy (Wh)	IEC 62053-22 Class 0.1 S
Reactive energy (VARh)	IEC 62053-24 Class 0.5 S
Power monitoring device (PMD)	IEC 61557-12 PMD/SD/K70/0.2 and PMD/SS/K70/0.2
Active power (P)	IEC 61557-12 Class 0.1
Reactive power (Q _V)	IEC 61557-12 Class 1
Apparent power (S _V)	IEC 61557-12 Class 0.2
Apparent energy (E_{apV})	IEC 61557-12 Class 0.2
Current (I)	IEC 61557-12 Class 0.1
Voltage (U)	IEC 61557-12 Class 0.1
Frequency (f)	IEC 61557-12 Class 0.02

NOTE: Reactive energy and demand values, by default, are based only on the fundamental frequency, and do not include higher harmonics. Active and apparent energy and demand values are measured using the entire signal, including harmonics.

Power quality

	IEC 62586-1/2 PQI-A
Power quality instrument (PQI)	IEC 61000-4-30 Class A (<i>U</i> _{din} = 230 V)
	IEC 61000-4-15 Class F1 (<i>U</i> _n = 230 V, 120 V)
Voltage unbalance (U _{nb})	IEC 61557-12 Class 0.2
Voltage harmonics (<i>U</i> _h)	IEC 61557-12 Class 1
Voltage THD (THD _u)	IEC 61557-12 Class 1
Current harmonics (I _h)	IEC 61557-12 Class 1
Current THD (THD _i)	IEC 61557-12 Class 1
Waveform capture	16–1024 samples per cycle

Voltage inputs

Specified accuracy range	57–400 V L-N/100–690 V L-L (Wye) or 100–600 V L-L (Delta or Wye with unearthed neutral)
Specified accuracy frequency	50/60 Hz ± 15%
	400 Hz ± 10%
Overload	600 V L-N or 1035 V L-L
Impedance	> 5 MΩ
Measurement category	III

Current inputs

Nominal	IEC: 1A/5A (Class 0.1 S)
	ANSI: Current Class 2, 10, 20 (Accuracy Class 0.1)
Specified accuracy current range	10 mA-20 A
Starting current	1 mA
Withstand	30 A continuous, 50 A @ 10 sec/hr, 500 A @ 1 sec/hr
Impedance	0.3 mΩ (typical)
Burden	0.01 VA maximum at 5 A

LVCS current inputs

Input voltage range	± 5.5 V pk
Minimum signal	1 mV
Withstand	30 V pk continuous
Input impedance	200 kΩ

Control power

AC control power	
Operating range	50/60 Hz ± 10%: 90–480 V ± 10%
	400 Hz: 90–120 V ± 10%
Rurdon (motor only)	Maximum: 16.5 W/38 VA @ 480 V (45–65 Hz)
Burden (meter only)	Maximum: 13 W/24 VA @ 120 V (400 Hz)
Burden (fully optioned meter)	Maximum: 40 W/80 VA @ 480 V (45-65 Hz)
	Maximum: 36 W/58 VA @ 120 V (400 Hz)
	100 ms (6 cycles at 60 Hz) typical, 120 V AC
Ride-through time (no optional accessories)	400 ms (24 cycles at 60 Hz) typical, 240 V AC
	1200 ms (72 cycles at 60 Hz) typical, 480 V AC
DC control power	
Operating range	110-480 V DC ± 10%
Burden (meter only)	Maximum: 13.5 W at 480 V DC
Burden (fully optioned meter)	37 W at 480 V DC
Overvoltage category	III

Low-voltage DC control power

DC control power	
Operating range	20-60 V DC ± 10%
Burden (meter only)	Maximum: 15 W at 20–60 V DC
Burden (fully optioned meter)	Maximum: 38 W at 20-60 V DC
Overvoltage category	III

Digital output (Form A)

Number	4
Туре	Form A solid-state
Reference voltage	40 V
Maximum load voltage	30 V AC/60 V DC
Maximum load current	75 mA
ON resistance	13–40 Ω at 25 °C (77 °F)
Signal type	Continuous or pulse
Pulse frequency	≤ 25 Hz

Relay output (Form C)

Number	2
Туре	Form C mechanical relay

Maximum load voltage	250 V AC/30 V DC
Maximum load current	8 A @ 250 V AC
	5 A @ 24 V DC
	20k cycles (resistive)
Operate time	Maximum: 10 ms
Release time	Maximum: 5 ms
Lifetime	No Load: 10,000,000 operations
	Rated Voltage and Load: 50,000 operations

Digital inputs

Number	8
Туре	Externally excited, 24 V DC whetting voltage available from the meter
Reference voltage	40 V
Event timestamp accuracy	± 1 ms
Maximum valtaga	30 V AC
Maximum voltage	60 V DC
Pulse frequency	≤ 25 Hz
Response time	1 cycle
Minimum pulse width	20 ms
Current direct	ON: ≤ 2.5 mA
Current draw	OFF: ≤ 0.5 mA
Voltage ON state	4–30 V AC
	4-60 V DC
V-14 OFF -4-4-	0–1.4 V AC
Voltage OFF state	0-2.0 V DC
IRIG-B	IRIG-B00x format (unmodulated IRIG-B time code)
	Coded expressions 0–7 are supported but the year data is not used.

Whetting source (Digital inputs)

Output voltage	24 V DC
Output current	20 mA
Maximum load	8 digital inputs (meter base)

Environmental characteristics

	–25 °C to Max temp (−13 °F to Max temp)
Operating temperature	NOTE : Maximum operating temperature could change based on the quantity and type of attached option modules. See <i>Maximum operating temperature with option modules</i> below.
Storage temperature	–40 °C to 85 °C (–40 °F to 185 °F)
Humidity rating	5%–95% RH non-condensing
	Maximum dewpoint: 37 °C (99 °F)
Pollution degree	2
Altitude	< 3000 m (9843 ft) above sea level
	Not suitable for wet locations
Location/mounting	For indoor use only
	Must be permanently connected and fixed

Maximum operating temperature with option modules

Maximum operating	PM89M2600	PM89M0024
temperature	Digital (2 out, 6 in)	Analog (2 out, 4 in)
70 °C (158 °F)	0–4	0,1
70 °C (158 °F)	0	2
60 °C (140 °F)	1, 2	2–4

LEDs

Energy pulsing LEDs (visible and infrared)

Туре	Visible orange, infrared
Wavelength	600-609 nm (orange), 825-925 nm (infrared)
Maximum pulse rate	10 Hz (100 ms)

Status LEDs (visible)

Type Bi-color, red/green

EMC (electromagnetic compatibility)

EMC standards	IEC 62052-11, IEC 61326-1, IEC 61000-6-5	
---------------	--	--

Immunity to electrostatic discharge	IEC 61000-4-2
Immunity to radiated fields	IEC 61000-4-3
Immunity to fast transients	IEC 61000-4-4
Immunity to surges	IEC 61000-4-5
Immunity to conducted disturbances	IEC 61000-4-6, IEC 61000-4-16
Immunity to power frequency magnetic fields	IEC 61000-4-8
Immunity to conducted disturbances, 2 - 150 kHz	CLC/TR 50579
Immunity to voltage dips and interruptions	IEC 61000-4-11
Immunity to ring waves	IEC 61000-4-12
Conducted and radiated emissions	EN 55011 and EN 55032 Class B, FCC part 15 Class B, ICES-003 Class B
Surge withstand capability (SWC)	IEEE/ANSI C37.90.1

Safety

	IEC/EN 61010-1, CAT III, 400 VLN / 690 VLL
Safety construction	UL 61010-1 and CSA-C22.2 No. 61010-1, CATIII, 347 V LN / 600 VLL
	IEC/EN 62052-31, Protective Class II

Ethernet communications

Number of ports	2 (switched mode)
Maximum cable length	100 m (328 ft), per TIA/EIA 568-5-A
Cable type	CAT5 (or higher)
Connector type	Unshielded RJ45 modular connector (2)
Mode	10Base-T, 100Base-TX, Auto-MDIX
Data rate	up to 100 Mbps

RS-485 communications

Number of ports	2
Cable type	Shielded twisted pair
Maximum cable length	1200 m (4000 ft)
Maximum number of devices (unit loads)	Up to 32 devices on the same bus
Parity	None, even, odd
Baud rate	2400–115200, 19200 recommended

Real-time clock

Clock drift (time error)	Meter Powered ON: 5 ppm maximum
	Meter Powered OFF: 20 ppm maximum at 25 °C (77 °F)
Battery backup time	Minimum 7 years under specified storage conditions

Display

METSERD192 display

WE TOLING 192 display	
Display	
Display type	Capacitive touchscreen, WVGA color graphic TFT LCD 800 x 480 resolution
Display backlight	White LED
Viewable area	152.5 x 91.5 mm (6.00 x 3.60 in)
Weight	0.9 kg (2.0 lb)
Communications ports	
Optical communications ports	ANSI C12.18 optical port
	IEC 1107 optical port adapter
USB communications ports	USB host port: Type A USB
	USB device port: Mini-B USB
Control power	
Power over Ethernet (PoE) power	PD Type 1 Class 3 per IEEE 802.3af, 10W maximum

Auxiliary control power	24 V DC ± 20%
(Not required for PoE applications)	DC burden 10 W maximum
	Use UL listed or UL recognized NEC class 2 (or equivalent
	SELV or PELV) power source
Communication connection	
Cable type	CAT5 (or higher). Use with unshielded RJ45 modular
	connector
Cable length	100 m (330 ft) maximum
Connection type	Direct, point-to-point
Environment	
Operating temperature	–20 °C to 60 °C (–4 °F to 140 °F)
Storage temperature	–40 °C to 85 °C (–40 °F to 185 °F)
Humidity rating	5%–95% RH non-condensing
	Maximum dewpoint: 37 °C (99 °F)
Pollution degree	2
Altitude	< 3000 m (9843 ft) above sea level
IP degree of protection	Front: IP65
	Rear: IP30
Location/mounting	For UL Type 12 applications, install display on a flat surface
	of a Type 12 enclosure
	Not suitable for wet locations
	For indoor use only

Option modules

See your option module's installation guide for additional option module specifications.

METSEPM89M0024 Analog (2 out, 4 in)

Maximum number of modules	4
Input resistance	< 300 Ω (current mode)
	> 500 kΩ (voltage mode)
Input voltage mode	0-30 V DC
Input current mode	4–20 mA , 0–20 mA
Operating temperature	–25 to 70 °C (−13 to 158 °F)
	Maximum operation temperature is based on the quantity and type of attached option modules.

METSEPM89M2600 Digital (2 out, 6 in)

|--|--|

	–25 to 70 °C (−13 to 158 °F)
Operating temperature	Maximum operation temperature is based on the quantity and type of attached option modules.

METSEPMRS4854W 4-Wire RS-485

Maximum number of modules	1
	–25 to 70 °C (–13 to 158 °F)
Operating temperature	Maximum operation temperature is based on the quantity and type of attached option modules.

METSEPMFIBER Fiber Ethernet

Maximum number of modules	1
	–25 to 70 °C (–13 to 158 °F)
Operating temperature	Maximum operation temperature is based on the quantity and type of attached option modules.

Other

Parameter	Description
Weight (meter base only)	1.5 kg (3.3 lb)
Weight (Measurement Canada)	3.23 kg (7.12 lb)
Meter start time ¹	25 seconds: Measurements
	35 seconds: Communications
	45 seconds: Display initialization
Meter storage	2000 MB
Data update rate	Regular data: 1 second
	High-speed: 50/60 Hz half-cycle
Advanced security user accounts	Up to 50 users

^{1 –} Meter start up time is expressed as the typical elapsed time from the application of control power to the result indicated in the description field.

Schneider Electric

35 rue Joseph Monier 92500 Rueil Malmaison – France www.se.com

As standards, specifications, and designs change from time to time, please ask for confirmation of the information given in this publication.

©2023 Schneider Electric. All Rights Reserved.

7EN02-0390-08 10/2023